

Electropneumatic Positioner Type 4763



Fig. 1 · Type 4763

Mounting and Operating Instructions

EB 8359-2 EN

Edition September 2010



APPROVED

Contents

1	Design and principle of operation	6
2	Attachment	8
2.1	Attachment to valves with cast yokes	8
2.2	Attachment to valves with rod-type yokes	9
2.3	Cover of the positioner housing	9
3	Connections	10
3.1	Electrical connections	10
3.2	Pneumatic connections	11
3.2.1	Pressure gauges	11
3.2.2	Supply pressure	11
4	Operation	12
4.1	Combining positioner and actuator	12
4.1.1	Determining/reversing the operating direction	12
4.2	Starting point and input signal (reference variable)	14
4.3	Setting the positioner at the valve.	15
4.3.1	Setting the air delivery (volume restriction Q) and proportional band XP	15
4.3.2	Setting actuator version "Stem extends"	16
4.3.3	Setting actuator version "Stem retracts"	16
4.4	Exchanging the range spring	17
5	Converting an electropneumatic into a pneumatic positioner	18
6	Servicing explosion-protected devices	19
7	Maintenance, calibration and work on equipment	19
8	Accessories and mounting parts	20
9	Dimensions in mm	21
	Test certificates	22

General safety instructions



- ▶ *The positioner is to be mounted, started up or operated only by trained and experienced personnel familiar with the product.
According to these Mounting and Operating Instructions, trained personnel refers to individuals who are able to judge the work they are assigned to and recognize possible dangers due to their specialized training, their knowledge and experience as well as their knowledge of the applicable standards.*
- ▶ *Explosion-protected versions of this positioner are to be operated only by personnel who have undergone special training or instructions or who are authorized to work on explosion-protected devices in hazardous areas. Refer to section 6.*
- ▶ *Any hazards that could be caused by the process medium, the operating pressure, the signal pressure or by moving parts of the control valve are to be prevented by means of the appropriate measures.*
- ▶ *If inadmissible motions or forces are produced in the pneumatic actuator as a result of the supply pressure, the supply pressure must be restricted by means of a suitable supply pressure reducing station.*
- ▶ *Proper shipping and appropriate storage are assumed.*

- ▶ **Note:** *The device with a CE marking fulfils the requirements of the Directives 94/9/EC (ATEX) and 2004/108/EC.
The declaration of conformity is available on request.*

Versions

Electropneumatic Positioner Type 4763-	x	1	x	0	0	x	x	x	x	0	x	0	x	x	0
Explosion protection															
Without	0					2/7									
⊕ II 2G Ex ia IIC T6 acc. to ATEX	1														
CSA/FM intrinsically safe/non incandive	3														
⊕ II 3G Ex nA II T6 for Zone 2 (ATEX)	8					2/7									
Range spring															
Range spring 1, travel = 15 mm		1													
Range spring 2, travel = 30 mm, split-range 15 mm		2													
Range spring 3, travel = 60 mm, split-range 30 mm		3													
Pneumatic connections															
ISO 228/1 G ¼						1									
¼-18 NPT						3									
Electrical connection															
Cable gland															
M20 x 1.5 blue (plastic)						1									
M20 x 1.5 black (plastic)						2									
M20 x 1.5 (nickel-plated brass)						7			2						
i/p module															
Type 6109							1								
Type 6112							2								
Reference variable															
4 ... 20 mA								0							
0 ... 20 mA							2	2							
1 ... 5 mA							2	3							
Temperature range															
Standard									0						
Low temperature down to -45 °C							2	2							
Special version															
None										0	0	0			
For oxygen as the operating medium	0/1									0	1	6			
⊕ II 3 D IP 54 T 80 °C (with manufacturer's declaration)	8					2/7				0	1	8			

Type 4736 Positioner	
Travel range	7.5 to 60 mm, with 90 mm lever extension
Reference variable	4 to 20 mA (Ex) Internal resistance R_i at 20 °C approx. $250 \Omega \pm 7\%$
Split-range 0 to 50 % and 50 to 100 % Reference variable span (up to 50 mm travel)	4 to 20 mA (not Ex) Internal resistance R_i at 20 °C approx. $200 \Omega \pm 7\%$
	0 to 20 mA Internal resistance R_i at 20 °C approx. $200 \Omega \pm 7\%$
	1 to 5 mA Internal resistance R_i at 20 °C approx. $880 \Omega \pm 7\%$
	For type of protection Ex ia IIC, the data listed in the certificate of conformity must be observed
Range spring	See table on page 14
Supply air	Supply air 1.4 to 6 bar (20 to 90 psi)
Air quality acc. to ISO 8573-1 (2001)	Maximum particle size and density: Class 4 · Oil content: Class 3 Pressure dew point: Class 3 or at least 10 K below the ambient temperature to be expected
Output signal pressure p_{st}	Max. 0 to 6 bar (0 to 90 psi)
Characteristic	Linear · Deviation from terminal-based conformity: $\leq 1.5\%$
Hysteresis	$< 0.5\%$
Sensitivity	$< 0.1\%$
Operating direction	Reversible
Proportional band X_p (at 1.4 bar supply air)	1 to 3% with spring 1 or 2 1 to 1.5% with spring 3
Air consumption in steady state, $X_p = 1\%$	With 1.4 bar supply air: $0.19 \text{ m}^3/\text{h}$ With 6 bar supply air: $0.5 \text{ m}^3/\text{h}$
Air output capacity	At Δp 1.4 bar: $3.0 \text{ m}^3/\text{h}$ At Δp 6 bar: $8.5 \text{ m}^3/\text{h}$
Transit time for Type 3271 "Stem extends"	$240 \text{ cm}^2: \leq 1.8 \text{ s}$ · $350 \text{ cm}^2: \leq 2.5 \text{ s}$ · $700 \text{ cm}^2: \leq 10 \text{ s}$
Permissible ambient temperature	-20 to 70 °C; With metal cable gland: -35 to 70 °C Special version: -45 to 80 °C The limits specified in the EC Type Examination Certificate additionally apply for explosion-protected devices. Version with oxygen as operating medium up to max. 60 °C
Influences	Temperature $< 0.03\%/1 \text{ K}$ Supply air $< 0.3\%/0.1 \text{ bar}$ Vibration: $< 2\%$ between 10 and 150 Hz and 4 g Effect when turned by 180°: $< 3.5\%$
Degree of protection	IP 54 · Special version IP 65
Electromagnetic compatibility	Requirements according to EN 61000-6-2, EN 61000-6-3 and EN 61326-1 are met
Weight	Approx. 1.2 kg
Materials	Housing: Die-cast aluminum, chromated and plastic-coated External parts: Stainless steel




Fig. 3 · Functional diagram


2 Attachment

To attach the positioner to valves with cast yokes according to IEC 60534-6 (NAMUR rib), mounting parts (order no. 1400-5745) are used. For valves with rod-type yokes (pillars), the mounting kit (order no. 1400-5745) and additionally the mounting kit (order no. 1400-5342) are necessary (see also accessories table on page 20).

Since the positioner can be attached on either side of the valve, the physical location (left or right attachment) should be determined before actual attachment (see corresponding Figs. 7 to 10 in section 4.1).

2.1 Attachment to valves with cast yokes

1. Fasten the plate (20) to the stem connector clamps (22) of the valve using the screws (21).
2. Unscrew the positioner cover, and secure the device to the valve yoke using the mounting screw (15). The O-ring included in the mounting kit is not required for this device. Make sure that the pin (2) is routed inside the wire strap and therefore clamped against the plate (20).



2.2 Attachment to valves with rod-type yokes

1. Screw the plate (20), off-centered, to the travel indicator (24) of the plug stem (23) using the screws (21).
2. Place both the support (28) and the clamping plate (26) on the rod (27) and lightly fasten. Move the support until both the center of the plate (20) and the support (28) are aligned at half the valve travel.
3. Screw tight the support and clamping plate.

4. Mount the positioner to the support using the mounting screw (15). Make sure that the pin (2) is led inside the wire strap and therefore clamped against the plate (20).

2.3 Cover of the positioner housing

After attaching the positioner, make sure that the vent plug on the cover of the positioner housing points downwards after the valve has been installed.




Fig. 5 · Attachment to valves with rod-type yokes according to IEC 60534-6

3 Connections

3.1 Electrical connections



DANGER!

Risk of electric shock and/or the formation of an explosive atmosphere!

- For electrical installation, observe the relevant electrotechnical regulations and the accident prevention regulations that apply in the country of use.
- The following regulations apply to mounting and installation in hazardous areas: EN 60079-14: 2008 **Explosive atmospheres – Part 14: Electrical installations design, selection and erection** (or VDE 0165 Part 1).

NOTICE

- Adhere to the terminal assignment! Switching the assignment of the electrical terminals may cause the explosion protection to become ineffective!
- Do not loosen enameled screws in or on the housing.
- The maximum permissible values specified in the national EC type examination certificates apply when interconnecting intrinsically safe electrical equipment (U_i or U_o ; I_i or I_o ; P_i or P_o ; C_i or C_o and L_i or L_o).

Selecting cables and wires:

Observe **Clause 12 of EN 60079-14: 2008** when installing intrinsically safe circuits. The Subclause 12.2.2.7 applies when running

multi-core cables containing more than one intrinsically safe circuit.

In particular, the radial thickness of the conductor insulation for common insulation materials, such as polyethylene, must have a minimum radial thickness of 0.2 mm.

The diameter of an individual wire in a fine-stranded conductor must not be smaller than 0.1 mm. Protect the conductor ends against splicing, e.g. by using wire-end ferrules.

When two separate cables are used for connection, an additional cable gland can be installed.


Seal cable entries left unused with plugs.

Devices used at ambient temperatures **below $-20\text{ }^{\circ}\text{C}$** must be fitted with metal cable glands.

Equipment for use in zone 2/zone 22

In equipment operated with type of protection Ex nA II (non-sparking equipment) according to EN 60097-15: 2003, circuits may be connected, interrupted or switched while energized only during installation, maintenance or repair.

The wiring for the input signal is led using cable glands to the terminals 11 (+) and 12 (–). The ground connection can be connected inside or outside of the positioner housing.



The following accessories are available:

Cable gland M 20 x 1.5

Black Order no. 1400-6985

Blue Order no. 1400-6986

Adapter M 20 x 1.5 to ½ NPT:

Aluminum, powder-coated

Order no. 0310-2149

3.2 Pneumatic connections

The pneumatic connections are designed as tapped holes with ¼ NPT or ISO 2228/1-G ¼ thread. The conventional male connections for metal and copper pipes (or plastic hoses) can be used.

Note:

The supply air must be dry and free of any oil and dust. Always observe the maintenance instructions applicable to the connected pressure reducing stations. Blow out air lines thoroughly before connecting them.

3.2.1 Pressure gauges

We recommend attaching pressure gauges for the supply air and signal pressure in order to monitor the positioner. The parts are listed as accessories in the table on page 20.

3.2.2 Supply pressure

The required supply pressure is determined by the bench range and the operating direction (fail-safe action) of the actuator. The bench range is written on the nameplate as spring range or signal pressure range depending on the type of actuator. **FA** (actuator stem extends) or **FE** (actuator stem retracts) or a symbol indicates the operating direction.

Actuator stem extends (FA)

Fail-safe position Valve CLOSED
(for globe and angle valves)

Required supply pressure =
Upper bench range value + 0.2 bar,
minimum 1.4 bar.

Actuator stem retracts (FE)

Fail-safe position Valve OPEN
(for globe and angle valves)

The required supply pressure for a tight-closing valve is roughly estimated from the maximum signal pressure $p_{st_{max}}$:

$$p_{st_{max}} = F + \frac{d^2 \cdot \pi \cdot \Delta p}{4 \cdot A} \text{ [bar]}$$

d = Seat diameter [cm]

Δp = Differential pressure across valve [bar]

A = Actuator diaphragm area [cm²]

F = Upper bench range of actuator [bar]

In the absence of such specifications, proceed as follows:

Required supply pressure =
Upper bench range value + 1 bar

The positioner output pressure is led to the top or bottom diaphragm case of the actuator as shown in Figs. 7 to 10.

4 Operation

4.1 Combining positioner and actuator

The arrangement of the actuator, input signal, operating direction and mounting location is schematically represented in Figs. 7 to 10.

Each subsequent change such as reversal of the control loop's operating direction or field reversing the actuator version from direct "Actuator stem extends" to reverse "Actuator stem retracts" or vice versa also involves changing the mounting location of the positioner.

4.1.1 Determining/reversing the operating direction

(Figs. 7 to 11)

When the input signal (reference variable w) increases, the signal pressure p_{st} can either be increasing (direct operating direction \llcorner) or decreasing (reverse operating direction \lrcorner). The same applies to a decreasing input signal; the output pressure either decreases (direct operating direction \llcorner) or increases (reverse operating direction \lrcorner). Symbols are located on the flapper (10.2) which

identify the respective operating directions (direct \llcorner or reverse \lrcorner).



Depending on the flapper position, the adjusted operating direction is marked with the corresponding symbol. If the operating direction of the required function does not match the symbol or if the operating direction is to be changed, proceed as follows:

1. Remove both screws of the cover plate, and lift off the nozzle block (10) along with the cover plate.
2. Reinstall the nozzle block turned 180° together with the cover plate, and screw tight.




Make sure that the nozzle block and flapper are correctly located above or below the feeler pin (9.1) as shown in Fig. 11.

If the operating direction is to be changed after the initially determined arrangement of positioner and actuator, note that the positioner must be mounted in a different location and the nozzle block must be turned. Always consider the location of the lever (1) and the plate (20), "lever on top of plate" or reversed "plate on top of lever" as shown in Figs. 7 to 10.

Actuator: Stem extends (FA)



Actuator: Stem retracts (FE)



4.2 Starting point and input signal (reference variable)

The attached lever and the installed range spring of the positioner are assigned to the values of rated valve travel (mm) and the input signal (% reference variable) as in the table below.

In standard operation, the reference variable span is 100 % = 16 mA. A smaller span of, for example, 50 % = 8 mA is only required for split-range operation (Fig. 13). The span can be changed by exchanging the range spring (section 4.4). On making adjustments to the positioner, the travel must be adapted to the input signal and vice versa.




Fig. 12 · Standard operation




Fig. 13 · Split-range operation, two valves operating in opposing directions

Rated travel [mm]	Min./max. travel [mm]	Reference variable (input signal)	Range spring
Standard travels for SAMSON valves with lever I (40 to 127 mm long)			
15	7.5 to 15	100 %	1
		50 %	2
30	14 to 32	100 %	2
		50 %	3
60	30 to 70	100 %	3
Additional travel ranges with lever I and lever extension (40 to 200 mm long)			
20	7.5 to 26	100 %	1
		50 %	2
40	14 to 50	100 %	2
		50 %	3
> 60	30 to 90	100 %	3

With a 4 to 20 mA input signal, for example, the valve must also move through the entire range (0 to 100 %). The starting point then is 4 mA and the upper range value 20 mA.

In split-range operation, the controller output signal used to control two control valves is divided in such a way that these valves move through their entire travel with half of the input signal range (e.g. first valve set to 4 to 12 mA, second valve set to 12 to 20 mA). To prevent the two from overlapping, a dead band of ± 0.5 mA as in Fig. 13 must be taken into account.

The starting point (zero) is adjusted using the zero adjustment screw (4), the reference variable span and, hence, the upper range value using the pin (2).

4.3 Setting the positioner at the valve

- ▶ Connect an ammeter to the control signal input at the terminals 11 (+) and 12 (-).
- ▶ Connect the supply air to the supply input (supply 9).

4.3.1 Setting the air delivery (volume restriction Q) and proportional band XP

1. Close the volume restriction (14) as far as the required speed of response allows.
You can check the speed of response by pressing the range spring (6) as far as it will go.
2. Set the input signal to approximately 50 % of its range. Then, turn the zero adjust-

ment screw (4) until the valve is at approximately 50 % valve travel.

On setting the Xp restriction, observe the relationship with the supply air pressure as indicated in Fig. 14. The preset value of Xp should read approximately 3 %.

3. Check the plug stem's tendency to oscillation by pressing the range spring (6) briefly as far as it will go.
Xp should be set to a value as small as possible, however, without causing noticeable overshoot.

Note:

Always determine the Xp setting prior to adjusting the starting point. Subsequent modification displaces the zero point!

The zero can also be shifted by altering the adjusted supply air pressure.

If necessary, check the zero adjustment under operating conditions of the plant and, re-adjust, if need be.




Fig. 14 · Setting the XP restriction

4.3.2 Setting actuator version "Stem extends"

Note:

To ensure that the total closing force of the actuator can be effective in the control valve, the diaphragm chamber must be completely vented at the lower range value of the reference variable (operating direction <<) and at the upper range value (operating direction <>).

Therefore, set input signal to a slightly increased starting point of 4.5 mA when the operating direction is direct << and to a slightly lowered starting point of 19.5 mA when the operating direction is reverse <>. This applies in particular to controllers and control systems whose output signal is limited to a range of 4 to 20 mA.

Starting point (zero) e.g. 4.5 mA

1. Turn the zero adjustment screw (4) until the plug stem just begins to move from the resting position (observe plug stem with travel indicator).
2. Reduce the input signal on the ammeter and increase again slowly. Check whether the plug stem starts moving at a starting point of 4.5 mA and, if necessary, correct.

Upper range value (span) e.g. 20 mA

3. After the starting point has been adjusted, increase the input signal. The plug stem must be motionless at an upper range value of exactly 20 mA and therefore already moved through 100 % of its travel range (watch the travel indicator at

the valve!). If the upper range value is incorrect, the pin (2) must be moved as follows in order to correct the signal:

4. Move pin to:
End of lever → to increase travel
Pivot → to reduce travel

Whenever you correct the input signal, re-adjust zero afterwards. Subsequently, check the upper range value.

Repeat until the two values match.

4.3.3 Setting actuator version "Stem retracts"

Note:

For actuator version "Actuator stem retracts", the diaphragm chamber must be loaded with a pressure that is capable of tightly closing the control valve, even with prevailing upstream pressure in the plant. This concerns an upper range value of the input signal corresponding to 20 mA (direct operating direction <<) or a lower range value corresponding to 4 mA (reverse operating direction <>).

The required signal pressure is indicated on the adhesive label on the positioner or is roughly estimated as in section 3.2.2.

Starting point (zero) e.g. 20 mA

1. Adjust the input signal to a starting point of 20 mA on the ammeter. Turn the zero adjustment screw (4) until the control valve just begins to move from the initial position.
2. Increase the input signal and slowly reduce to a starting point of 20 mA again.

Check if the valve begins to move at exactly 20 mA.

Correct deviation using the zero adjustment screw (4); turning it counterclockwise moves the control valve earlier from its final position and clockwise later.

Upper range value (span) e.g. 4 mA

3. After adjusting the starting point, adjust the input signal to an upper range value of 4 mA using the ammeter. With an upper range value of exactly 4 mA, the plug stem must be motionless and therefore already moved through 100 % of its travel range (watch the travel indicator at the valve!).
4. If the upper range value is incorrect, the pin (2) must be moved to correct the signal.

Adjust 20 mA and turn the zero adjustment screw (4) until the required signal pressure is indicated on the pressure gauge.

By way of substitution for a pressure gauge, set 19.5 mA as the starting point.

4.4 Exchanging the range spring

If the range is to be altered or changed to split-range operation, replace the range spring as shown in Fig. as follows:

1. Remove screw (7) on the range spring. Pull out hexagon socket screw (5) and the lever together with shaft.
2. Exchange range spring. Slide lever with shaft through sleeve (3), positioner housing and bracket (6.1).
3. Secure range spring with the screw (7).
4. Move bracket and shaft until the screw (5) sits on the flattened part of the shaft. Tighten screw (5). Allow for a play from 0.05 to 0.15 mm between the lever (1) and the sleeve (3) as well as between the range spring (6) and the positioner housing.

5 Converting an electropneumatic into a pneumatic positioner

The appropriate conversion kit allows the electropneumatic positioner to be converted into a Type 4765 Pneumatic Positioner.

Note: *EB 8359-1 EN then applies for the converted Type 4765 Pneumatic Positioner.*

Required conversion kit for model index **.02.** or lower

for G threaded connection

Order number 1400-6724

for NPT threaded connection

Order number 1400-6725

Required conversion kit for model index **.03.** or higher


for G threaded connection

Order number 1400-6795

for NPT threaded connection

Order number 1400-6796

1. Undo mounting screws and lift the i/p converter unit together with the printed circuit board out of the positioner housing.
2. Remove screw gland (1). Plug on hose (5) and screw the connecting nipple (4) of the conversion kit tightly on the housing.
3. Insert sealing element (7) into connecting plate (6) and screw tight in the housing.



4. Push the free end of the hose onto the connecting plate (6).

6 Servicing explosion-protected devices

If a part of the device on which the explosion protection is based needs to be serviced, the device must not be put back into operation until a qualified inspector has assessed it according to explosion protection requirements, has issued an inspection certificate or given the device a mark of conformity.

Inspection by a qualified inspector is not required if the manufacturer performs a routine test on the device prior to putting it back into operation. The passing of the routine test must be documented by attaching a mark of conformity to the device. Replace explosion-protected components only by original, routine-tested components from the manufacturer.

Devices that have already been operated outside hazardous areas and are intended for future use inside hazardous areas must comply with the safety requirements placed on serviced devices. Before being used inside hazardous areas, test the devices according to the specifications for servicing explosion-protected devices.

7 Maintenance, calibration and work on equipment


The interconnection with intrinsically safe circuits to check or calibrate the apparatus must only be performed with intrinsically safe current/voltage calibrators and measuring instruments to rule out any damage to components relevant for explosion protection.

The maximum values for intrinsically safe circuits specified in the approvals must be kept.

8 Accessories and mounting parts

Accessories – Mounting parts	Order number
Range spring 1	1190-0736
Range spring 2	1190-0737
Range spring 3	1190-0738
Lever I	1690-6469
Lever extension	1400-6716
Pressure gauge attachment	1400-6950
Pressure gauge attachment, free of copper	1400-6951
Mounting kit for valves with cast yoke acc. to NAMUR	1400-5745
Mounting kit for valves with rod-type yokes acc. to NAMUR for 18 to 35 mm rod diameters	1400-5745 and 1400-5342
Spare parts assortment with seals and diaphragms	1400-6792
Spare parts assortment with seals, diaphragms and pneumatic components (for model index .02 or higher)	1042-0040
Conversion kit to upgrade to degree of protection IP 65 (refer to SAMSOMATIC print Z 900-7 for more details)	1790-7408

9 Dimensions in mm



Physikalisch-Technische Bundesanstalt
Braunschweig und Berlin



Physikalisch-Technische Bundesanstalt
Braunschweig und Berlin



TRANSLATION

EC TYPE EXAMINATION CERTIFICATION

(1) Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres – Directive 94/9/EC

(2) EC Type Examination Certificate Number

PTB 02 ATEX 2078

(3) Equipment: Model 4763-1.../P Positioner
(4) Manufacturer: SAMSON AG, Mess- und Regeltechnik
(5) Address: Weismillstr. 3, D-60314 Frankfurt, Germany

(6) This equipment and any acceptable variations thereof are specified in the schedule to this certificate.

(7) The Physikalisch-Technische Bundesanstalt, notified body number 0102 in accordance with Article 9 of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment intended for use in potentially explosive atmospheres as specified in Annex II to the Directive.

The examination and test results are recorded in confidential report

PTB-Ex 02-22054.

(8) The Essential Health and Safety Requirements are satisfied by compliance with

EN 50014: 1997+A1+A2 EN 50020: 1994

(9) If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special conditions for safe use specified in the schedule to this certificate.

(10) According to the Directive 94/9/EC, this EC TYPE EXAMINATION CERTIFICATE relates only to the design and construction of the specified equipment. If applicable, further requirements of this Directive apply to the manufacture and supply of the equipment.

(11) The marking of the equipment shall include the following:



Zertifizierungsstelle Explosionsschutz Braunschweig, 19. July 2002
By order

(Signature)

(Seal)

Dr.-Ing. U. Johannsmeyer
Regierungsdirigtor

EC Type Examination Certificate without signature and seal are invalid.
This EC Type Examination Certificate may only be reproduced in its entirety and without any changes, schedule included.
Errors or changes shall require the prior approval of the Physikalisch-Technische Bundesanstalt.

Physikalisch-Technische Bundesanstalt, Bundesallee 100, D-38116 Braunschweig

Plb 95-4763.doc

EC Type Examination Certificate without signature and seal are invalid.
This EC Type Examination Certificate may only be reproduced in its entirety and without any changes, schedule included.
Errors or changes shall require the prior approval of the Physikalisch-Technische Bundesanstalt.

Physikalisch-Technische Bundesanstalt, Bundesallee 100, D-38116 Braunschweig

Plb 95-4763.doc

Physikalisch-Technische Bundesanstalt
Braunschweig und Berlin

Electrical data

Signal circuit (terminals 11/12)
Type of protection: intrinsic safety EEx ia IIC only for connection to a certified intrinsically safe circuit

Maximum values:

- U_i = 28 V
- I_i = 110 mA or 85 mA
- P_i = 0.7 W
- U_o = 25 V
- I_o = 120 mA
- P_o = 0.7 W
- C_i = negligible
- L_i = negligible

(16) **Test Report PTB Ex. 02-22054**

(17) **Special conditions for safe use**

None

(18) **Essential Health and Safety Requirements**

In compliance with the standards specified above.

Braunschweig, 19. July 2002

Zertifizierungsstelle Explosionsschutz

By order

(Signature) (seal)

Dr. Ing. U. Jahnsmeyer
Regierungsdirektor

EC Type Examination Certificates without signature and seal are invalid.
This EC Type Examination Certificate requires the prior approval of the Physikalisch-Technische Bundesanstalt.
Errors or changes shall require the prior approval of the Physikalisch-Technische Bundesanstalt.

Physikalisch-Technische Bundesanstalt
Braunschweig und Berlin

Schedule

(14) **EC TYPE EXAMINATION CERTIFICATE No. PTB 02 ATEX 2078**

Description of Equipment

The Model 4763-1... I/P Positioner is intended for attachment to pneumatic control valves. It serves for converting control signals of 0...1...20 mA or 1...5 mA from a controlling system into a pneumatic actuating pressure of 6 bar max. For auxiliary power non-combustible media are used.

The I/P converter circuit is a passive two terminal network which may be connected to any certified intrinsically safe circuit, provided the permissible maximum values of U_i, I_i and P_i are not exceeded.

The device is intended for use inside and outside of hazardous locations.

The correlation between version, temperature classification, permissible ambient temperature ranges and maximum short-circuit currents is shown in the table below.

Version 4763-1...1, with Model 6109 I/P Module

Temperature class	Permissible ambient temperature range	Maximum short-circuit current
T6	-45 °C ... 60 °C	85 mA
T5	-45 °C ... 70 °C	
T4	-45 °C ... 80 °C	100 mA
T5	-45 °C ... 70 °C	
T4	-45 °C ... 80 °C	

Version 4763-1...2, with Model 6112 I/P Module

Temperature class	Permissible ambient temperature range	Maximum short-circuit current
T6	-45 °C ... 60 °C	85 mA or
T5	-45 °C ... 70 °C	100 mA
T4	-45 °C ... 80 °C	120 mA

EC Type Examination Certificates without signature and seal are invalid.
This EC Type Examination Certificate requires the prior approval of the Physikalisch-Technische Bundesanstalt.
Errors or changes shall require the prior approval of the Physikalisch-Technische Bundesanstalt.

TRANSLATION

- (1) **Statement of Conformity**
- (2) **Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres – Directive 94/9/EC**
- (3) **EC Type Examination Certificate Number**
- (4) **Equipment:** Model 4763-8 1/P Positioner
- (5) **Manufacturer:** Samson AG
- (6) **Address:** Weismüllerstr. 3, D-60314 Frankfurt, Germany
- (7) This equipment and any acceptable variation thereof are specified in the schedule to this certificate and the documents referred to therein.
- (8) The Physikalisch-Technische Bundesanstalt, notified body number 0102, in accordance to Article 9 of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres given in Annex II to the Directive.
- The examination and test results are recorded in confidential report
- PTB Ex. 03-23304**
- (9) The Essential Health and Safety Requirements are satisfied by compliance with
- EN 50021: 1999**
- (10) If the sign "XX" is placed after the certificate number, it indicates that the equipment is subject to special conditions for safe use specified in the schedule to this certificate.
- (11) In compliance with the Directive 94/9/EC this Statement of Conformity relates only to the design and construction of the equipment specified. Further requirements of this Directive apply to manufacture and marketing of this equipment.

1/4

EC Type Examination Certificates without signature and seal are invalid.
 This EC Type Examination Certificate may only be reproduced in its entirety and without any changes, schedule included.
 Changes or changes that require the prior approval of the Physikalisch-Technische Bundesanstalt.

Physikalisch-Technische Bundesanstalt, Bundesallee 100, D-38116 Braunschweig P120 Ex.n.doc

- (12) The marking of the equipment shall include the following:



Zertifizierungsstelle Explosionsschutz Braunschweig, 30. September 2003
 By order

(Signature) (Seal)

Dr.-Ing. U. Johannsmeyer
 Regierungsdirektor

2/4

EC Type Examination Certificates without signature and seal are invalid.
 This EC Type Examination Certificate may only be reproduced in its entirety and without any changes, schedule included.
 Changes or changes that require the prior approval of the Physikalisch-Technische Bundesanstalt.

Physikalisch-Technische Bundesanstalt, Bundesallee 100, D-38116 Braunschweig P120 Ex.n.doc

- (13) **Schedule**
(14) **Statement of Conformity PTB 01 ATEX 2170 X**
(15) **Description of Equipment**

The Model 4763-8... IP Positioner is intended for attachment to pneumatic control valves. It serves for converting control signals of 0/4...20mA or 1...5mA from a controlling system into a pneumatic actuating pressure of 0bar max.

For pneumatic auxiliary power non-combustible media are used.

The device is intended for use inside and outside of hazardous areas...

The correlation between temperature classification and permissible ambient temperature ranges is shown in the table below:

Temperature class	Permissible ambient temperature range
T6	-45°C ... 60°C
T5	-45°C ... 70°C
T4	-45°C ... 80°C

Electrical data

Signal circuit
(terminals 11/12)

Type of protection: Ex nA II

- (16) Test report: **PTB Ex 03-23304**

- (17) **Special conditions for safe use**

The signal circuit (terminals 11/12) shall be preceded with by a fuse installed outside of the hazardous area.
This fuse shall comply with IEC 60127-2/II, 250V F, or with IEC 60127-2/VI, 250V T, with a fuse nominal current I_n of ≤ 30mA max.

The positioner shall be mounted in an enclosure providing at least Degree of Protection IP 54 in compliance with the IEC Publication 60529.
This requirement applies also to the cable entries and/or plug connectors.

The wiring shall be connected in such a manner that the connection facilities are not subjected to pull and twisting.

3/4

EC Type Examination Certificates without signature and seal are invalid.
This EC Type Examination Certificate may only be reproduced in its entirety and without any changes, schedules included.
Extracts or changes shall require the prior approval of the Physikalisch-Technische Bundesanstalt.
Physikalisch-Technische Bundesanstalt, Bundesallee 100, D-38116 Braunschweig PTB23 Ex n06c

Schedule of the Statement of Conformity

- (18) **Basic health and safety requirements**

Are satisfied by compliance with the standard specified above.

Zertifizierungsstelle Explosionsschutz

Braunschweig,

By order

(Signature)

(seal)

Dr. Ing. U. Johannsmeyer

4/4

EC Type Examination Certificates without signature and seal are invalid.
This EC Type Examination Certificate may only be reproduced in its entirety and without any changes, schedules included.
Extracts or changes shall require the prior approval of the Physikalisch-Technische Bundesanstalt.
Physikalisch-Technische Bundesanstalt, Bundesallee 100, D-38116 Braunschweig PTB23 Ex n06c

Addendum Page 1

Installation Manual for apparatus certified by CSA for use in hazardous locations.

Electrical rating of intrinsically safe apparatus and apparatus for installation in hazardous locations.

Table 1: Maximum values

Signal circuit	U_i or V_{max}	I_i or I_{max}	P_i or P_{max}	C_i	L_i
Signal circuit	28V	115mA	0.7W	0µF	0µH

U_i or $V_{oc} \leq U_i$ or V_{max} / I_i or $I_{sc} \leq I_i$ or I_{max} / P_i or P_{max} ; $C_i \geq C_i$ and $L_i \geq L_i$

Table 2: CSA - certified barrier parameters of solenoid valve circuit

Barrier	Supply barrier		Evaluation barrier	
	V_{max}	R_{min}	V_{max}	Diode Return
Signal circuit	$\leq 28V$	$\geq 200\Omega$	28V	Diode Return

Table 3: The correlation between temperature classification and permissible ambient temperature ranges is shown in the table below.

Temperature class	Permissible ambient temperature range
T6	60°C
T5	-45°C ... 70°C
T4	80°C

Intrinsically safe if installed as specified in manufacturer's installation manual.

CSA - certified for hazardous locations

Ex: II, IIC T6; class I, Zone 0

Ex: I, Group A, B, C, D

Class II; Groups E, F + G; Class III


Notes

- 1.) The apparatus may be installed in intrinsically safe circuit only when used in conjunction with the CSA certified apparatus. For maximum values of U_i or V_{max} , I_i or I_{max} , P_i or P_{max} ; C_i and L_i of the various apparatus see Table 1.
- 2.) The apparatus may be installed in intrinsically safe circuit only when used in conjunction with the CSA certified intrinsically safe barrier.
For barrier selection see Table 2.
- 3.) Installation shall be in accordance with the Canadian Electrical Code Part 1.
- 4.) Use only supply wires suitable for 5°C above surrounding temperature.

Revisions Control Number: 1 May 05

Addendum to EB 8359-2 EN

Addendum Page 2



Version: Model 4763-3 I/P Positioner.

Supply and evaluation barrier CSA certified.

For the permissible maximum values for the intrinsically safe circuit see Table 1

For the permissible barrier parameters for the circuit see Table 2


Cable entry M 20 x 1.5 or metal conduit according to drawing No. 1050 - 0539 T or 1050 - 0540 T

CSA - certified for hazardous locations

Class I; Div. 2, Groups A, B, C, D

Class II; Div. 2, Groups E, F + G; Class III

Type 3 Enclosure



Notes:

- 1.) For the maximum values for the circuit see Table 1 and 2.

- 2.) Cable entry only rigid metal conduit according to drawing No. 1050-0539 T and 1050-0540 T

Revisions Control Number: 1 May 05

Addendum to EB 8359-2 EN

Installation Manual for apparatus approved by FM for use in hazardous locations.

Electrical rating of intrinsically safe apparatus and apparatus for installation in hazardous locations.

Table 1: Maximum values

Signal circuit	U or V _{max}	I or I _{max}	P or P _{max}	C _i	L _i
	28V	115mA	0.7W	0nF	0 μH

Notes: U or V or V_i ≤ U or V_{max} / I or I_i or I_i ≤ I or I_{max}

P or P_{max} ≤ P or P_{max}

Table 2: FM - approved barrier parameters of solenoid valve circuit

Barrier	Supply barrier			Evaluation barrier		
	V _{oc}	R _{in}	I _{ic}	V _{oc}	R _{in}	I _{ic}
Signal circuit	≤ 28V	≥ 280Ω	≤ 115mA	28V	#	0mA

Table 3: The correlation between temperature classification and permissible ambient temperature ranges is shown in the table below.

Temperature class	Permissible ambient temperature range
T6	80°C
T5	-46°C ≤ t _a ≤ 70°C
T4	80°C

Intrinsically safe if installed as specified in manufacturer's installation manual.

FM-approved for hazardous locations

Class I, Zone 0, A, Ex, ia, IIC T5,

Class I, II, III, Division 1, Groups A, B, C, D, E, F + G


NEMA 3R

Notes:

- 1.) The apparatus may be installed in intrinsically safe circuit only when used in conjunction with the FM approved apparatus. For maximum values of U or V_{max}; I or I_{max}; P or P_{max}; C_i and L_i of the various apparatus see Table 1.
- 2.) The apparatus may be installed in intrinsically safe circuit only when used in conjunction with the FM approved intrinsically safe barrier.
- 3.) Installation shall be in accordance with the National Electrical Code ANSI/NFPA 70 and ANSI/ISA RP 12.0.6.01
- 4.) Use only supply wires suitable for 5°C above surrounding temperature.

Revisions Control Number: 1 August 04

Addendum to EB 8359-2 EN



Version: Model 4763-3 (VP Positioner).


Supply and evaluation barrier FM/CSA-approved.

For the permissible maximum values for the intrinsically safe circuit see Table 1 For the permissible barrier parameters for the circuit see Table 2

Cable entry M 20 x 1.5 or metal conduit according to drawing No. 1050 - 0539 T or 1050 - 1040 T

FM - approved for hazardous locations
Class I, Division 2, Groups A, B, C, D
Class II Division 2, Groups F + G, Class III

NEMA 3R



Notes:

- 1.) For the maximum values for the circuit see Table 1 and 2.
- 2.) Cable entry only/rigid metal conduit according to drawing No. 1050/0539 T and 1050/0540 T
- 3.) The installation shall be in accordance with the National Electrical Code ANSI/NFPA 70

Revisions Control Number: 1 August 04

Addendum to EB 8359-2 EN



SAMSON AG · MESS- UND REGELTECHNIK
Weismüllerstraße 3 · 60314 Frankfurt am Main · Germany
Phone +49 69 4009-0 · Fax +49 69 4009-1507
Internet: <http://www.samson.de>

EB 8359-2 EN

S/Z/2012-10