## Technical Information Cerabar M PMC51, PMP51, PMP55

### Process pressure measurement

# Pressure transmitter with ceramic and metal sensors

#### Application

The device is used for the following measuring tasks:

- Absolute pressure and gauge pressure measurement in gases, steams or liquids in all areas of process engineering and process measurement technology
- Level, volume or mass measurement in liquids
- High process temperature
  - without diaphragm seals up to 130 °C (266 °F), for a maximum of 60 minutes 150 °C (302 °F)
  - with diaphragm seals up to 400  $^\circ \!\! C$  (752  $^\circ \!\! F)$
- High pressure up to 400 bar (6000 psi)
- International usage thanks to a wide range of approvals

#### Your benefits

- Very good reproducibility and long-term stability
- High reference accuracy up to ±0.15 % as PLATINUM version: ±0.075 %
- Turn down up to 100:1
- Uniform platform for differential pressure, hydrostatics and pressure (Deltabar M
   – Deltapilot M Cerabar M)
- Simple, fast commissioning through a user interface designed for real-world applications
- Used for process pressure monitoring up to SIL2, certified to IEC 61508 Edition 2.0 and IEC 61511 by TÜV NORD
- The patented TempC membrane for the diaphragm seal reduces measured errors caused by environmental and process temperature influences to a minimum
- ASME-BPE-compliant device versions









## Table of contents

Document function	<b>5</b> 5 5 6
Terms and abbreviations	7 8
Device selection	<b>9</b> 1 2
pressure sensors	.2 .3
Measured variable	<b>4</b> 4
Signal range 4 to 20 mA1Signal on alarm1Load - 4 to 20 mA Analog 420 mA HART1Resolution1Dead time, Time constant1Dynamic behavior current output (analog electronics)1Dynamic behavior current output (HART electronics)1Dynamic behavior digital output (HART electronics)1Dynamic behavior FOUNDATION Fieldbus1Dynamic version1	.6 .6 .6 .6 .7 .7 .7 .7 .7 .7 .7 .8 .8 .8 .9 .9
Supply voltage2Current consumption2Electrical connection2Terminals2Cable entry2Device plug connectors2Cable specification2Start-up current2Residual ripple2Influence of power supply2	2 3 3

#### of the ceran rocess isolating dianhragm

process isolating diaphragm	27
Reference operating conditions	27
Influence of orientation	27
Uncertainty of measurement for small absolute pressure	
ranges	27

Reference accuracy – PMC51	28
PMC51	28
Total performance – PMC51	29
Long-term stability	29
Total Error - PMC51	30
Warm-up period	30
	50
Performance characteristics of the metallic	
	21
process isolating diaphragm	31
Reference operating conditions	21
Uncertainty of measurement for small absolute pressure	<b>D</b> 1
ranges	31 31
Performance Characteristics Conformance	
Influence of orientation	31
Reference accuracy – PMP51 , PMP55	32
Thermal change in the zero output and the output span –	~ ~
PMP51 and PMP55	33
Total Performance – PMP51	34
Long-term stability	34
Total Error - PMP51	35
Warm-up period	35
<b>T</b> ( <b>11</b> ( <b>1</b>	24
Installation	
General installation instructions	36
Managering arrangement for devices without diaphrage	

Environment	40
Applications with hydrogen	39
Ultrapure gas applications (PMC51 und PMP51)	39
PWIS cleaning	
	39
Oxygen applications	39
"Separate housing" version	38
Wall and pipe-mounting manifold (optional)	37
Wall and pipe mounting, transmitter (optional)	37
РМР55	36
Measuring arrangement for devices with diaphragm seal –	
seal – PMC51, PMP51	36
Measuring arrangement for devices without diaphragm	
	50

Ambient temperature range	40
Storage temperature range	40
Climate class	40
Degree of protection	40
Vibration resistance	40
Electromagnetic compatibility	41

Process . Process temperature range PMC51 . Process temperature limits . Process temperature limits of flexible capillary armoring: PMP55 . Pressure specifications .	42 42 44
Mechanical constructionDevice heightF31 housing, aluminumF15 housing, stainless steel (hygienic)	<b>45</b> 45 45 46

PMC51: process connections with internal process	
isolating diaphragm	
isolating diaphragm	
PMC51: process connections with internal process	
isolating diaphragm - height H	
PMC51: process connections with flush-mounted process	
isolating diaphragm	
isolating diaphragm	
PMC51: process connections with flush-mounted process	
isolating diaphragm - height H	
PMC51: process connections with flush-mounted process	
isolating diaphragm	
isolating diaphragm - height H	
PMC51: hygienic process connections with flushmounted	
process isolating diaphragm 55	
PMP51: process connections with internal process	
isolating diaphragm	
PMP51: process connections with internal process isolating diaphragm 61	
PMP51: process connections with flush-mounted process	
isolating diaphragm	
ANSI threaded connection	
PMP51: process connections with flush-mounted process	
isolating diaphragm	
isolating diaphragm	
PMP51: hygienic process connections with flushmounted	
process isolating diaphragm	
Valve manifold DA63M- (optional) 71	
PMP51: process connections	
PMP55 basic device - examples	
isolating diaphragm	
PMP55: process connections with flush-mounted process	
isolating diaphragm	
PMP55: process connections with flush-mounted process	
isolating diaphragm	
isolating diaphragm	
PMP55: hygienic process connections with flushmounted	
process isolating diaphragm	
PMP55: hygienic process connections with flushmounted process isolating diaphragm	
process isolating diaphragm	
isolating diaphragm	
PMP55: process connections with flush-mounted process	
isolating diaphragm	
PMP55 process connections	
Wall and pipe mounting with "Separate housing" version 93Reduction in installation height	
Weight	
Materials not in contact with process	
Materials in contact with the process	
Seals	
Fill fluid	
Operability 101	
Operability         101           Operating concept         101	
Local operation	
Operating languages	
Remote operation 105	

System integration (Except analog electronics) ..... 106 Planning instructions for diaphragm seal Diaphragm seal filling oils ..... 109 Operating temperature range ..... 109 Installation instructions ..... 110 Vacuum applications ..... 111 113 RoHS ..... 113 RCM-Tick marking ..... 113 EAC conformity ..... 113 Certificate of Compliance ASME BPE 2012 ..... 114 114 Other standards and guidelines ..... 114 Pressure Equipment Directive 2014/68/EU (PED) . . . . 114 Drinking water approval ..... 116 Classification of process sealing between electrical systems and (flammable or combustible) process fluids in Inspection certificate ..... 116 Ordering information ..... 118 Measuring point (TAG) ..... 118 Configuration data sheet (HART, PROFIBUS PA, FOUNDATION Fieldbus electronics) ..... 118 Configuration data sheet (Analog electronics) . . . . . . . 121 Field of Activities ..... 122 Technical Information ..... 122 Brief operating instruction ..... 122 125 125 Welding necks and Weld-in tool flanges ..... 125 Mounting bracket for wall and pipe mounting ..... 126 126 126 126  $FOUNDATION^{TM} Field bus \dots 126$ 

Symbols used

## **Document information**

Document function	The document contains all the technical data on the device and provides an overview of the
	accessories and other products that can be ordered for the device.

Symbol	Meaning
<b>A</b> DANGER	<b>DANGER!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in seriousor fatal injury.
	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in seriousor fatal injury.
<b>A</b> CAUTION	<b>CAUTION!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minoror medium injury.
NOTICE	<b>NOTICE!</b> This symbol contains information on procedures and other facts which do not result in personalinjury.

#### Electrical symbols

Safety symbols

Symbol	Meaning	Symbol	Meaning
Ð	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.	4	<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

#### Symbols for certain types of information

Symbol	Meaning
$\checkmark$	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Preferred</b> Procedures, processes or actions that are preferred.
X	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
i	<b>Tip</b> Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Visual inspection

#### Symbols in graphics

Symbol	Meaning
1, 2, 3	Item numbers
1. , 2. , 3	Series of steps

Symbol	Meaning
A, B, C,	Views
A-A, B-B, C-C,	Sections

Documentation

See chapter "Additional documentation"  $\rightarrow$  🖺 122

The document types listed are available: In the Download Area of the Endress+Hauser Internet site: www.endress.com  $\rightarrow$  Download





Item	Term/abbreviation	Explanation
1	OPL	The OPL (over pressure limit = sensor overload limit) for the measuring device depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the measuring cell. Also observe pressure-temperature dependency. For the relevant standards and additional notes see the $\rightarrow \cong 44$ section. The OPL may only be applied for a limited period of time.
2	MWP	The MWP (maximum working pressure) for the sensors depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the measuring cell. Also observe pressure-temperature dependency. For the relevant standards and additional notes see the $\rightarrow \cong 44$ section. The MWP may be applied at the device for an unlimited period. The MWP can also be found on the nameplate.
3	Maximum sensor measuring range	Span between LRL and URL This sensor measuring range is equivalent to the maximum calibratable/adjustable span.
4	Calibrated/adjusted span	Span between LRV and URV Factory setting: 0 to URL Other calibrated spans can be ordered as customized spans.
р	-	Pressure
-	LRL	Lower range limit
-	URL	Upper range limit
-	LRV	Lower range value
-	URV	Upper range value
-	TD (Turn down)	Turn down Example - see the following section.

#### Turn down calculation



**Device selection** 

### Function and system design



#### Field of application

- Gauge pressure and absolute pressure
- Level

#### **Process connections**

PMC51:

- Thread
- EN flanges DN 25 DN 80
- ANSI flanges 1" 4"
- JIS flanges 50 A 100 A
- Flush-mounted hygienic connections

PMP51:

- Thread
- EN flanges DN 25 DN 80
- ANSI flanges 1" 4"
- Prepared for diaphragm seal mount
- Flush-mounted hygienic connections

PMP55:

Wide range of diaphragm seals

#### Measuring ranges

- PMC51: From -100/0 to 100 mbar (-1.5/0 to 1.5 psi) to -1/0 to 40 bar (-15/0 to 600 psi)
- PMP51: From -400/0 to 400 mbar (-6/0 to 6 psi) to -1/0 to 400 bar (-15/0 to 6000 psi)
- PMP55: From -400/0 to 400 mbar (-6/0 to 6 psi) to -1/0 to 400 bar (-15/0 to 6000 psi)

#### OPL

- PMC51: max. 60 bar (900 psi)
- PMP51: max. 600 bar (9000 psi)
- PMP55: max. 600 bar (9000 psi)

#### Process temperature range

- PMC51: -20 to +130 °C (-4 to +266 °F)
   For a maximum of 60 minutes: +150 °C (+302 °F)
- PMP51: -40 to +130 °C (-40 to +266 °F)
   For a maximum of 60 minutes: +150 °C (+302 °F)
- PMP55: -70 to +400 °C (-94 to +752 °F) (depending on the filling oil)

#### Ambient temperature range

- Without LCD: -40 to +85 °C (-40 to +185 °F)
- With LCD display: -20 to +70 °C (-4 to +158 °F) (extended temperature application range-40 to +85 °C (-40 to +185 °F) with limitations in optical properties, such as display speed and contrast)
- Separate housing:-20 to +60 °C (-4 to +140 °F)
- PMP55: Diaphragm seal systems depending on the version

#### **Reference** accuracy

- PMC51: Up to ±0.15% of the set span PLATINUM-Version: up to ±0.075% of the set span
- PMP51: Up to ±0.15% of the set span
- PLATINUM-Version: up to  $\pm 0.075\%$  of the set span
- PMP55: Up to ±0.15% of the set span

#### Supply voltage

- 11.5 to 45 V DC (versions with plug-in connection 35 V DC)
- For intrinsically safe device versions: 11.5 to 30 V DC

#### Output

4 to 20 mA, 4 to 20 mA with superimposed HART protocol, PROFIBUS PA or FOUNDATION Fieldbus

#### Options

- Inspection certificate 2.2 or 3.1 or other certificates
- 3Aapproval and EHEDG approval
- Specific firmware versions
- Initial device settings
- Separate housing
- Broad range of accessories
- NACE-compliant materials

#### Specialties

- PMC51:
  - Metal-free measurement with PVDF connection
- Special cleaning of the transmitter to remove paint-wetting substances, for use in paint shops
- PMP51:
  - Process connections with minimum oil volume
  - Gas-tight, elastomer-free
- PMP55:
  - Wide range of diaphragm seals
  - For extreme medium temperatures
  - Process connections with minimum oil volume
  - Completely welded versions

#### Measuring principle

Ceramic process isolating diaphragm used in PMC51 (Ceraphire®)



- 1 Air pressure (gauge pressure sensors)
- 2 Ceramic substrate
- 3 Electrodes
- 4 Ceramic process isolating diaphragm

The ceramic sensor is a dry sensor, i.e. the process pressure acts directly on the robust ceramic process isolating diaphragm and deflects it. A pressure-dependent change in capacitance is measured at the electrodes of the ceramic substrate and the process isolating diaphragm. The measuring range is determined by the thickness of the ceramic process isolating diaphragm.

#### Advantages:

- Guaranteed overload resistance up to 40 times the nominal pressure
- Thanks to ultrapure 99.9% ceramic (Ceraphire<sup>®</sup>, see also "www.endress.com/ceraphire")
   extremely high chemical stability, comparable with Alloy C
- high mechanical stability
- Can be used in absolute vacuum

#### Metallic process isolating diaphragm used in PMP51 and PMP55



- *1* Silicon measuring element, substrate
- 2 Wheatstone bridge
- 3 Channel with fill fluid
- 4 Metallic process isolating diaphragm

#### PMP51

The operating pressure deflects the process isolating diaphragm and a fill fluid transfers the pressure to a resistance bridge (semiconductor technology). The pressure-dependent change in the bridge output voltage is measured and evaluated.

#### Advantages:

- Can be used for process pressure up to 400 bar (6000 psi)
- High long-term stability
- Guaranteed overload resistance up to 4 times the nominal pressure
- Significantly less thermal effect compared to diaphragm seal systems

#### PMP55

The operating pressure acts on the process isolating diaphragm of the diaphragm seal and is transferred to the process isolating diaphragm of the sensor by a diaphragm seal fill fluid. The process isolating diaphragm is deflected and a fill fluid transfers the pressure to a resistance bridge. The pressure-dependent change in the bridge output voltage is measured and evaluated.

#### Advantages:

- Depending on the version, can be used for process pressure up to 400 bar (6000 psi) and simultaneous extreme process temperatures
- High long-term stability
- Guaranteed overload resistance up to 4 times the nominal pressure

## Level measurement (level, volume and mass)



- h Height (level)
- p Pressure
- $\rho$  Density of the medium
- g Gravitation constant

#### Your benefits

- Choice of different level measuring modes in the device software
- Volume and mass measurements in any tank shapes by means of a freely programmable characteristic curve
- Choice of diverse level units
- Has a wide range of uses, even in the following cases:
  - in the event of foam formation
  - in tanks with agitators of screen fittings
  - in the event of liquid gases

## Electrical differential pressure measurement with gauge pressure sensors



- 1 Shut-off valves
- 2 e.g. filter

In the example given, two Cerabar M devices (each with a gauge pressure sensor) are interconnected. The pressure difference can thus be measured using two independent Cerabar M devices.

#### **WARNING**

#### Risk of explosion!

 If using intrinsically safe devices, strict compliance with the rules for interconnecting intrinsically safe circuits as stipulated in IEC60079-14 (proof of intrinsic safety) is mandatory.

Communication protocol	<ul> <li>4 to 20 mA without communication protocol (analog electronics)</li> <li>6 to 20 mA with UADT communication protocol</li> </ul>
	4 to 20 mA with HART communication protocol
	<ul> <li>PROFIBUS PA</li> </ul>
	<ul> <li>The Endress+Hauser devices meet the requirements of the FISCO model.</li> </ul>
	- Due to a low current consumption of 11 mA $\pm$ 1 mA, the following number of devices can be operated on one bus segment if installing as per FISCO: up to 8 devices for Ex ia, CSA IS and FM
	IS applications or up to 31 devices for all other applications e.g. in non-hazardous areas, Ex nA etc. Further information on PROFIBUS PA can be found in Operating Instructions BA00034S "PROFIBUS DP/PA: Guidelines for planning and commissioning" and in the PNO Guideline.
	FOUNDATION Fieldbus
	<ul> <li>The Endress+Hauser devices meet the requirements of the FISCO model.</li> </ul>
	<ul> <li>Due to a low current consumption of 16 mA ± 1 mA, the following number of devices can be operated on one bus segment if installing as per FISCO: up to 6 devices for Ex ia, CSA IS and FM IS applications or up to 22 devices for all other applications e.g. in non-hazardous areas, Ex nA etc. Further information on FOUNDATION Fieldbus, such as requirements for bus system components, can be found in Operating Instructions BA00013S "FOUNDATION Fieldbus Overview".</li> </ul>

## Input

#### Measured variable

#### Measured process variables

- Analog electronics: Absolute pressure and gauge pressure
- HART, PROFIBUS PA, FOUNDATION Fieldbus: Absolute pressure and gauge pressure, from which level (level, volume or mass) is derived

#### Measuring range

#### PMC51 – with ceramic process isolating diaphragm (Ceraphire®) for gauge pressure

Sensor	Maximum sensor	measuring range	Smallest calibratable	MWP	OPL	Vacuum	Option <sup>2)</sup>
	lower (LRL) upper (URL)		measuring span (preset at the factory) <sup>1)</sup>			resistance	
	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	
100 mbar (1.5 psi)	-0.1 (-1.5)	+0.1 (+1.5)	0.01 (0.15)	2.7 (40.5)	4 (60)	0.7 (10.5)	1C
250 mbar (3.75 psi)	-0.25 (-3.75)	+0.25 (+3.75)	0.01 (0.15)	3.3 (49.5)	5 (75)	0.5 (7.5)	1E
400 mbar (6 psi)	-0.4 (-6)	+0.4 (+6)	0.02 (0.3)	5.3 (79.5)	8 (120)	0	1F
1 bar (15 psi)	-1 (-15)	+1 (+15)	0.05 (1)	6.7 (100.5)	10 (150)	0	1H
2 bar (30 psi)	-1 (-15)	+2 (+30)	0.1 (1.5)	12 (180)	18 (270)	0	1K
4 bar (60 psi)	-1 (-15)	+4 (+60)	0.2 (3)	16.7 (250.5)	25 (375)	0	1M
10 bar (150 psi)	-1 (-15)	+10 (+150)	0.5 (7.5)	26.7 (400.5)	40 (600)	0	1P
40 bar (600 psi)	-1 (-15)	+40 (+600)	2 (30)	40 (600)	60 (900)	0	1S

1) Factory calibration turn down: Max 20:1, higher on request or configurable in the device.

2) Product Configurator, "Sensor range" ordering feature

	PMC51 – with ceramic	process isolating di	aphragm (Ceraphire	<sup>®</sup> ) for absolute pressure
--	----------------------	----------------------	--------------------	--------------------------------------

Sensor	Maximum sens range	or measuring	Smallest calibratable measuring span (preset	MWP	OPL	Vacuum resistance	Option <sup>2)</sup>
	lower (LRL) upper (URL)		at the factory) <sup>1)</sup>				
	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar (psi)]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	
100 mbar (1.5 psi)	0	+0.1 (+1.5)	0.01 (0.15)	2.7 (40.5)	4 (60)	0	2C
250 mbar (3.75 psi)	0	+0.25 (+3.75)	0.01 (0.15)	3.3 (49.5)	5 (75)	0	2E
400 mbar (6 psi)	0	+0.4 (+6)	0.02 (0.3)	5.3 (79.5)	8 (120)	0	2F
1 bar (15 psi)	0	+1 (+15)	0.05 (1)	6.7 (100.5)	10 (150)	0	2H
2 bar (30 psi)	0	+2 (+30)	0.1 (1.5)	12 (180)	18 (270)	0	2K
4 bar (60 psi)	0	+4 (+60)	0.2 (3)	16.7 (250.5)	25 (375)	0	2M
10 bar (150 psi)	0	+10 (+150)	0.5 (7.5)	26.7 (400.5)	40 (600)	0	2P
40 bar (600 psi)	0	+40 (+600)	2 (30)	40 (600)	60 (900)	0	2S

1) Factory calibration turn down: Max 20:1, higher on request or configurable in the device.

2) Product Configurator, "Sensor range" ordering feature

Sensor	Maximum sens range	or measuring	Smallest calibratable measuring span (preset	MWP	OPL	Vacuum resistance <sup>2)</sup>	Option <sup>3)</sup>
	lower (LRL)	upper (URL)	at the factory) <sup>1)</sup>			Silicone oil/ Inert oil/ Synthetic oil	
	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	
400 mbar (6 psi)	-0.4 (-6)	+0.4 (+6)	0.02 (0.3)	4 (60)	6 (90)		1F
1 bar (15 psi)	-1 (-15)	+1 (+15)	0.05 (1)	6.7 (100)	10 (150)	-	1H
2 bar (30 psi)	-1 (-15)	+2 (+30)	0.1 (1.5)	13.3 (200)	20 (300)		1K
4 bar (60 psi)	-1 (-15)	+4 (+60)	0.2 (3)	18.7 (280.5)	28 (420)	-	1M
10 bar (150 psi)	-1 (-15)	+10 (+150)	0.5 (7.5)	26.7 (400.5)	40 (600)	0.01/0.04/0.01	1P
40 bar (600 psi)	-1 (-15)	+40 (+600)	2 (30)	100 (1500)	160 (2400)	- (0.15/0.6/0.15)	1S
100 bar (1 500 psi)	-1 (-15)	+100 (+1500)	5 (75)	100 (1500)	400 (6000)	-	1U
400 bar (6 000 psi)	-1 (-15)	+400 (+6000)	20 (300)	400 (6000)	600 (9000)		1W

#### PMP51 and PMP55 – metallic process isolating diaphragm for gauge pressure

1) Factory calibration turn down: Max 20:1, higher on request or configurable in the device.

The vacuum resistance applies to the measuring cell at reference conditions. The pressure and temperature application limits of the selected filling oil must also be observed for the PMP55. → 

 <sup>(1)</sup> 109.

3) Product Configurator, "Sensor range" ordering feature

#### PMP51 and PMP55 - metallic process isolating diaphragm for absolute pressure

Sensor	Maximum ser range	nsor measuring	Smallest calibratable measuring span	MWP	OPL	Vacuum resistance <sup>2)</sup>	Option <sup>3)</sup>
	lower (LRL) lower (URL)		(preset at the factory) <sup>1)</sup>			Silicone oil/ Inert oil/ Synthetic oil	
	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar (psi)]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	[bar <sub>abs</sub> (psi <sub>abs</sub> )]	
400 mbar (6 psi)	0	+0.4 (+6)	0.02 (0.3)	4 (60)	6 (90)		2F
1 bar (15 psi)	0	+1 (+15)	0.05 (1)	6.7 (100)	10 (150)		2H
2 bar (30 psi)	0	+2 (+30)	0.1 (1.5)	13.3 (200)	20 (300)		2K
4 bar (60 psi)	0	+4 (+60)	0.2 (3)	18.7 (280.5)	28 (420)		2M
10 bar (150 psi)	0	+10 (+150)	0.5 (7.5)	26.7 (400.5)	40 (600)	0.01/0.04/0.01 (0.15/0.6/0.15)	2P
40 bar (600 psi)	0	+40 (+600)	2 (30)	100 (1500)	160 (2400)	(0.15/0.0/0.15)	2S
100 bar (1 500 psi)	0	+100 (+1500)	5 (75)	100 (1500)	400 (6000)	_	2U
400 bar (6 000 psi)	0	+400 (+6000)	20 (300)	400 (6000)	600 (9000)		2W

1) Factory calibration turn down: Max 20:1, higher on request or configurable in the device.

2) The vacuum resistance applies to the measuring cell at reference conditions. The pressure and temperature application limits of the selected filling oil must also be observed for the PMP55. → 🗎 109.

3) Product Configurator, "Sensor range" ordering feature

Output signal	<ul> <li>4 to 20 mA analog, 2-wire</li> <li>4 to 20 mA with superimposed digital communication protocol HART 6.0, 2-wire</li> <li>Digital communication signal PROFIBUS PA (Profile 3.02)</li> <li>Digital communication signal FOUNDATION Fieldbus</li> </ul>					
	Output	Option <sup>1)</sup>				
	4 to 20mA	1				
	4 to 20mA HART	2				
	PROFIBUS PA	3				
	FOUNDATION Fieldbus	4				
	1) Product Configurator, "Output" ordering feature					
Signal range 4 to 20 mA	4 to 20 mA Analog, 4 to 20 mA HART: 3.8 to 20.5 mA					
Signal on alarm	As per NAMUR NE 43					
	<ul> <li>Signal overshoot: &gt; 20.5 mA</li> <li>Signal undershoot: &lt; 3.8 mA</li> <li>Min Alarm (3.6 mA)</li> <li>4 to 20 mA HART: Options: <ul> <li>Max. alarm: can be set from 21 to 23 mA (factory setting: 22 mA)</li> <li>Hold measured value: last measured value is held</li> <li>Min. alarm: 3.6 mA</li> </ul> </li> <li>PROFIBUS PA: can be set in the Analog Input block Options: Last Valid Out Value (factory setting), Fail-safe Value, Status</li> <li>FOUNDATION Fieldbus: can be set in the Analog Input block Options: Last Good Value, Fail-safe Value (factory setting), Wrong Value</li> </ul>					
Load - 4 to 20 mA Analog 420 mA HART	$\frac{R_{Lmax}}{[\Omega]}$ $\frac{1456}{1239}$ $804$ $369$ $\frac{11.5}{20}$ $3 \rightarrow R_{Lmax} \leq \frac{U-11.5}{23} \frac{V}{23} \frac{V}{M}$ $\frac{1}{2}$ $\frac{1}{2} \frac{1}{2} \frac{V}{23} \frac{V}{M}$ $\frac{1}{2} \frac{V}{23} \frac{V}{M}$	nglog)				

- Supply voltage 11.5 to 30 V DC for intrinsically safe device versions (not for analog) Supply voltage 11.5 to 45 V DC (versions with plug-in connector 35 V DC) for other types of protection and for uncertified device versions R<sub>Lmax</sub> Maximum load resistance 2
- 3
- Supply voltage U

When operating via a handheld terminal or via a PC with an operating program, a minimum communication resistance of 250  $\Omega$  must be taken into account. 

#### Resolution

Current output: 1 μA

• Display: can be set (factory setting: presentation of the maximum accuracy of the transmitter)

#### Dead time, Time constant



Dynamic behavior current output (analog		Туре	Dead time $(t_1)$ [ms]	Time constant T63 (= t <sub>2</sub> ) [ms]	Time constant T90 (= t <sub>3</sub> ) [ms]
electronics)	max.	PMC51	60	40	50
	max.	PMP51	40	40	50
	max.	PMP55	PMP51 + influence of t	he diaphragm seal	

Presentation of the dead time and the time constant:

Dynamic behavior current output (HART electronics)		Туре	Dead time (t <sub>1</sub> ) [ms]	Time constant T63 (= t <sub>2</sub> ) [ms]	Time constant T90 (= t <sub>3</sub> ) [ms]
output (IIANI electronics)	max.	PMC51	50	85	200
	max.	PMP51	70	80	185
	max.	PMP55	PMP51 + influence of t	he diaphragm seal	

## Dynamic behavior digital output (HART electronics)

	Туре	Dead time $(t_1)$ [ms]	Dead time (t <sub>1</sub> ) [ms] + Time constant T63 (= t <sub>2</sub> ) [ms]	Dead time $(t_1)$ [ms] + Time constant T90 (= $t_3$ ) [ms]
min.	PMC51	210	295	360
max.		1010	1095	1160
min.	PMP51	210	285	345
max.		1010	1085	1145
max.	•			

#### Reading cycle

- Acyclic: max. 3/s, typical 1/s (depends on command # and number of preambles)
- Cyclic (Burst): max. 3/s, typical 2/s

The device commands the BURST MODE function for cyclic value transmission via the HART communication protocol.

#### Cycle time (update time)

Cyclic (Burst): min. 300 ms

#### **Response time**

- Acyclic: min. 330 ms, typical 590 ms (depends on command # and number of preambles)
- Cyclic (Burst): min. 160 ms, typical 350 ms (depends on command # and number of preambles)

Dynamic behavior PROFIBUS PA		Туре	Dead time (t <sub>1</sub> ) [ms]	Dead time (t <sub>1</sub> ) [ms] + Time constant T63 (= t <sub>2</sub> ) [ms]	Dead time (t <sub>1</sub> ) [ms] + Time constant T90 (= t <sub>3</sub> ) [ms]
	min.	PMC51	85	170	235
	max.		1185	1270	1335

	Туре	Dead time (t <sub>1</sub> ) [ms]	Dead time (t <sub>1</sub> ) [ms] + Time constant T63 (= t <sub>2</sub> ) [ms]	Dead time $(t_1)$ [ms] + Time constant T90 (= $t_3$ ) [ms]		
min.	PMP51	85	160	220		
max.		1185	1260	1320		
max.	PMP55	PMP51 + influence of the diaphragm seal				

#### Reading cycle (SPS)

- Acyclic: typical 25/s
- Cyclic: max. 30/s (dependent on the number and type of function blocks used in a closed-control loop)

#### Cycle time (update time)

#### min. 100 ms

The cycle time in a bus segment in cyclic data communication depends on the number of devices, on the segment coupler used and on the internal PLC cycle time.

#### **Response time**

- Acyclic: approx. 23 to 35 ms (depends on Min. Slave Interval)
- Cyclic: approx. 8 to 13 ms (depends on Min. Slave Interval)

#### Dynamic behavior FOUNDATION Fieldbus

	Туре	Dead time (t <sub>1</sub> ) [ms]	Dead time (t <sub>1</sub> ) [ms] + Time constant T63 (= t <sub>2</sub> ) [ms]	Dead time (t <sub>1</sub> ) [ms] + Time constant T90 (= t <sub>3</sub> ) [ms]
min.	PMC51	95	180	245
max.		1095	1180	1245
min.	PMP51	95	170	230
max.		1095	1170	1230
max.	PMP55	PMP51 + influence of t	he diaphragm seal	

#### Reading cycle

- Acyclic: typical 5/s
- Cyclic: max. 10/s (dependent on the number and type of function blocks used in a closed-control loop)

#### Cycle time (update time)

Cyclic: min. 100 ms

#### **Response time**

	<ul> <li>Acyclic: typical 70 ms (for standard bus parameter settings)</li> <li>Cyclic: max. 20 ms (for standard bus parameter settings)</li> </ul>				
Damping	<ul> <li>A damping affects all outputs (output signal, display):</li> <li>Via on-site display, handheld terminal or PC with operating program, continuous from</li> <li>Via DIP-switch on the electronic insert, switch position "on" (= set value) and "off" (= damping switched off)</li> <li>Factory setting: 2 s</li> </ul>				
Firmware version	Designation	Option 1)			
	01.00.zz, FF, DevRev01	76			
	01.00.zz, PROFIBUS PA, DevRev01	77			
	01.00.zz, HART, DevRev01 78				

1) Product Configurator, "Firmware version" ordering feature

#### Protocol-specific data HART

Manufacturer ID	17 (11 hex)
Device Type Code	25 (19 hex)
Device Revision	01 (01 hex) - SW version 01.00.zz
HART specification	6
DD Revision	<ul><li>01 (Dutch))</li><li>02 (Russian))</li></ul>
Device description files (DTM, DD)	Information and files can be found:
	<ul><li>www.endress.com</li><li>www.fieldcommgroup.org</li></ul>
HART load	Min. 250 Ω
HART device variables	The measured values can be freely assigned to the device variables:
	Measured values for PV (primary variable)  Pressure Level Tank content
	<ul> <li>Measured values for SV, TV (second and third variable)</li> <li>Pressure</li> <li>Level</li> </ul>
	Measured values for QV (fourth variable) Temperature
Supported functions	<ul> <li>Burst mode</li> <li>Additional Transmitter Status</li> <li>Device Locking</li> <li>Alternative operating modes</li> </ul>

#### Protocol-specific data PROFIBUS PA

Manufacturer ID	17 (11 hex)
Ident number	1554 hex
Profile Version	3.02 SW Version 01.00.zz
GSD Revision	5
DD Revision	1
GSD File	Information and files can be found:
DD Files	<ul><li>www.endress.com</li><li>www.profibus.org</li></ul>
Output values	Measured values for PV (via Analog Input Function Block) <ul> <li>Pressure</li> <li>Level</li> <li>Tank content</li> </ul> <li>Measured values for SV <ul> <li>Pressure</li> <li>Temperature</li> </ul> </li>
Input values	Input value sent from PLC, can be shown on display
Supported functions	<ul> <li>Identification &amp; Maintenance Simple device identification via control system and nameplate</li> <li>Condensed status</li> <li>Automatic ident number adaptation and switchable to following ident numbers:         <ul> <li>9700: Profile-specific transmitter identification number with the "Classic" or "Condensed" status.</li> <li>151C: Compatibility mode for the old Cerabar M (PMC41, PMC45, PMP41, PMP45, PMP46, PMP48).</li> <li>1553: Identification number for the new Cerabar M (PMC51, PMP51, PMP55).</li> </ul> </li> <li>Device locking: The device can be locked by hardware or software.</li> </ul>

#### Protocol-specific data FOUNDATION Fieldbus

T.	0	101	71	10	 L IC	IUD	u

Device Type	0x1019
Device Revision	01 (hex)
DD Revision	0x01021
Device description files (DTM, DD)	Information and files can be found:
	<ul><li>www.endress.com</li><li>www.fieldcommgroup.org</li></ul>
CFF Revision	0x000102
ITK Version	5.2.0
ITK-Certification Driver-No.	IT067700
Link-Master (LAS) capable	yes
Link Master / Basic Device selectable	Yes; Factory setting: Basic Device
Number of VCRs	44
Number of Link Objects in VFD	50
Number of FB-Schedule Objects	40

#### Virtual communication references (VCRs)

Permanent Entries	44
Client VCRs	0
Server VCRs	5
Source VCRs	8
Sink VCRs	0
Subscriber VCRs	12
Publisher VCRs	19

#### Link settings

Slot time	4
Min. Inter PDU delay	12
Max. response delay	40

#### **Transducer Blocks**

Block	Content	Output values
TRD1 Block	Contains all parameters related to the measurement	<ul> <li>Pressure or level (channel 1)</li> <li>Process temperature (channel 2)</li> <li>Measured pressure value (channel 3)</li> <li>Max. pressure (channel 4)</li> <li>Level before linearization (channel 5)</li> </ul>
Diagnostic Block	Contains diagnostic information	Error code via DI channels (channel 10 to 15)
Display Block	Contains parameters to configure the onsite display	No output values

#### **Function blocks**

Block	Content	Number of blocks	Execution time	Functionality
Resource Block	The Resource Block contains all the data that uniquely identify the device. It is an electronic version of a nameplate of the device.	1		enhanced
Analog Input Block 1 Analog Input Block 2	The AI Block receives the measuring data from the Sensor Block, (selectable via a channel number) and makes the data available to other function blocks at its output. Enhancement: digital outputs for process alarms, fail safe mode.	2	25 ms	enhanced
Digital Input Block	This block contains the discrete data of the Diagnose Block (selectable via a channel number 10 to 15) and provides them for other blocks at the output.	1	20 ms	standard
Digital Output Block	This block converts the discrete input and thus initiates an action (selectable via a channel number) in the DP Flow Block or in the im TRD1 Block. Channel 20 resets the counter for max. pressure transgressions value.	1	20 ms	standard
PID Block	The PID Block serves as a proportional-integralderivative controller and is used almost universally for closed-loop-control in the field including cascade and feedforward. Input IN can be indicated on the display. The selection is performed in the Display Block (DISPLAY_MAIN_LINE_CONTENT).	1	40 ms	standard
Arithmetic Block	This block is designed to permit simple use of popular measurement math functions. The user does not have to know how to write equations. The math algorithm is selected by name, chosen by the user for the function to be performed.	1	35 ms	standard
Input Selector Block	The Input Selector Block facilitates the selection of up to four inputs and generates an output based on the configured action. This block normally receives its inputs from AI Blocks. The block performs maximum, minimum, average and 'first good' signal selection. Inputs IN1 to IN4 can be indicated on the display. The selection is performed in the Display Block (DISPLAY_MAIN_LINE_1_CONTENT).	1	30 ms	standard
Signal Characterizer Block	DThe Signal Characterizer Block has two sections, each with an output that is a non- linear function of the respective input. The non-linear function is generated by a single look-up table with 21 arbitrary x-y pairs.	1	40 ms	standard
Integrator Block	The Integrator Block integrates a variable as a function of the time or accumulates the counts from a Pulse Input Block. The block may be used as a totalizer that counts up until reset or as a batch totalizer that has a setpoint, where the integrated or accumulated value is compared to pre-trip and trip settings, generating a binary signal when the setpoint is reached.	1	35 ms	standard

Additional function block information:

Instantiate Function Block	YES
Number of additional instantiatable function blocks	20

## Power supply

#### **WARNING**

#### An incorrect connection compromises electrical safety!

- When using the measuring device in hazardous areas, the relevant national standards and regulations as well as the safety instructions or installation or control drawings must be observed. → 
  <sup>B</sup> 122.
- According to IEC/EN61010 a suitable disconnector has to be installed for the device.
- HART: Overvoltage protection HAW569-DA2B for the non-hazardous area, ATEX II 2 (1) Ex ia IIC and IEC Ex ia can be ordered as an option (see "Ordering information" ordering feature).
- Protective circuits against reverse polarity, HF influences and overvoltage peaks are installed.

## **Terminal assignment** 1 ₩₽ (3) 1 6 3 1 External grounding terminal (only for devices with certainly approvals or if "Measuring point" (TAG) is ordered) 2 Internal grounding terminal 3 Supply voltage $\rightarrow \cong 22$ 4...20 mA for HART devices 4 For HART and FOUNDATION Fieldbus devices: With a handheld terminal, all the parameters can be 5 configured anywhere along the bus line via menu operation.

- 6 Terminals
- 7 For HART devices: test terminals, see section "Taking 4 to 20 mA test signal" → 🖺 22

#### Supply voltage

#### 4 to 20 mA HART

Type of protection	Supply voltage
Intrinsically safe	11.5 to 30 V DC
<ul><li>Other types of protection</li><li>Devices without certificate</li></ul>	11.5 to 45 V DC (versions with plug-in connection 35 V DC)

#### Taking 4 to 20 mA test signal

A 4 to 20 mA test signal may be measured via the test terminals without interrupting the measurement.

#### PROFIBUS PA

Version for non-hazardous areas: 9 to 32 V DC

#### FOUNDATION Fieldbus

Version for non-hazardous areas: 9 to 32 V DC

Current consumption	<ul> <li>PROFIBUS PA: 11 mA ±1 mA, switch-on current corresponds to IEC 61158-2, Clause 21</li> </ul>
	<ul> <li>FOUNDATION Fieldbus: 16 mA ±1 mA, switch-on current corresponds to IEC 61158-2, Clause 21</li> </ul>

Electrical connection	Cable entry	Degree of protection	Option <sup>1)</sup>
	M20 gland	IP66/68 NEMA 4X/6P	А
	G ½" thread	IP66/68 NEMA 4X/6P	С
	NPT ½" thread	IP66/68 NEMA 4X/6P	D
	M12 plug	IP66/67 NEMA 4X/6P	Ι
	7/8" plug	IP66/68 NEMA 4X/6P	М
	HAN7D plug 90 deg	IP65	Р
	PE cable 5m	IP66/68 NEMA4X/6P + pressure compensation via cable	S
	M16 valve connector	IP64	V

1) Product Configurator, "Electrical connection" ordering feature

#### PROFIBUS PA

The digital communication signal is transmitted to the bus via a 2-wire connection. The bus also provides the power supply. For further information on the network structure and grounding, and for further bus system components such as bus cables, see the relevant documentation, e.g. Operating Instructions BA00034S "PROFIBUS DP/PA: Guidelines for planning and commissioning" and the PNO Guideline.

#### **FOUNDATION Fieldbus**

The digital communication signal is transmitted to the bus via a 2-wire connection. The bus also provides the power supply. For further information on the network structure and grounding and for further bus system components such as bus cables, see the relevant documentation, e.g. Operating Instructions BA00013S "FOUNDATION Fieldbus Overview" and the FOUNDATION Fieldbus Guideline.

#### Terminals

Supply voltage and internal ground terminal: 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

• External ground terminal: 0.5 to 4 mm<sup>2</sup> (20 to 12 AWG)

Cable entry	Approval	Туре	Clamping area
	Standard, CSA GP ATEX II1/2G or II2G Ex ia, IEC Ex ia Ga/Gb or Ex ia Gb, FM/ CSA IS	Plastic M20x1.5	5 to 10 mm (0.2 to 0.39 in)
	ATEX II1/2D Ex t, II1/2GD Ex ia, II3G Ex nA, IEC Ex t Da/Db	Metal M20x1.5 (Ex e)	7 to 10.5 mm (0.28 to 0.41 in)

For other technical data, see the housing section  $\rightarrow \square 45$ 

#### Device plug connectors

#### Devices with valve connector (HART)



I BN = brown, BU = blue, GNYE = green

A Electrical connection for devices with valve connector

*B* View of the plug connector at the device

#### Material: PA 6.6

#### Devices with Harting plug Han7D (HART)



A Electrical connection for devices with Harting plug Han7D

*B* View of the plug-in connector at the device

Material: CuZn, contacts for plug-in jack and connector are gold-plated

#### Connecting the cable version (all device versions)



- $1 \quad RD = red$
- 2 BK = black
- 3 GNYE = green
- 4 4...20 mA

#### Devices with M12 plug(Analog, HART, PROFIBUS PA)



- 1 Signal +
- 2 Not assigned
- 3 Signal –
- 4 Earth

Endress+Hauser offers the following accessories for devices with an M12 connector:

Plug-in jack M 12x1, straight

- Material: body PA; coupling nut CuZn, nickel-plated
- Degree of protection (fully locked): IP66/67
- Order number: 52006263

Plug-in jack M 12x1, elbowed

- Material: body PBT/PA; coupling nut GD-Zn, nickel-plated
- Degree of protection (fully locked): IP66/67
- Order number: 71114212

Cable 4x0.34 mm<sup>2</sup> (20 AWG) with M12 socket, elbowed, screw plug, length 5 m (16 ft)

- Material: body PUR; coupling nut CuSn/Ni; cable PVC
- Degree of protection (fully locked): IP66/67
- Order number: 52010285

#### Devices with 7/8" plug (Analog, HART, FOUNDATION Fieldbus)



- 1 Signal -
- 2 Signal +
- 3 Not assigned
- 4 Shield

External thread: 7/8 - 16 UNC

- Material: 316L (1.4401)
- Protection: IP66/68

#### Cable specification

#### Analog

- Endress+Hauser recommends using twisted, shielded two-wire cables.
- The cable outer diameter depends on the cable entry used.

#### HART

- Endress+Hauser recommends using twisted, shielded two-wire cables.
- The cable outer diameter depends on the cable entry used.

	PROFIBUS PA
	Use a twisted, shielded two-wire cable, preferably cable type A
	For further information on the cable specifications, see Operating Instructions BA00034S "PROFIBUS DP/PA: Guidelines for planning and commissioning", the PNO Guideline 2.092 PROFIBUS PA User and Installation Guideline" and IEC 61158-2 (MBP).
	FOUNDATION Fieldbus
	Use a twisted, shielded two-wire cable, preferably cable type A
	For further information on the cable specifications, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview", FOUNDATION Fieldbus Guideline and IEC 61158-2 (MBP).
Start-up current	<ul> <li>Analog electronics:: 12 mA</li> <li>HART: 12 mA or 22 mA (selectable)</li> </ul>
Residual ripple	No influence on 4 to 20 mA signal up to ±5 % residual ripple within the permitted voltage range [according to HART hardware specification HCF_SPEC-54 (DIN IEC 60381-1)].
Influence of power supply	≤0.001 % of URL/V
Overvoltage protection (optional)	The device can be fitted with overvoltage protection. The overvoltage protection is mounted at the factory on the housing thread (M20x1.5) for the cable gland and is approx. 70 mm (2.76 in) in length (take additional length into account when installing). The device is connected as illustrated in the following graphic.
	For details refer to TI01013KDE, XA01003KA3 and BA00304KA2.
	Ordering information:
	Product Configurator, "Mounted accessories" ordering feature, option NA
	Wiring



- Without direct shield grounding With direct shield grounding Incoming connection cable HAW569-DA2B Α
- В
- 1
- 2 3
- Unit to be protected Connection cable 4

# Performance characteristics of the ceramic process isolating diaphragm

Reference operating conditions	• As per IEC 60770 • Ambient temperature $T_A$ = constant, in the range of +21 to +33 °C (+70 to +91 °F) • Humidity $\varphi$ = constant, in the range of: 5 to 80 % RH
	<ul> <li>Ambient pressure p<sub>U</sub> = constant, in the range of:860 to 1060 mbar (12.47 to 15.37 psi)</li> <li>Position of the measuring cell: constant, in the range of: ±1° horizontally</li> </ul>
	<ul> <li>Input of LOW SENSOR TRIM and HIGH SENSOR TRIM for lower range value and upper range value</li> <li>Span based on zero point</li> </ul>
	<ul> <li>Material of the process isolating diaphragm: Al<sub>2</sub>O<sub>3</sub> (aluminum oxide ceramic Ceraphire<sup>®</sup>)</li> <li>Supply voltage: 24 V DC ±3 V DC</li> <li>Load with HART: 250 Ω</li> </ul>

#### Influence of orientation



#### *Measuring error in mbar (psi)*

Process isolating diaphragm axis is horizontal (A)			Process isolating diaphragm pointing downwards (C)	
	Calibration position, no measuring error	< +0.2 mbar (+0.003 psi)	< -0.2 mbar (-0.003 psi)	



Position-dependent zero point shift can be corrected at the device  $\rightarrow \square 36$ 

## Uncertainty of measurement for small absolute pressure ranges

- The smallest expanded uncertainty of measurement that can be returned by our standards is:
- 0.4% of the measured value in the range of 1 to 30 mbar (0.0145 to 0.435 psi)
- 1% of the measured value in the range < 1 mbar (0.0145 psi).

#### Reference accuracy – PMC51

The reference accuracy comprises the non-linearity according to limit point setting, hysteresis and non-reproducibility as per IEC 60770. The data refer to the calibrated span.

Gauge pressure sensors			
Measuring cell Standard reference accuracy		Platinum reference accuracy	
100 mbar (1.5 psi)	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.0075 % x TD</li> </ul>	
250 mbar (3.75 psi), 400 mbar (6 psi), 1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi)	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.1 %</li> </ul>	
40 bar (600 psi)	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.0075 % x TD</li> </ul>	

Absolute pressure sensors			
Measuring cell Standard reference accuracy		Platinum reference accuracy	
100 mbar (1.5 psi)	<ul> <li>TD 1:1 to &lt; TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.015 x TD</li> </ul>	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.015 % x TD</li> </ul>	
250 mbar (3.75 psi)	<ul> <li>TD 1:1 to &lt; TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to &lt; TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.1 %</li> </ul>	
400 mbar (6 psi), 1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi)	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to &lt; TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.1 %</li> </ul>	
40 bar (600 psi)	<ul> <li>TD 1:1 to ≤ TD 10:1 = ±0.15 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to &lt; TD 10:1 = ±0.075 %</li> <li>TD &gt; 10:1 to TD 20:1 = ±0.0075 % x TD</li> </ul>	

## Thermal change in the zero PMC51 with thread or flange output and the output span – PMC51

Signal output	Measuring cell	% of the calibrated measur		
		-40 to −20 °C (-40 to -4 °F)	−10 to +60 °C (+14 to +140 °F)	-20 to +100 ℃ (-4 to +212 ℉)
HART, PROFIBUS PA, FOUNDATION Fieldbus	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±(0.6 + 0.45 x TD)	±0.2 + 0.275 x TD	±(0.4 + 0.425 x TD)
	1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.5 + 0.35 x TD	±0.1 + 0.15 x TD	±(0.225 + 0.525 x TD)
Analog (4 to 20 mA)	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±(0.6 + 0.45 x TD)	±0.4 + 0.275 x TD	±0.7 + 0.425 x TD
	1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.5 + 0.35 x TD	±0.3 + 0.15 x TD	±0.525 + 0.525 x TD

#### PMC51 with hygienic process connection

Signal output	Measuring cell	% of the calibrated measuring span	
		−10 to +60 °C (+14 to +140 °F)	−20 to +130 °C (−4 to +266 °F)
HART, PROFIBUS PA, FOUNDATION Fieldbus	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±(0.4 + 0.275 x TD)	±(0.7 + 0.425 x TD)
	1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±(0.3 + 0.15 x TD)	±(0.525 + 0.525 x TD)
Analog (4 to 20 mA)	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±(0.4 + 0.275 x TD)	±(0.7 + 0.425 x TD)
	1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±(0.3 + 0.15 x TD)	±(0.525 + 0.525 x TD)

#### Total performance - PMC51

The "Total performance" specification comprises the non-linearity including hysteresis, non-reproducibility as well as the thermal change in the zero point. All specifications apply to the temperature range -10 to +60 °C (+14 to +140 °F) and Turndown 1:1.

Signal output	Measuring cell	% URL
HART, PROFIBUS PA,	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±0.575
FOUNDATION Fieldbus	1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.5
Analog (4 to 20 mA)	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±0.775
	1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.7

#### Long-term stability

For devices with thread or flange:

	Measuring range	Long-term stability of URL / 1 year	Long-term stability of URL / 5 years	Long-term stability of URL / 10 years
PMC51	≤ 1 bar (15 psi)	±0.2 %	±0.4 %	±0.5 %
	> 1 bar (15 psi)	±0.1 %	±0.25 %	±0.4 %

#### For devices with hygienic process connections:

	Measuring range	Long-term stability of URL / 1 year
PMC51	≤ 1 bar (15 psi)	±0.35 %
	> 1 bar (15 psi)	±0.2 %

#### Total Error - PMC51

The total error comprises the long-term stability and the total performance. All specifications apply to the temperature range -10...+60 °C (+14...+140 °F) and Turndown 1:1.

	Signal output	Measuring cell	% URL / 1 Jahr
PMC51 with thread or flange	HART, PROFIBUS PA, FOUNDATION Fieldbus	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±0.55
		1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.47
	Analog (4 to 20 mA)	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±0.75
		1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.67
PMC51 with hygienic process connection	HART, PROFIBUS PA, FOUNDATION Fieldbus	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±0.925
		1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.7
	Analog (4 to 20 mA)	100 mbar (1.5 psi), 250 mbar (3.75 psi), 400 mbar (6 psi)	±1.125
		1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±0.9

Warm-up period

• 4 to 20 mA analog:  $\leq$  1,5 s

■ 4 to 20 mA HART: ≤5 s

■ PROFIBUS PA: ≤8 s

■ FOUNDATION Fieldbus: ≤20 s (after a TOTAL-reset ≤45 s)

## Performance characteristics of the metallic process isolating diaphragm

Reference operating conditions	• As per IEC 60770 • Ambient temperature $T_A$ = constant, in the range of: +21 to +33 °C (+70 to +91 °F) • Humidity $\varphi$ = constant, in the range of: 5 to 80 % RH • Ambient pressure $p_A$ = constant, in the range of: 860 to 1060 mbar (12.47 to 15.37 psi) • Position of the measuring cell: constant, in range ±1° horizontally • Input of LOW SENSOR TRIM and HIGH SENSOR TRIM for lower range value and upper range value • Span based on zero point • Material of the process isolating diaphragm: AISI 316L • Filling oil: NSF-H1 synthetik oil according to FDA 21 CFR 178.3570 • Supply voltage: 24 V DC ±3 V DC • Load with HART: 250 $\Omega$
Uncertainty of measurement for small absolute pressure ranges	<ul> <li>The smallest expanded uncertainty of measurement that can be returned by our standards is:</li> <li>0.4% of the measured value in the range of 1 to 30 mbar (0.0145 to 0.435 psi)</li> <li>1% of the measured value in the range &lt; 1 mbar (0.0145 psi).</li> </ul>
Performance Characteristics	All performance characteristics are in conformance to $\geq \pm 3$ sigma.

#### Conformance

#### Influence of orientation



#### Measuring error in mbar (psi)

	Process isolating diaphragm axis is horizontal (A)	Process isolating diaphragm pointing upwards (B)	Process isolating diaphragm pointing downwards (C)
PMP51 with process connections $\frac{1}{2}$ " thread and Silicone oil	- · ·	< +4 mbar (+0.06 psi)	< -4 mbar (-0.06 psi)
PMP51 with process connections > thread $\frac{1}{2}$ and flanges	measuring error	< +10 mbar (+0.145 psi) This value is doubled for inert oil.	< -10 mbar (-0.145 psi) This value is doubled for inert oil.



Position-dependent zero point shift can be corrected at the device.  $\rightarrow \square 36$ 

#### Reference accuracy -PMP51, PMP55

The reference accuracy comprises the non-linearity according to limit point setting, hysteresis and non-reproducibility as per IEC 60770. The data refer to the calibrated span.

	PMP51 and PMP55 without capillary				
Measuring cell	Standard reference accuracy	Platinum reference accuracy <sup>1)</sup>			
400 mbar (6 psi)	<ul> <li>TD 1:1 = ±0.15 %</li> <li>TD &gt;1:1 to TD 20:1 = ±0.15 % x TD</li> </ul>	Not available			
	<ul> <li>PMP51 with hygienic process connection:</li> <li>TD 1:1 = ±0.3 %</li> <li>TD &gt;1:1 to TD 10:1 = ±0.3 % x TD</li> </ul>	Not available			
1 bar (15 psi)	<ul> <li>TD 1:1 to TD 5:1 = ±0.15 %</li> <li>TD &gt;5:1 to TD 20:1 = ±0.03 % x TD</li> </ul>	<ul> <li>TD 1:1 to TD 2.5:1 = ±0.075 %</li> <li>TD &gt;2.5:1 to TD 20:1 = ±0.03 % x TD</li> </ul>			
	<ul> <li>PMP51 with hygienic process connection:</li> <li>TD 1:1 = ±0.3 %</li> <li>TD &gt;1:1 to TD 10:1 = ±0.3 % x TD</li> </ul>	<ul> <li>PMP51 with hygienic process connection:</li> <li>TD 1:1 = ±0.2 %</li> <li>TD &gt;1:1 to TD 10:1 = ±0.2 % x TD</li> </ul>			
2 bar (30 psi)	<ul> <li>TD 1:1 to TD 10:1 = ±0.15 %</li> <li>TD &gt;10:1 to TD 20:1 = ±0.015 % x TD</li> </ul>	<ul> <li>TD 1:1 to TD 5:1 = ±0.075 %</li> <li>TD &gt;5:1 to TD 20:1 = ±0.015 % x TD</li> </ul>			
	PMP51 with hygienic process connection: ■ TD 1:1 to TD ≤5:1 = ±0.15 % ■ TD >5:1 to TD ≤10:1 = ±0.2 %	PMP51 with hygienic process connection: ■ TD 1:1 to TD ≤5:1 = ±0.075 % ■ TD >5:1 to TD ≤10:1 = ±0.1 %			
4 bar (60 psi)	<ul> <li>TD 1:1 to TD 10:1 = ±0.15 %</li> <li>TD &gt;10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to TD 10:1 = ±0.075 %</li> <li>TD 10:1 to TD 20:1 = ±0.0075 % x TD</li> </ul>			
	PMP51 with hygienic process connection: ■ TD 1:1 to TD ≤10:1 = ±0.15 % ■ TD >10:1 to TD 20:1 = ±0.2 %	PMP51 with hygienic process connection: ■ TD 1:1 to TD ≤10:1 = ±0.075 % ■ TD >10:1 to TD 20:1 = ±0.1 %			
10 bar (150 psi), 40 bar (600 psi)	<ul> <li>TD 1:1 to TD 10:1 = ±0.15 %</li> <li>TD &gt;10:1 to TD 20:1 = ±0.2 %</li> </ul>	<ul> <li>TD 1:1 to TD 10:1 = ±0.075 %</li> <li>TD 10:1 to TD 20:1 = ±0.1 %</li> </ul>			
	PMP51 with hygienic process connection: ■ TD 1:1 to TD ≤10:1 = ±0.15 % ■ TD >10:1 to TD 20:1 = ±0.2 %	PMP51 with hygienic process connection: ■ TD 1:1 to TD ≤10:1 = ±0.075 % ■ TD >10:1 to TD 20:1 = ±0.1 %			
100 bar (1500 psi)	i) TD 1:1 to TD 10:1 = ±0.15 % TD >10:1 to TD 20:1 = ±0.2 % TD 1:1 to TD 10:1 = ±0.075 % TD 10:1 to TD 20:1 = ±0.2 %				
400 bar (6 000 psi)	<ul> <li>TD 1:1 to TD 5:1 = ±0.15 %</li> <li>TD &gt;5:1 to TD 20:1 = ±(0.03 % x TD)</li> <li>TD &gt;5:1 to TD 20:1 = ±(0.03 % x TD)</li> </ul>				

1) Only PMP51, PMP55 with direct diaphragm seal mounting

Measuring cell	PMP55 with capillary
400 mbar (6 psi)	<ul> <li>TD 1:1 = ±0.15 %</li> <li>TD &gt;1:1 to TD 20:1 = ±0.15 % x TD</li> </ul>
1 bar (15 psi)	<ul> <li>TD 1:1 to TD 3.75:1 = ±0.15 %</li> <li>TD &gt;3.75:1 to TD 20:1 = ±0.04 % x TD</li> </ul>
2 bar (30 psi)	<ul> <li>TD 1:1 to TD 3.75:1 = ±0.15 %</li> <li>TD &gt;3.75:1 to TD 20:1 = ±0.04 % x TD</li> </ul>
4 bar (60 psi)	<ul> <li>TD 1:1 to TD 10:1 = ±0.15 %</li> <li>TD &gt;10:1 to TD 20:1 = ±0.2 %</li> </ul>
10 bar (150 psi), 40 bar (600 psi)	<ul> <li>TD 1:1 to TD 10:1 = ±0.15 %</li> <li>TD &gt;10:1 to TD 20:1 = ±0.2 %</li> </ul>
100 bar (1 500 psi)	<ul> <li>TD 1:1 to TD 10:1 = ±0.15 %</li> <li>TD &gt;10:1 to TD 20:1 = ±0.2 %</li> </ul>
400 bar (6 000 psi)	<ul> <li>TD 1:1 to TD 5:1 = ±0.15 %</li> <li>TD &gt;5:1 to TD 20:1 = ±(0.03 % x TD)</li> </ul>

Thermal change in the zero output and the output span – PMP51 and PMP55

#### PMP51 and PMP55 (basic device)

When using a PMP55, the influence from the respective diaphragm seal must also be taken into account  $\rightarrow \cong$  107.

	-10 to +60 °C (+14 to +140 °F)	-40 to -10 °C (-40 to +14 °F) +60 to +85 °C (+140 to +185 °F)
Measuring cell	% of the calibrated measuring span	
400 mbar (6 psi), 1 bar (15 psi), 2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi), 100 bar (1500 psi)	±(0.34 + 0.15 x TD)	±(0.4 + 0.25 x TD)
400 bar (6000 psi)	±(0.3 + 0.35 x TD)	±(0.3 + 0.7 x TD)

#### PMP51 with hygienic process connection

Signal output	Measuring cell	-10 to +60 °C (+14 to +140 °F)	-40 to -10 °C (-40 to +14 °F) +60 to +125 °C (+140 to +257 °F)	
		% of the calibrated measuring span		
HART,	Clamp <sup>1</sup> /2" / 400 mbar (6 psi)	±(0.1 + 0.4 x TD)	±(0.8 + 1.5 x TD)	
PROFIBUS PA, FOUNDATION Fieldbus	400 mbar (6 psi), 1 bar (15 psi)	±(0.1 + 0.25 x TD)	±(0.1 + 1.1 x TD)	
	2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±(0.1 + 0.2 x TD)	±(0.1 + 0.5 x TD)	
Analog	Clamp ½" / 400 mbar (6 psi)	±(0.3 + 0.4 x TD)	±(1.1 + 1.5 x TD)	
(4 to 20 mA)	400 mbar (6 psi), 1 bar (15 psi)	±(0.3 + 0.25 x TD)	±(0.4 + 1.1 x TD)	
	2 bar (30 psi), 4 bar (60 psi), 10 bar (150 psi), 40 bar (600 psi)	±(0.3 + 0.2 x TD)	±(0.4 + 0.5 x TD)	

# Total Performance - PMP51The "Total performance" specification comprises the non-linearity including hysteresis,<br/>nonreproducibility as well as the thermal change in the zero point. All specifications apply to the<br/>temperature range -10 to +60 °C (+14 to +140 °F) and Turndown 1:1.

Signal output	Measuring cell	PMP51	PMP51 with hygienic process connection	PMP51 with gold/rhodium-coated process isolating diaphragm		
		% des U	% des URL			
HART,	400 mbar (6 psi)	±0.34	±0.34	±1.25		
PROFIBUS PA, FOUNDATION Fieldbus	1 bar (15 psi)		±0.25	±0.75		
	2 bar (30 psi)		±0.25	±0.45		
	4 bar (60 psi)	±0.30	±0.25	±0.3		
	10 bar (150 psi), 40 bar (600 psi)	±0.25	±0.25	±0.25		
	100 bar (1500 psi)	±0.25	-	±0.25		
	400 bar (6000 psi)	±0.4	-	±0.4		
Analog	400 mbar (6 psi)	±0.34	±0.54	±1.25		
(4 to 20 mA)	1 bar (15 psi)		±0.54	±0.75		
	2 bar (30 psi)		±0.45	±0.45		
	4 bar (60 psi)	±0.30	±0.45	±0.3		
	10 bar (150 psi), 40 bar (600 psi)	±0.25	±0.45	±0.25		
	100 bar (1500 psi)	±0.25	-	±0.25		
	400 bar (6000 psi)	±0.4	-	±0.4		

Long-term stability

#### For devices with thread or flange:

	Measuring range	Long-term stability of URL / 1 year	Long-term stability of URL / 5 years	Long-term stability of URL / 10 years
PMP51	all	±0.1 %	±0.2 %	±0.25 %
PMP55	all	To determine long-term stability, the basic device (PMP51) is observed without the attached diaphragm seal.		

#### For devices with hygienic process connections:

	Measuring range	Long-term stability of URL / 1 year
PMP51	≤ 1 bar (15 psi)	±0.25 %
	> 1 to 10 bar (15 to 150 psi)	±0.1 %
	40 bar (600 psi)	±0.1 %
	100 bar (1500 psi)	±0.1 %
	400 bar (6000 psi)	±0.1 %

#### Total Error - PMP51

The total error comprises the long-term stability and the total performance. All specifications apply to the temperature range -10...+60 °C (+14...+140 °F) and Turndown 1:1.

Signal output	Measuring cell	% of URL/year
HART,	400 mbar (6 psi)	±0.59
PROFIBUS PA, FOUNDATION Fieldbus	1 bar (15 psi) bis 100 bar (1500 psi)	±0.35
	400 bar (6000 psi)	±0.50
Analog	400 mbar (6 psi)	±0.79
(4 to 20 mA)	1 bar (15 psi) bis 100 bar (1500 psi)	±0.55
	400 bar (6 000 psi)	±0.50

Warm-up period

• 4 to 20 mA Analog:  $\leq$  1,5 s

• 4 to 20 mA HART:  $\leq$ 5 s

■ PROFIBUS PA: ≤8 s

■ FOUNDATION Fieldbus: ≤20 s (after a TOTAL-reset ≤45 s)

General installation instructions	The position-dependent zero point shift can be corrected: – directly at the device via operating keys on the electronic insert – directly at the device via operating keys on the display(except analog electronics) – via digital communication if the cover is not open(except analog electronics).
	<ul> <li>Endress+Hauser offers a mounting bracket for installing the device on pipes or walls.</li> <li>Use flushing rings for flange and cell diaphragm seals if medium buildup or clogging can be expected at the diaphragm seal connection. The flushing ring can be inserted between the process connection and the diaphragm seal. Thanks to the two lateral flushing bore holes, material buildup in front of the process isolating diaphragm can be rinsed away and the pressure chamber can be ventilated.</li> </ul>
	<ul> <li>To guarantee the leak-tightness of the transmitter, Endress+Hauser recommends that only genuine cable glands be used (also available as spare parts).</li> </ul>
Measuring arrangement for devices without diaphragm seal – PMC51, PMP51	Cerabar M transmitters without diaphragm seals are mounted as per the norms for a manometer (DIN EN 837-2). We recommend the use of shutoff devices and siphons. The orientation depends on the measuring application.
	Pressure measurement in gases
	Mount Cerabar M with shutoff device above the tapping point so that any condensate can flow into the process.
	Pressure measurement in steams
	Use a siphon if measuring pressure in steams. The siphon reduces the temperature to almost the ambient temperature. Fill the siphon with liquid before commissioning. Preferably mount the Cerabar M with a siphon below the tapping point.
	<ul> <li>Advantages:</li> <li>Defined water column only causes minimal/negligible measured errors</li> <li>Only minimal/negligible thermal effects on the device The device may also be mounted above the tapping point. Pay attention to the maximum</li> </ul>
	<ul><li>Fill the siphon with liquid before commissioning.</li></ul>
	Pressure measurement in liquids
	Mount Cerabar M with shutoff device below or at the same level as the tapping point.
	Level measurement
	<ul> <li>Mount Cerabar M below the lowest measuring point (zero point of the measurement).</li> <li>Do not mount the device at the following positions: In the filling curtain, in the tank outlet or at a point in the vessel which could be affected by pressure pulses from an agitator or a pump.</li> <li>The calibration and functional test can be carried out more easily if you mount the device downstream of a shutoff device.</li> </ul>
Measuring arrangement for devices with diaphragm seal	→

## Installation

Measuring arrangement for devices with diaphragm seal – PMP55
# Wall and pipe mounting, transmitter (optional)

Endress+Hauser offers the following mounting bracket for installing the device on pipes or walls:



Ordering information:

- Product configurator "Accessory Enclosed" ordering feature, option PA.
- included in the delivery for devices with a separate housing (available for order via feature "Separate housing")
- available for order as a separate accessory (Part No.: 71102216).

0

Further details  $\rightarrow \square$  93.

# Wall and pipe-mounting manifold (optional)



Ordering information:

Product Configurator "Accessory Enclosed" ordering feature, version "PK"

#### "Separate housing" version

With the "separate housing" version, you are able to mount the housing with the electronics insert at a distance from the measuring point. This allows for trouble-free measurement:

- Under particularly difficult measuring conditions (at installation locations that are cramped or difficult to access)
- If rapid cleaning of the measuring point is required
- If the measuring point is exposed to vibrations
- You can choose between different cable versions:
- PE: 2 m (6.6 ft), 5 m (16 ft) and 10 m (33 ft)
- FEP: 5 m (16 ft).
- Ordering information:
- Product Configurator, "Separate housing" ordering feature
- Product Configurator, "Enclosed accessories" ordering feature, option PA

For the dimensions  $\rightarrow \square 93$ 

In the case of the "separate housing" version, the sensor is delivered with the process connection and cable ready mounted. The housing and a mounting bracket are enclosed as separate units. The cable is provided with a socket at both ends. These sockets are simply connected to the housing and the sensor.



Degree of protection for the process connection and sensor with the use of

- FEP-cabel:
  - IP 69<sup>1)</sup>
  - IP 66 NEMA 4/6P
  - IP 68 (1,83 mH<sub>2</sub>O für 24 h) NEMA 4/6P
- PE-cabel:
  - IP 66 NEMA 4/6P
  - IP 68 (1,83 mH $_2{\rm O}$  für 24 h) NEMA 4/6P
- Technical data of the PE and FEP cable:
- Minimum bending radius: 120 mm (4.72 in)
- Cable extraction force: max.450 N (101.16 lbf)
- Resistance to UV light

<sup>1)</sup> Identification of IP protection category according to DIN EN 60529. The earlier designation "IP69K" according to DIN 40050 Part 9 is no longer valid (the standard was withdrawn on November 1, 2012). The tests required for both standards are identical.

Use in hazardous area:

- Intrinsically safe installations (Ex ia/IS)
- FM/CSA IS: for Div.1 installation only

Oxygen applications	Oxygen and other gases can react explosively to oils, grease and plastics, such that, among other things, the following precautions must be taken:
	<ul> <li>All components of the system, such as measuring devices, must be cleaned in accordance with the BAM (DIN 19247) requirements.</li> </ul>
	<ul> <li>Dependent on the materials used, a certain maximum temperature and a maximum pressure for oxygen applications must not be exceeded.</li> </ul>

The devices suitable for gaseous oxygen applications are listed in the following table with the specification  $\boldsymbol{p}_{\text{max}}$ 

Order code for devices <sup>1)</sup> , cleaned for oxygen applications	p <sub>max</sub> for oxygen applications	T <sub>max</sub> for oxygen applications
PMC51 <sup>2)</sup> – devices with sensors, nominal value < 10 bar (150 psi)	Over pressure limit (OPL) of sensor <sup>3) 4)</sup>	60 ℃ (140 °F)
PMC51 − devices with sensors, nominal value $\ge$ 10 bar (150 psi)	40 bar (600 psi)	60 ℃ (140 °F)
PMP51 , PMP55 <sup>5)</sup>	Depends on the lowest-rated element, with regard to pressure, of the selected components: over pressure limit (OPL) of sensor,process connection (1.5 x PN) or fill fluid (160 bar (2 320 psi)	85 °C (185 °F)

1)

Only device, not accessory or enclosed accessory Product Configurator, "Service" ordering feature, option "HB" 2)

3)

Product Configurator, "Sensor range" ordering feature PMC51 with PVDF thread or PVDF flange  $p_{max} = 15$  bar (225 psi)15 bar (225 psi) 4)

Product Configurator, "Service" ordering feature, option "HB" 5)

PWIS cleaning	Special cleaning of the transmitter to remove paint-wetting substances, for use in paint shops, for instance.	
	Ordering information:	
	Ordering information: Product Configurator, "Service" ordering feature, option HC	
	The stability of the materials used must be checked before using them in the medium.	
Ultrapure gas applications (PMC51 und PMP51)	Endress+Hauser also provides devices which have been cleaned of oil and grease for special applications, such as for ultrapure gas. No special restrictions regarding the process conditions apply to these devices.	
	Ordering information: Product Configurator, "Service" ordering feature, option "HA"	
Applications with hydrogen	A <b>ceramic</b> process isolating diaphragm or a <b>gold-plated</b> metal process isolating diaphragm offers universal protection against hydrogen diffusion, both in gas applications and in applications with aqueous solutions.	
	Applications with hydrogen in aqueous solutions	
	A <b>gold/rhodium-plated</b> metal process isolating diaphragm (AU/Rh) offers effective protection against hydrogen diffusion.	

## Environment

#### Ambient temperature range

Version	PMC51	PMP51	PMP55	
Without LCD display	-40 to +85 °C (-40 to +185 °F)			
With LCD display <sup>1)</sup>	-20 to +70 °C (-4 to +	-20 to +70 °C (-4 to +158 °F)		
With M12 plug , elbowed	−25 to +85 °C (−13 to	-25 to +85 °C (-13 to +185 °F)		
With separate housing		-20 to +60 °C (-4 to +140 °F) (installation without insulation)		
Diaphragm seal systems <sup>2)</sup>	-	-	→ 🗎 107	

1) Extended temperature application range (-40 to +85 °C (-40 to +185 °F)) with restrictions in optical properties such as display speed and contrast

2) Ambient temperature range and process temperature range are mutually dependent - see chapter "Thermal insulation"  $\rightarrow~\textcircled{}$  110

#### NOTICE

#### High temperatures or vibrations can destroy the device!

Storage temperature range	Version		PMC51	PMP51		PMP55
	Without LCD display		−40 to +90 °C (−40 to +185 °F)			
	With LCD display	With LCD display		185 °F)		
	With M12 plug , elbowed		−25 to +85 °C (−13 to +2	185 °F)		
	With separate housing		-40 to +60 °C (-40 to +2	140 °F)		_
	Diaphragm seal systems <sup>1)</sup>		_	-		→ 🗎 107
	1) Devices with PVC-she	eathed capillary:	-25 to +90 °C (-13 to +1	L94 °F)		
Climate class	Class 4K4H (air temperat as per DIN EN 60721-3-4			celative ł	numidity: 4 to	100%) satisfied
Degree of protection	<ul> <li>Depending on the used Ordering information: Product Configurator, "</li> <li>Separate housing → ■</li> <li>Device/Additional</li> </ul>	Electrical conr	nection" ordering featu	re	Vibration resi	stance
	option				VIDIALION IESI	stance
	Devices without mounting bracket	<ul> <li>Part 7: Guid Type Appro</li> <li>Chapter 2: 7</li> </ul>	elines for the Performano vals 'est Requirements for Ele quipment and Systems		guaranteed for 5 to 25 Hz: ±1. 25 to 100 Hz: 4 in all 3 planes	6 mm (0.06 in);
		IEC 61298-3			guaranteed for	
		IEC 60068-2-6	5		10 to 60 Hz: ±0 60 to 2000 Hz in all 3 planes	0.35 mm (0.01 in)

#### NOTICE

#### Strong vibrations can destroy the device!

- ► For high-vibration applications a PMC51/ PMP51 with a separate housing can be used.
- For high-vibration applications a PMP55 with a capillary can be used.
- We recommend a suitable bracket for mounting ( $\rightarrow \implies 37$ ).

Electromagnetic compatibility

- Electromagnetic compatibility as per all the relevant requirements of the EN 61326 series and NAMUR Recommendation EMC (NE21).
- Max. deviation : < 0.5 % of the span

Further details can be found in the manufacturer declaration.



**Process** 

A, B and C see next section.  $T_a$  = Ambient temperature.  $T_p$  = Process temperature

**Process temperature limits** 

PMC51

For oxygen applications, observe  $\rightarrow \implies 39$ 

#### PMC51 (with ceramic process isolating diaphragm)

- A: -40 to +100 °C (-40 to +212 °F) for process connections with threaded connection or flange
- B: -20 to +130 °C (-4 to +266 °F) for hygienic process connections
- C: For max. 60 minutes: +150 °C (+302 °F) for hygienic process connections
- With applications involving saturated steam, a device with a metallic process isolating diaphragm must be used, or a siphon for temperature isolation should be provided during installation.
- Observe the process temperature range of the seal. See also the following table.

Seal	Notes	Process temperature range		Option <sup>1)</sup>
		Thread or flange	Hygienic process connections	
FKM Viton	-	-20 to +100 °C (-4 to +212 °F)	-	А
FKM Viton	cleaned for O2 application	-5 to +60 °C (+23 to +140 °F)	-	A <sup>2)</sup>
FKM Viton	FDA , 3A Class I, USP Class VI	−5 to +100 °C (+23 to +212 °F)	-5 to +150 °C (+23 to +302 °F)	В
FFKM Perlast G75LT	-	-20 to +100 °C (-4 to +212 °F)	-20 to +150 °C (-4 to +302 °F)	С
NBR	FDA <sup>3)</sup>	-10 to +100 °C (+14 to +212 °F)	-	F
NBR, low temperature	-	-40 to +100 °C (-40 to +212 °F)	-	Н
HNBR	FDA <sup>3)</sup> , 3A Class I, KTW, AFNOR, BAM	-25 to +100 °C (-13 to +212 °F)	-20 to +100 °C (-4 to +212 °F)	G
EPDM 70	FDA <sup>3)</sup>	-40 to +100 °C (-40 to +212 °F)	-	J
EPDM 291	FDA <sup>3)</sup> , 3A Class II, USP Class VI, DVGW, KTW, W270, WRAS, ACS, NSF61	-15 to +100 °C (+5 to +212 °F)	−15 to +150 °C (+5 to +302 °F)	К
FFKM Kalrez 6375	-	+5 to +100 °C (+41 to +212 °F)	-	L
FFKM Kalrez 7075	-	+5 to +100 °C (+41 to +212 °F)	-	М
FFKM Kalrez 6221	FDA <sup>3)</sup> , USP Class VI	−5 to +100 °C (+23 to +212 °F)	-5 to +150 °C (+23 to +302 °F)	N
Fluoroprene XP40	FDA <sup>3)</sup> , USP Class VI, 3A Class I	+5 to +100 °C (+41 to +212 °F)	+5 to +150 °C (+41 to +302 °F)	Р
VMQ Silicone	FDA <sup>3)</sup>	−35 to +85 °C (−31 to +185 °F)	−20 to +85 °C (−4 to +185 °F)	S

1) Product Configurator, order code for "Seal"

3) Suitable for foods FDA 21 CFR 177.2600

With "HB" option, see Product Configurator, "Service" ordering feature 2)

#### Applications with jumps in temperature

Extreme jumps in temperature can result in temporary measuring errors. Temperature compensation takes effect after several minutes. Internal temperature compensation is faster the smaller the jump in temperature and the longer the time interval involved.



For further information please contact your local Endress+Hauser Sales Center.

#### PMP51 (with metallic process isolating diaphragm)

Designation	Temperature operating range
Process connections with internal process isolating diaphragm	-40 to +125 °C (-40 to +257 °F)
Process connections with flush-mounted process isolating diaphragm	-40 to +100 °C (-40 to +212 °F)
Hygienic process connections	-40 to +130 °C (-40 to +266 °F) For a maximum of 60 minutes: 150 °C (302 °F)

#### PMP55 (with diaphragm seal)

Depends on diaphragm seal and filling oil: –70 °C (–94 °F) up to +400 °C (+752 °F). Observe the temperature application limits  $\rightarrow \cong 109$ .

#### Devices with PTFE coated process isolating diaphragm

The non-stick coating has excellent gliding properties and is used to protect the process isolating diaphragm against abrasive media.

#### NOTICE

#### Destruction of the device due to incorrect use of PTFE foil!

► The PTFE foil is designed to protect the unit against abrasion. It does not provide protection against corrosive media.

For the range of application of the 0.25 mm (0.01 in) PTFE foil on an AISI 316L (1.4404/1.4435) process isolating diaphragm, see the following diagram:





Process temperature limits of flexible capillary armoring: PMP55

- 316L: No restrictions
- PTFE: No restrictions
  - PVC: See the following diagram



Pressure specifications

#### **WARNING**

## The maximum pressure for the measuring device depends on the lowest-rated element with regard to pressure.

- For pressure specifications, see the "Measuring range" section and the "Mechanical construction" section.
- ▶ Only operate the measuring device within the prescribed limits!
- The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the measuring device.
- The MWP (maximum working pressure) is specified on the nameplate. This value refers to a reference temperature of +20 °C (+68 °F) and may be applied to the device for an unlimited time. Observe temperature dependency of the MWP. The pressure values permitted at higher temperatures can be found in the standards EN 1092-1: 2001 Tab. 18 (With regard to their stability-temperature property, the materials 1.4435 and 1.4404 are grouped together under 13EO in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.), ASME B 16.5a 1998 Tab. 2-2.2 F316, ASME B 16.5a 1998 Tab. 2.3.8 N10276, JIS B 2220.
- ▶ OPL (Over Pressure Limit = sensor overload limit): The test pressure corresponds to the over pressure limit of the sensor and may only be applied for a limited time period to ensure measurement within specification and in order to avoid permanent damage. In the case of sensor range and process connections where the over pressure limit (OPL) of the process connection is smaller than the nominal value of the sensor, the device is set at the factory, at the very maximum, to the OPL value of the process connection. If you want to use the entire sensor range, select a process connection with a higher OPL value.
- ► Oxygen applications: The values for " $p_{max}$  and  $T_{max}$  for oxygen applications" may not be exceeded → 🗎 39.
- Devices with ceramic process isolating diaphragm: Avoid steam hammering! Steam hammering can cause zero point drift. Recommendation: Residue (such as condensation or drops of water) can remain at the process isolating diaphragm after CIP cleaning and lead to local steam hammering if immediately steam is introduced. In practice, drying the process isolating diaphragm (e.g. by blowing off excess moisture) has proven to be a successful way of avoiding steam hammering.

## Mechanical construction

#### **Device height**

#### The device height is calculated from

- the height of the housing
- the height of optional mounted parts such as temperature isolators or capillaries
- the height of the relevant process connection.

The individual heights of the components can be found in the following sections. To calculate the device height, simply add up the individual heights of the components. If necessary, the installation space (the space used to install the device) must also be taken into account. You can use the following table for this:



#### F31 housing, aluminum



Material	Weight kg (lbs)	Weight kg (lbs)	
	With display	Without display	
Aluminium <sup>2)</sup>	1.1 (2.43)	1.0 (2.21)	Ι
Aluminum with glass viewing window <sup>2)</sup>			J

1) Product Configurator, "Housing" ordering feature

2) Degree of protection dependent on cable entry used  $\rightarrow \triangleq 40$ 



			A0023570
1 2	Cover with viewing window Cover without viewing window		
	neering unit mm (in). Front view,	left-hand side view, top view	

Material	Weight kg (lbs)	Option 1)	
	With display	Without display	
Stainless steel <sup>2)</sup>	1.1 (2.43)	1.0 (2.21)	Q
Stainless steel with glass viewing window <sup>2)</sup>			R
Stainless steel with plastic viewing window <sup>2)</sup>			S

1) 2)

Product Configurator, "Housing" ordering feature Product Configurator, "Housing" ordering feature  $\rightarrow \cong 40$ 

#### PMC51: process connections with internal process isolating diaphragm

#### ISO 228 G threaded connection



Item	Designation	Material	Weight	Approval <sup>1)</sup>	Option <sup>2)</sup>
			kg (lb)		
		AISI 316L		CRN	GCJ
		Alloy C276 (2.4819)	-	CRN	GCC
A	Thread ISO 228 G ½" A EN 837	<ul> <li>PVDF</li> <li>Mount only with enclosed mounting bracket</li> <li>MWP 10 bar (150 psi), OPL max. 15 bar (225 psi)</li> <li>Process temperature range: -10 to +60 °C (+14 to +140 °F)</li> </ul>	0.63 (1.39)	-	GCF
В	Thread ISO 228 G ½" A, G ¼" (female))	AISI 316L	-	CRN	GLJ
D		Alloy C276 (2.4819)	-	CRN	GLC
	Thread ISO 228 G ½" A,	AISI 316L	1	CRN	GMJ
Ľ	Bore 11.4 mm (0.45 in)	Alloy C276 (2.4819)	]	CRN	GMC

1) CSA approval: Product Configurator, "Approval" ordering feature

#### ANSI threaded connection



Item	Designation	Material	Weight	Approval <sup>1)</sup>	Option <sup>2)</sup>
			kg (lb)	]	
A	ANSI ½" MNPT, ¼" FNPT	AISI 316L		CRN	RLJ
A	AINOI 72 IVIINE I, 74 I'INE I	Alloy C276 (2.4819)		CRN	RLC
D	ANSI ½" MNPT, Bore 11.4 mm (0.45 in)	AISI 316L	_	CRN	RKJ
Б		Alloy C276 (2.4819)	_	CRN	RKC
С	ANSI ½" MNPT, Bore 3 mm (0.12 in)	<ul> <li>PVDF</li> <li>Mount only with enclosed mounting bracket</li> <li>MWP 10 bar (150 psi), OPL max. 15 bar (225 psi)</li> <li>Process temperature range: +10 to +60 °C (+14 to +140 °F)</li> </ul>	0.63 (1.39)	-	RJF
D	ANSI ½" FNPT	AISI 316L		CRN	R1J
U	Bore 11.4 mm (0.45 in)	Alloy C276 (2.4819)		CRN	R1C

CSA approval: Product Configurator, "Approval" ordering feature Product Configurator, "Process connection" ordering feature 1)

2)

#### PMC51: process connections with internal process isolating diaphragm

#### JIS threaded connection



Item	Designation	Material	Weight	Option <sup>1)</sup>
			kg (lb)	
А	JIS B0202 G ½" (male))	AISI 316L	0.63 (1.39)	GNJ
В	JIS B0203 R ½" (male))	TOL J TOL		GOJ

1) Product Configurator, "Process connection" ordering feature

#### DIN 13 threaded connection



Designation	Material	Weight	Option <sup>1)</sup>
		kg (lb)	
DIN 13 M20 x 1,5, EN 837	AISI 316L	0.63 (1.39)	G5J
Bore3 mm (0.12 in)	Alloy C276 (2.4819)	(1.53)	G6J

1) Product Configurator, "Process connection" ordering feature

nections	F31 housing	F15 housing
ss 1 - height	27 mm (1.06 in)	34 mm (1.34 in)

PMC51: process connections with internal process isolating diaphragm - height H

#### PMC51: process connections with flush-mounted process isolating diaphragm

#### DIN 13 threaded connection



Designation	Material	Weight	Option <sup>1)</sup>
		kg (lb)	
DIN 13 M44 x 1.25	AISI 316L	0.63 (1.39)	G4J

1) Product Configurator, "Process connection" ordering feature

#### ISO 228 G threaded connection



Item	Designation	Material	Weight	Option <sup>1)</sup>
			kg (lb)	
А	Thread ISO 228 G 1 <sup>1</sup> /2" A	AISI 316L	0.63 (1.39)	GVJ
В	Thread ISO 228 G 2" A	AISI 316L	0.05 (1.59)	GWJ

#### PMC51: process connections with flush-mounted process isolating diaphragm

#### ANSI threaded connection



Position	Designation	Material	Weight	Approval <sup>1)</sup>	Option <sup>2)</sup>
			kg (lb)		
А	Thread ANSI 1 ½" MNPT	AISI 316L	0.63 (1.39)	CRN	U7J
В	Thread ANSI 2" MNPT	AISI 316L	0.0) (1.59)	CRN	U8J

1) CSA approval: Product Configurator, order code for "Approval"

2) Product Configurator, "Process connection" section

PMC51: process connections with flush-mounted process isolating diaphragm - height H

Process connection	F31 housing	F15 housing
DIN 13 M44 x 1.25	53 mm (2.09 in)	60 mm (2.36 in)
Thread ISO 228 G 1 <sup>1</sup> / <sub>2</sub> " A	50 mm (1.97 in)	57 mm (2.24 in)
Thread ISO 228 G 2" A	45 mm (1.77 in)	52 mm (2.05 in)
Thread ANSI 1 <sup>1</sup> / <sub>2</sub> " MNPT	48 mm (1.89 in)	55 mm (2.17 in)
Thread ANSI 2" MNPT	45 mm (1.77 in)	52 mm (2.05 in)

PMC51: process connections with flush-mounted process isolating diaphragm



Flange	Flange									Weight	Option 1)
Material	Nominal diameter	Nominal pressure	Shape <sup>2)</sup>	D	b	g	Quantity	<b>g</b> <sub>2</sub>	k	1	
				mm	mm	mm	]	mm	mm	kg (lb)	
AISI 316L	DN 25	PN 10-40	B1 (D)	115	18	68	4	14	85	1.4 (3.09)	CNJ
AISI 316L	DN 32	PN 10-40	B1 (D)	140	18	78	4	18	100	2.0 (4.41)	СРЈ
AISI 316L	DN 40	PN 10-40	B1 (D)	150	18	88	4	18	110	2.4 (5.29)	CQJ
ECTFE <sup>3)</sup>	DN 40	PN 10-40	B2 (E)	150	21	88	4	18	110	2.6 (5.73)	CQP
AISI 316L	DN 50	PN 10-40	B1 (D)	165	20	102	4	18	125	3.2 (7.06)	СХЈ
PVDF	DN 50	PN 10-16	B2 (E)	165	21.4	102	4	18	125	0.6 (1.32)	CFF
ECTFE <sup>3)</sup>	DN 50	PN 25-40	B2 (E)	165	20	102	4	18	125	3.2 (7.06)	CRP
AISI 316L	DN 80	PN 10-40	B1 (D)	200	24	138	8	18	160	5.4 (11.91)	CZJ
ECTFE <sup>3)</sup>	DN 80	PN 25-40	B2 (E)	200	24	138	8	18	160	5.5 (12.13)	CSP

1) Product Configurator, "Process connection" section

2) Description as per DIN 2527 provided in brackets

3) ECTFE coating on AISI 316L (1.4404). When operating in hazardous areas, avoid electrostatic charging of the plastic surfaces.

#### ASME flanges, connection dimensions as per ANSI B 16.5, raised face RF



Flange						Boltholes			Weight	Approval <sup>1)</sup>	Option <sup>2)</sup>
Material	Nominal diameter	Class	D	b	g	Quantity	<b>g</b> <sub>2</sub>	k			
	[in]	[lb./sq.in]	[in]	[in]	[in]	1	[in]	[in]	[kg (lb)]	_	
AISI 316/316L <sup>3)</sup>	1	150	4.25	1.18	2	4	0.62	3.12	0.9 (1.98)	-	ACJ <sup>4)</sup>
AISI 316/316L <sup>3)</sup>	1	300	4.88	1.18	2	4	0.75	3.5	1.4 (3.09)	-	ANJ <sup>4)</sup>
AISI 316/316L <sup>3)</sup>	1 1/2	150	5	0.69	2.88	4	0.62	3.88	1.0 (2.21)	CRN	AEJ
AISI 316/316L <sup>3)</sup>	1 1/2	300	6.12	0.81	2.88	4	0.88	4.5	2.6 (5.73)	CRN	AQJ
AISI 316/316L <sup>3)</sup>	2	150	6	0.75	3.62	4	0.75	4.75	2.4 (5.29)	CRN	AFJ
ECTFE <sup>5)</sup>	2	150	6	0.75	3.62	4	0.75	4.75	2.4 (5.29)	-	AFN
PVDF	2	150	6	0.75	3.62	4	0.75	4.75	0.5 (1.1)	-	AFF
AISI 316/316L <sup>3)</sup>	2	300	6.5	0.88	3.62	8	0.75	5	3.2 (7.06)	CRN	ARJ
AISI 316/316L <sup>3)</sup>	3	150	7.5	0.94	5	4	0.75	6	4.9 (10.8)	CRN	AGJ
ECTFE <sup>5)</sup>	3	150	7.5	0.94	5	4	0.75	6	4.9 (10.8)	-	AGN
PVDF	3	150	7.5	0.94	5	4	0.75	6	0.9 (1.98)	-	AGF
AISI 316/316L <sup>3)</sup>	3	300	8.25	1.12	5	8	0.88	6.62	6.8 (14.99)	CRN	ASJ
AISI 316/316L <sup>3)</sup>	4	150	9	0.94	6.19	8	0.75	7.5	7.1 (15.66)	CRN	AHJ
ECTFE <sup>5)</sup>	4	150	9	0.94	6.19	8	0.75	7.5	7.1 (15.66)	-	AHN
AISI 316/316L <sup>3)</sup>	4	300	10	1.25	6.19	8	0.88	7.88	11.6 (25.58)	CRN	ATJ

1) CSA approval: Product Configurator, order code for "Approval"

2) Product Configurator, "Process connection" section

3) Combination of AISI 316 for required pressure resistance and AISI 316L for required chemical resistance (dual rated)

4) Screws must be 15 mm (0.59 in) longer than the standard flange screws.

5) ECTFE coating on AISI 316/316L. When operating in hazardous areas, avoid electrostatic charging of the plastic surfaces.

#### JIS flanges, connection dimensions as per JIS B 2220 BL, raised face RF



Flange E							Boltholes			Option <sup>1)</sup>
Material	Nominal diameter	Nominal pressure	D	b	g	Quantity	<b>g</b> <sub>2</sub>	k		
			mm	mm	mm		mm	mm	kg (lb)	
	50 A	10 K	155	16	96	4	19	120	2.0 (4.41)	KFJ
AISI 316L (1.4435)	80 A	10 K	185	18	127	8	19	150	3.3 (7.28)	KGJ
, , ,	100 A	10 K	210	18	151	8	19	175	4.4 (9.7)	KHJ

1) Product Configurator, "Process connection" section

PMC51: process connections with flush-mounted process	F31 housing	F15 housing
isolating diaphragm - height	94 mm (3.7 in)	98 mm (3.86 in)

PMC51: hygienic process connections with flushmounted process isolating diaphragm

In order to guarantee a hygiene approval, a seal with appropriate approval must be selected for the hygienic process connection:

- For 3A approval, you require a seal made of EPDM or HNBR  $\rightarrow \triangleq 42$
- For EHEDG approval, you require a seal made of VMQ silicone, FFKM Kalrez  $\rightarrow$   $\cong$  42



Position	Designation	Nominal pressure	Material 1)	Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
				kg (lb)		
А	DIN 11851 DN40	PN 25		0.7 (1.54)	EHEDG, 3A with seal FDA, ASME-BPE, CRN	MZJ <sup>4)</sup>
В	DIN 11851 DN50	PN 25		0.9 (1.98)	EHEDG, 3A with seal FDA, ASME-BPE, CRN	MRJ <sup>4)</sup>
С	DIN 11864 DN40, Rohr DIN 11866-A	PN 16	AISI 316L (1.4435)	0.66 (1.46)	EHEDG, 3A with seal FDA, ASME-BPE	NCJ <sup>4)</sup>
D	DIN 11864 DN50, Rohr DIN 11866-A	PN 16		0.29 (0.64)	EHEDG, 3A with seal FDA, ASME-BPE	NDJ <sup>4)</sup>

Delta-ferrite content < 1 %. The roughness of the surface in contact with the medium is  $R_a < 0.76 \mu m$  (30  $\mu in$ ). 1)

CSA approval: Product Configurator, order code for "Approval" 2)

Product Configurator, "Process connection" section 3)

Endress+Hauser supplies these slotted nuts in stainless steel AISI 304 (DIN/EN material number 1.4301) or in AISI 304L (DIN/EN material 4) number 1.4307).



Position	Designation	Nominal pressure	Material <sup>1)</sup>	Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
				kg (lb)		
Е	Tri-Clamp ISO 2852, DN40-DN51 (2")	PN 40		0.65 (1.44)	EHEDG, 3A with seal FDA, CRN, ASME- BPE	TDJ <sup>4)</sup>
F	Tri-Clamp ISO 2852, DN76.1 (3")	PN 40	AISI 316L (1.4435)	0.9 (1.98)	EHEDG, 3A with seal FDA, CRN, ASME- BPE	TFJ
G	Varivent F pipe, DN25-32	PN 40		0.46 (1)	EHEDG, 3A with seal FDA, ASME-BPE	TQJ
Н	Varivent N pipe, DN40–162	PN 40		1 (2.21)	EHEDG, 3A with seal FDA, ASME-BPE	TRJ

1) Delta ferrite content < 1 %. The roughness of the surface in contact with the medium is  $R_a < 0.76 \ \mu m$  (30  $\mu in$ ).

2) CSA approval: Product Configurator, "Approval" ordering feature

3) Product Configurator, "Process connection" section

4) Endress+Hauser supplies these slotted nuts in stainless steel AISI 304 (DIN/EN material number 1.4301) or in AISI 304L (DIN/EN material number 1.4307).



Position	Designation	Nominal pressure	Material <sup>1)</sup>	Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
				kg (lb)		
Ι	DRD, DN50 (65 mm)	PN 25		0.9 (1.98)	FDA	TIJ <sup>4)</sup>
J	APV Inline, DN50	PN 40	AISI 316L (1.4435)	0.52 (1.15)	3A with seal FDA, CRN, ASME-BPE	TMJ
К	NEUMO BioControl, DN50	PN 16	, , ,	1.34 (2.6)	3A with seal FDA, ASME-BPE	S4J <sup>5)</sup>

1) Delta ferrite content < 1 %. The roughness of the surface in contact with the medium is  $R_a < 0.76 \mu m$  (30  $\mu in$ ).

2) CSA approval: Product Configurator, "Approval" ordering feature

3) Product Configurator, "Process connection" section

4) Endress+Hauser supplies these slotted nuts in stainless steel AISI 304 (DIN/EN material number 1.4301) or in AISI 304L (DIN/EN material number 1.4307).

5) 4 screws DIN912 M8 x 45 are enclosed (material A4-80)



Position	Designation	Nominal pressure	Material <sup>1)</sup>	Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
				kg (lb)		
L	SMS 1 1/2"	PN 25	AISI 316L	0.65 (1.43)	EHEDG, 3A, ASME-BPE	TXJ <sup>4)</sup>
М	SMS 2"	PN 25	(1.4435)	0.65 (1.43)	EHEDG, 3A, ASME-BPE	T7J <sup>4)</sup>

1) Delta ferrite content < 1 %. The roughness of the surface in contact with the medium is  $R_a < 0.76 \mu m$  (30  $\mu$ in).

2) CSA approval: Product Configurator, "Approval" ordering feature

3) Product Configurator, "Process connection" section

4) Endress+Hauser supplies the slotted nuts in stainless steel AISI 304 (DIN/EN material number 1.4301) or in AISI 304L (DIN/EN material number 1.4307).

Position	Process connection	F31 housing	F15 housing
A	DIN 11851 DN40	48 mm (1.89 in)	54 mm (2.13 in)
В	DIN 11851 DN50	70 mm (2.76 in)	77 mm (3.03 in)
С	DIN 11864 DN40, pipe DIN 11866-A	48 mm (1.89 in)	54 mm (2.13 in)
D	DIN 11864 DN50, pipe DIN 11866-A	70 mm (2.76 in)	77 mm (3.03 in)
E	Tri-Clamp ISO 2852, DN40-DN51 (2")	70 mm (2.76 in)	77 mm (3.03 in)
F	Tri-Clamp ISO 2852, DN76.1 (3")	70 mm (2.76 in)	77 mm (3.03 in)
G	Varivent F pipe, DN25-32	48 mm (1.89 in)	54 mm (2.13 in)
Н	Varivent N pipe, DN40-162	70 mm (2.76 in)	77 mm (3.03 in)
Ι	DRD, DN50 (65 mm)	70 mm (2.76 in)	77 mm (3.03 in)
J	APV Inline, DN50	70 mm (2.76 in)	77 mm (3.03 in)
К	NEUMO BioControl, DN50	48 mm (1.89 in)	54 mm (2.13 in)
L	SMS 1 <sup>1</sup> / <sub>2</sub> "	48 mm (1.89 in)	54 mm (2.13 in)
М	SMS 2"	48 mm (1.89 in)	54 mm (2.13 in)

#### Height H

#### Universal adapter



Designation	Nominal	Material <sup>1) 2)</sup>	Weight	Approval Process	Option <sup>4)</sup>
	pressure		[kg (lb)]	connection <sup>3)</sup>	
Universal adapter with pre-installed silicone molded seal	PN 10	<ul> <li>4: top section AISI 316L (1.4404)</li> <li>5: bottom section AISI 316L (1.4435)</li> </ul>	0.74 (1.63)	EHEDG, 3A with seal FDA, ASME-BPE	UPJ
Universal adapter with pre-installed EPDM molded seal				EHEDG, 3A, ASME-BPE	UNJ

1) The roughness of the surface in contact with the medium is  $R_a$  < 0.76  $\mu m$  (30  $\mu in).$ 

2) Endress+Hauser supplies these slotted nuts in stainless steel AISI 304 (1.4301) or in AISI 304L (1.4307).

3) EHEDG or 3A approval only with approved process connection.

4) Product Configurator, "Process connection" section

Material of the molded seal (changeable seal)	Material of the measuring cell seal at the ceramic sensor (seal not changeable)	Approval of measuring cell seal	Option <sup>1)</sup>
Silicone (Spare part order no.: 52023572)	EPDM	FDA <sup>2)</sup> 3A Class II, USP Class VI. DVGW, KTW, W270, WRAS, ACS, NSF61	К
EPDM (Spare part order no.: 71100719)	EPDM	FDA <sup>2)</sup>	J

1) Product Configurator, "Seal" ordering feature

2) food-safe FDA 21 CFR 177.2600

# PMP51: process connections ISO 228 G threaded connection with internal process isolating diaphragm



Item	Designation	Material	Weight kg (lb)	Option <sup>1)</sup>
A Thread ISO 228 G ½" A EN 837		AISI 316L		GCJ
	Alloy C276 (2.4819)		GCC	
IR I	Thread ISO 228 G ½" A, G ¼" (female)	AISI 316L	0 (2 (1 20)	GLJ
		Alloy C276 (2.4819)	0.63 (1.39)	GLC
C	Thread ISO 228 G ½" A, Bore 11.4 mm (0.45 in)	AISI 316L		GMJ
C		Alloy C276 (2.4819)		GMC

1) Product Configurator, "Process connection" ordering feature

#### DIN 13 threaded connection



Item	Designation	Material	Weight kg (lb)	Option <sup>1)</sup>
А	DIN 13 M20 x 1,5	AISI 316L		G1J
Bore 11.4 m	Bore 11.4 mm (0.45 in)	Alloy C276 (2.4819)	0.6 (1.32)	G2J
в	DIN 13 M20 x 1,5, EN 837, Bore 3 mm (0.12 in)	AISI 316L	0.0 (1.52)	G5J
в		Alloy C276 (2.4819)		G6J

#### PMP51: process connections with internal process isolating diaphragm

#### ANSI threaded connection



Item	Designation	Material	Weight	Approval <sup>1)</sup>	Option <sup>2)</sup>
			kg (lb)		
	ANSI ½" MNPT. ¼" FNPT	AISI 316L		CRN	RLJ
A	ANSI 72 IVINE 1, 74 FINE 1	Alloy C276 (2.4819)	0.63 (1.39)	CRN	RLC
в	ANSI ½" MNPT, Bore 11.4 mm (0.45 in) = 400 bar (6 000 psi)	AISI 316L		CRN	RKJ
Б		Alloy C276 (2.4819)		CRN	RKC
С	ANSI ½" FNPT	AISI 316L	07/15/	CRN	R1J
		Alloy C276 (2.4819)	0.7 (1.54)	CRN	R1C

CSA approval: Product Configurator, "Approval" ordering feature Product Configurator, "Process connection" ordering feature 1)

2)



Item	Designation	Material	Weight	Option <sup>1)</sup>
			kg (lb)	
٨	Thread ISO 228 G ½" A DIN 3852	AISI 316L	0,4 (0.88)	GRJ
A	FKM seal (item 1) pre-istalled	Alloy C276 (2.4819)	0,4 (0.00)	GRC
В	Thread ISO 228 G 1" A	AISI 316L	0,7 (1.54)	GTJ
С	Thread ISO 228 G 1 1/2" A	AISI 316L	1,1 (2.43)	GVJ
D	Thread ISO 228 G 2" A	AISI 316L	1,5 (3.31)	GWJ

#### DIN 13 threaded connection



Designation	Material	Weight	Option <sup>1)</sup>
		kg (lb)	
DIN 13 M20 x 1.5	AISI 316L	0,6 (1.32)	G7J
	Alloy C276 (2.4819)	0,0 (1.52)	G8J



Position	Designation	Material	Weight	Approval <sup>1)</sup>	Option <sup>2)</sup>
			kg (lb)		
А	ANSI ¾" MNPT	AISI 316L	0.6 (1.32)	-	U4J
В	ANSI 1" MNPT		0.7 (1.54)	CRN	U5J
С	ANSI 1 ½" MNPT		1 (2.21)	CRN	U7J
D	ANSI 2" MNPT		1.3 (2.87)	CRN	U8J

CSA approval: Product Configurator, order code for "Approval" Product Configurator, "Process connection" section 1) 2)

PMP51: process connections with flush-mounted process isolating diaphragm



Flange <sup>1)</sup>								Boltholes			Option <sup>2)</sup>
Nominal diameter	Nominal pressure	Shape <sup>3)</sup>	D	b	g	m	Quantity	<b>g</b> <sub>2</sub>	k	Flange	
			[mm]	[mm]	[mm]	[mm]		[mm]	[mm]	[kg (lb)]	
DN 25	PN 10-40	B1 (D)	115	18	68 <sup>4)</sup>	4	4	14	85	1.2 (2.65)	CNJ
DN 32	PN 10-40	B1 (D)	140	18	78 <sup>4)</sup>	9	4	18	100	1.9 (4.19)	СРЈ
DN 40	PN 10-40	B1 (D)	150	18	88 4)	14	4	18	110	2.2 (4.85)	CQJ
DN 50	PN 10-40	B1 (D)	165	20	102	-	4	18	125	3.0 (6.62)	CXJ
DN 80	PN 10-40	B1 (D)	200	24	138	-	8	18	160	5.3 (11.69)	CZJ

1) Material: AISI 316L

2) Product Configurator, "Process connection" section

3) Description as per DIN 2527 provided in brackets

4) With these process connections the raised face is smaller than described in the standard. Due to the smaller raised face, a special seal must be used.

### EN/DIN flanges, connection dimensions as per EN 1092-1/DIN 2527

PMP51: process connections with flush-mounted process isolating diaphragm



ASME flanges, connection dimensions as per ASME B 16.5, raised face RF\*

Flange 1)							Boltholes			Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
Nominal diameter	Class/nominal pressure	D	b	g	с	m	Quantity	<b>g</b> <sub>2</sub>	k			
[in]	lb./sq.in	[in]	[in]	[in]	[in]	[in]		[in]	[in]	[kg (lb)]		
1	300	4.88	0.69	2 <sup>4)</sup>	0.06	0.2	4	0.75	3.5	1.3 (2.87)	CRN	ANJ
1 1⁄2	150	5	0.69	2.88 4)	0.08	0.52	4	0.62	3.88	1.5 (3.31)	CRN	AEJ
1 1⁄2	300	6.12	0.81	2.88 4)	0.08	0.52	4	0.88	4.5	2.6 (5.73)	CRN	AQJ
2	150	6	0.75	3.62	0.08	-	4	0.75	4.75	2.4 (5.29)	CRN	AFJ
2	300	6.5	0.88	3.62	0.08	-	8	0.75	5	3.2 (7.06)	CRN	ARJ
3	150	7.5	0.94	5	0.08	-	4	0.75	6	4.9 (10.8)	CRN	AGJ
3	300	8.25	1.12	5	0.08	-	8	0.88	6.62	6.7 (14.77)	CRN	ASJ
4	150	9	0.94	6.19	0.08	-	8	0.75	7.5	7.1 (15.66)	CRN	AHJ
4	300	10	1.25	6.19	0.08	-	8	0.88	7.88	11.6 (25.88)	CRN	ATJ

1) Material: AISI 316/316L; Combination of AISI 316 for required pressure resistance and AISI 316L for required chemical resistance (dual rated)

2) CSA approval: Product Configurator, "Approval" ordering feature

3) Product Configurator, "Process connection" section

4) With these process connections the raised face is smaller than described in the standard. Due to the smaller raised face, a special seal must be used.

#### PMP51: hygienic process connections with flushmounted process isolating diaphragm



Item <sup>1)2)</sup>	Designation	Nominal pressure	Weight	Approval	Option <sup>3)</sup>
			kg (lb)	-	
A	Clamp ISO2852, DN 18-22, DIN 32676 DN 15-20	PN 40	0.5 (1.10)	EHEDG, 3A, ASME-BPE	TBJ
В	Tri-Clamp ISO2852 DN 25 (1"), DIN 32676 DN 25	PN 40	0.6 (1.32)	EHEDG, 3A, ASME-BPE	TCJ
С	Tri-Clamp ISO2852 DN 38 (1½"), DIN 32676 DN 40	PN 40	0.6 (1.32)	EHEDG, 3A, ASME-BPE	TJJ
D	Tri-Clamp ISO2852 DN 40-51 (2"), DIN 32676 DN 50	PN 40	0.7 (1.54)	EHEDG, 3A, ASME-BPE	TDJ
E	DIN 11851 DN 25	PN 40	0.7 (1.54)	EHEDG, 3A, ASME-BPE	MXJ
F	DIN 11851 DN 32	PN 40	0.8 (1.76)	EHEDG, 3A, ASME-BPE	MIJ
G	DIN 11851 DN 40	PN 40	0.9 (1.98)	EHEDG, 3A, ASME-BPE	MZJ
Н	DIN 11851 DN 50	PN 25	1.1 (2.43)	EHEDG, 3A, ASME-BPE	MRJ

1) Material: AISI 316L (1.4435)

2) The roughness of the surface in contact with the medium is  $R_a 0.76 \ \mu m$  (30  $\mu in$ ). Version optionally in conformity with ASME-BPE for use in biochemical processes, wetted surfaces  $R_a 0.38 \ \mu m$  (15  $\mu in$ ), electropolished; to be ordered using order feature 570 "Service", option "HK" in the order code.



Item <sup>1) 2)</sup>	Designation	Nominal pressure	Weight	Approval	Option <sup>3)</sup>
			kg (lb)		
Ι	SMS 1"	PN 25	0.7 (1.54)	EHEDG, 3A, ASME-BPE	T6J
J	SMS 11/2"	PN 25	0.8 (1.76)	EHEDG, 3A, ASME-BPE	T7J
К	SMS 2"	PN 25	0.9 (1.98)	EHEDG, 3A, ASME-BPE	TXJ
L	Varivent B pipe DN 10-15	PN 40	0.7 (1.54)	EHEDG, 3A, ASME-BPE	TPJ
М	Varivent F pipe DN 25-32	PN 40	0.9 (1.98)	EHEDG, 3A, ASME-BPE	TQJ
Ν	Varivent N pipe DN 40-162	PN 40	1.1 (2.43)	EHEDG, 3A, ASME-BPE	TRJ

1) Material: AISI 316L (1.4435)

2) The roughness of the surface in contact with the medium is  $R_a 0.76 \ \mu m$  (30  $\mu in$ ). Version optionally in conformity with ASME-BPE for use in biochemical processes, wetted surfaces  $R_a 0.38 \ \mu m$  (15  $\mu in$ ), electropolished; to be ordered using order feature 570 "Service", option "HK" in the order code.



Item <sup>1) 2)</sup>	Designation	Nominal pressure	Bolthole		Weight	Approval	Option <sup>3)</sup>
			Quantity Diameter H		kg (lb)		
				mm (in)	]		
0	NEUMO BioControl D 25	PN 16	4	R: 3.5 (0.14)	0.8 (1.76)	EHEDG, 3A, ASME-BPE	S1J
Р	NEUMO BioControl D 50	PN 16	4	9 (0.35)	1.2 (2.65)	EHEDG, 3A, ASME-BPE	S4J
Q	DRD DN 50	PN 25	4	11.5 (0.45)	1.0 (2.21)	ASME-BPE	TIJ
R	APV Inline DN 50	PN 40	6	8.6 (0.34)	1.2 (2.65)	EHEDG, 3A, ASME-BPE	TPJ
			2	M8			

1) Material: AISI 316L (1.4435)

2) The roughness of the surface in contact with the medium is  $R_a 0.76 \ \mu m$  (30  $\mu in$ ). Version optionally in conformity with ASME-BPE for use in biochemical processes, wetted surfaces  $R_a 0.38 \ \mu m$  (15  $\mu in$ ), electropolished; to be ordered using order feature 570 "Service", option "HK" in the order code.



Item <sup>1) 2)</sup>	Designation	Seal		Nominal pressure	Weight	Approval	Option <sup>3)</sup>
		Item	Designation		kg (lb)		
S	Thread ISO228 G ½"	1	FKM molded seal pre-installed	PN 40	0.5 (1.1)	ASME-BPE	GOJ
		2	FKM O-ring pre-installed				
Т	Thread ISO228 G1"	-	Sealing via O-ring. VMQ O-ring included with the accessories QE and QF.	PN 40	0.8 (1.76)	3A, ASME-BPE	GZJ <sup>4)</sup>
U	Thread ISO228 G1"	1	Metall joint	PN 100	0.8 (1.76)	ASME-BPE	GXJ

1) Material: AISI 316L (1.4435)

2) The roughness of the surface in contact with the medium is  $R_a 0.76 \ \mu m$  (30  $\mu in$ ). Version optionally in conformity with ASME-BPE for use in biochemical processes, wetted surfaces  $R_a 0.38 \ \mu m$  (15  $\mu in$ ), electropolished; to be ordered using order feature 570 "Service", option "HK" in the order code.

3) Product Configurator, "Process connection" ordering feature

4) EHEDG in combination with EHEDG certified process- or weld in adapter; details see TI00426F.

Valve manifold DA63M-<br/>(optional)Endress+Hauser supplies milled valve manifolds via the transmitter's product structure in the<br/>following versions:



- 2-way valve manifolds in 316L or AlloyC can be
- ordered as an enclosed accessory (seal for mounting is enclosed)
- ordered as a mounted accessory (mounted valve manifolds are supplied with a documented leakage test).

Certificates ordered with the equipment (e.g. 3.1 material certificate and NACE) and tests (e.g. PMI and pressure test) apply to the transmitter and the valve manifold.

For other details (order option, dimension, weight, materials), see SD01553P/00/EN "Mechanical accessories for pressure measuring devices".

During the operating life of the valves, it may be necessary to re-tighten the packing.

#### Mounting on valve manifold



Ordering information:

Product Configurator, order code for "Accessories mounted".

#### PMP51: process connections Prepared for diaphragm seal mount



Material	Designation	Weight kg (lb)	Approval <sup>1)</sup>	Option <sup>2)</sup>
AISI 316L (1.4404)	Prepared for diaphragm seal mount	1.9 (4.19)	CRN	XSJ

1) 2) CSA approval: Product Configurator, "Approval" ordering feature


## Outer diameter of capillary

Designation	Outer diameter
Flexible armor made from 316L	8 mm (0.31 in)
Flexible armor with PVC-coating	10 mm (0.39 in)
Flexible armor with PTFE-coating	12.5 mm (0.49 in)

#### Diaphragm seal connection

Designation	OptionProduct Configurator, "Diaphragm seal connection" ordering feature
Direct	A
Temperature isolator	В
m capillary	D
ft capillary	E

- The weights of the diaphragm seals are given in the tables. For weight of housing, see  $\rightarrow \cong 45$ 
  - The following drawings are schematic diagrams. In other words, the dimensions of a diaphragm seal supplied may deviate from the dimensions given in this document.

  - For further information please contact your local Endress+Hauser Sales Center.

## Diaphragm seal cell structure (Pancake)



Engineering unit mm (in)

Flange					Diaphragm	seal	Approval <sup>1)</sup>	Option <sup>2)</sup>
Material	Nominal diameter	Nominal pressure <sup>3)</sup>	D	b	d <sub>M</sub>	Weight		
			[mm]	[mm]	[mm]	[kg (lb)]		
	DN 50	PN 16-400	102	20	59	1.3 (2.87)	-	UIJ
	DN 80	PN 16-400	138	20	89	2.3 (5.07)	-	UJJ
	DN 100	PN 16-400	162	20	89	3.1 (6.84)	-	UKJ
AISI 316L	[in]	[lb/sq.in]	[in (mm)]	[in (mm)]	[in (mm)]			
	2	150-2500	3.89 (99)	0.79 (20)	2.32 (59)	1.3 (2.87)	CRN	ULJ
	3	150-2500	5.00 (127)	0.79 (20)	3.50 (89)	2.3 (5.07)	CRN	UMJ
	4	150-2500	6.22 (158)	0.79 (20)	3.50 (89)	3.1 (6.84)	CRN	URJ

1) CSA approval: Product Configurator, order code for "Approval"

2) Product Configurator, "Process connection" section

3) The specified nominal pressure applies to the diaphragm seal. The maximum pressure for the measuring device is dependent on the lowest-rated element, with regard to pressure, of the selected components  $\rightarrow \cong$  44.

#### Thread ISO 228 and ANSI



Threaded con	nnection						Diaphr	agm seal		Approval <sup>1)</sup>	Option <sup>2)</sup>
Material	G	Nominal pressure	d1	d <sub>2</sub>	x1	SW/AF	d <sub>M</sub>	h	Weight		
		PN	[mm]	[mm]	[mm]		[mm]	[mm]	[kg (lb)]		
AISI 316L	G 1" A	400	30	39	21 <sup>3)</sup>	41	30	19	0.4 (0.88)	-	GTJ
Alloy C276									0.5 (1.1)	-	GTC
AISI 316L	G 1 ½" A	400	44	55	30	50	42	20	0.9 (1.98)	-	GVJ
Alloy C276									1.0 (2.21)	-	GVC
AISI 316L	G 2"	400	56	68	30	65	50	20	1.9 (4.19)	-	GWJ
Alloy C276									2.1 (4.63)	-	GWC
AISI 316L	1" MNPT	400	-	45	28	41	24	17	0.6 (1.32)	CRN	U5J
Alloy C276									0.7 (1.54)	CRN	U5C
AISI 316L	1 ½" MNPT	400	-	60	30	41	36	20	0.9 (1.98)	CRN	U7J
Alloy C276				52	30	46	32	20	1.0 (2.21)	CRN	U7C
AISI 316L	2" MNPT	400	-	78	30	65	38	35	1.8 (3.97)	CRN	U8J
Alloy C276	1								2.0 (4.41)	CRN	U8C

1) CSA approval: Product Configurator, order code for "Approval"

2) Product Configurator, order code for "Process connection"

3) 28 mm (1.1 in) in conjunction with high-temperature oil

## Tri-Clamp ISO 2852



Material <sup>1)</sup> .	Nominal	Nominal	Nominal	C <sub>7</sub>	d <sub>M</sub>		h	Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
	diameter ISO 2852	diameter DIN 32676	diameter		Standard	With TempC diaphragm				
			[in]	[mm]	[mm]	[mm]	[mm]	[kg (lb)]	-	
	ND 25 / 33.7	DN 25	1	50.5	24	-	37	0.32 (0.71)	EHEDG, 3A, CRN, ASME-BPE	TCJ
	ND 38	DN 40	1 ½	50.5	36	36	30	1 (2.21)	EHEDG, 3A, CRN, ASME-BPE	TJJ <sup>4) 5)</sup>
AISI 316L	ND 51 / 40	DN 50	2	64	48	41	30	1.1 (2.43)	EHEDG, 3A, CRN, ASME-BPE	TDJ <sup>4) 5)</sup>
	ND 63.5	-	2 1⁄2	77.5	61	61	30	0.7 (1.54)	EHEDG, 3A, ASME-BPE	TEJ <sup>6)</sup>
	ND 76.1	-	3	91	73	61	30	1.2 (2.65)	EHEDG, 3A, CRN, ASME-BPE	TFJ <sup>5)</sup>

1) Surface roughness of the wetted surfaces  $R_a < 0.76 \mu m$  (29.9  $\mu in$ ) as standard. Lower surface roughness available on request

2) CSA approval: Product Configurator, order code for "Approval"

H

3) Product Configurator, order code for "Process connection"

4) Process connections without TempC diaphragm: diaphragm seal versions optionally in conformity with ASME-BPE for use in biochemical processes, wetted surfaces R<sub>a</sub> < 0.38 μm (15 μin)), lectropolished; ordering information: Product Configurator "Service" ordering feature, option HK</p>

5) Alternatively available with TempC diaphragm.

6) With TempC diaphragm

PN max. = 40 bar (580 psi). The maximum PN depends on the used clamp.

#### Pipe diaphragm seal Tri-Clamp ISO 2852



Material	Nominal diameter	Nominal diameter	Nominal pressure	D	d <sub>2</sub>	d <sub>3</sub>	h	L	Weight	Approval <sub>2)</sub>	Option <sup>3)</sup>
	ISO 2852	[in]		[mm]	[mm]	[mm]	[mm]	[mm]	[kg (lb)]		
	DN 10	3⁄4	PN 40	10.5	25	34	41.5	140	0.6 (1.32)	3A, CRN	SIJ
AISI 316L	DN 25	1	PN 40	22.5	50.5	54	67	126	1.7 (3.75)	3A, CRN	SBJ
AISI 510L	DN 38	1 1/2	PN 40	35.5	50.5	69	67	126	1.0 (2.21)	3A, CRN	SCJ <sup>4)</sup>
	DN 51	2	PN 40	48.6	64	78	79	100	1.7 (3.75)	3A, CRN	SDJ <sup>4)</sup>

1) Surface roughness of the wetted surfaces  $R_a$  < 0.8  $\mu m$  (31.5  $\mu in)$  as standard.

2) CSA approval: Product Configurator, order code for "Approval"

3) Product Configurator, order code for "Process connection"

4) incl. 3.1 and pressure test according to Pressure Equipment Directive, Category II



Varivent for pipes



Material <sup>1)</sup>	Designation	Nominal	D	d <sub>M</sub>		Weight	Approval	Option <sup>2)</sup>	
		pressure		Standard	With TempC diaphragm				
			[mm]	[mm]	[mm]	[kg (lb)]			
AISI 316L	Type F for tubes DN 25 - DN 32	PN 40	50	34	36	0.4 (0.88)	EHEDG, 3A, ASME- BPE	TQJ <sup>3)</sup>	
AISI 316L	Type N for tubes DN 40 - DN 162	PN 40	68	58	61	0.8 (1.76)	EHEDG, 3A, ASME- BPE	TRJ <sup>4) 3)</sup>	

1) Surface roughness of the wetted surfaces  $R_a < 0.76~\mu m$  (29.9  $\mu in)$  as standard.

2) Product Configurator, order code for "Process connection"

3) Alternatively available with TempC diaphragm.

4) Diaphragm seal versions optionally in conformity with ASME-BPE for use in biochemical processes, wetted surfaces R<sub>a</sub> < 0.38 μm (15 μin)), electropolished; ordering information: Product Configurator "Service" ordering feature, option HK. In combination with the "Electropolished" option, the wetted parts of the Varivent connection type N are made of 316L (1.4435).</p>

### DRD DN50 (65 mm)



Material <sup>1)</sup>	Nominal pressure	d <sub>M</sub>		Weight	Option <sup>2)</sup>
		Standard	Standard With TempC diaphragm		
		[mm]	[mm]	[kg (lb)]	
AISI 316L	PN 25	50	48	0.75 (1.65)	TIJ <sup>3)</sup>

1) Surface roughness of the wetted surfaces  $R_a < 0.76 \mu m$  (29.9  $\mu$ in) as standard.

2) Product Configurator, order code for "Process connection"

3) Alternatively available with TempC diaphragm.

## SMS nozzles with coupling nut



Material <sup>1)</sup>	Nominal	Nominal	D	f	G	m	h	d <sub>M</sub>	Weight	Approval	Option <sup>2)</sup>
	diameter	pressure	[mm]	[mm]		[mm]	[mm]	[mm]	[kg (lb)]		
	1	PN 25	54	3.5	Rd 40 – 1/6	20	42.5	24	0.25 (0.55)	3A, EHEDG, ASME-	T6J
AISI 316L	1 1⁄2	PN 25	74	4	Rd 60 – 1/6	25	57	36	0.65 (1.43)	BPE	T7J <sup>3)</sup>
	2	PN 25	84	4	Rd 70 – 1/6	26	62	48	1.05 (2.32)		TXJ <sup>3)</sup>

1) Surface roughness of the wetted surfaces  $R_a < 0.76~\mu m$  (29.9  $\mu in)$  as standard.

2) Product Configurator, order code for "Process connection"

3) Alternatively available with TempC diaphragm.

## APV-RJT nozzles with coupling nut



Material <sup>1)</sup>	Nominal diameter	Nominal pressure	D	f	G	m	h	d <sub>M</sub>	Weight	Option <sup>2)</sup>
	[in]	[bar]	[mm]	[mm]		[mm]	[mm]	[mm]	[kg (lb)]	
	1	PN 40	77	6.5	1 13/16 - 1/8"	22	42.6	21	0.45 (0.99)	тој
AISI 316L	1 1/2	PN 40	72	6.4	2 5/16 - 1/8"	22	42.6	28	0.75 (1.65)	T1J
	2	PN 40	86	6.4	2 7/8 - 1/8"	22	42.6	38	1.2 (2.65)	T2J

1) Surface roughness of the wetted surfaces  $R_a$  < 0.8  $\mu m$  (31.5  $\mu in)$  as standard.

2) Product Configurator, order code for "Process connection"

## APV-ISS nozzles with coupling nut



Material <sup>1)</sup>	Nominal diameter	Nominal pressure	D	G	SW/AF	d <sub>M</sub>	Weight	Option <sup>2)</sup>
	[in]	[bar]	[mm]			[mm]	[kg (lb)]	
	1	PN 40	54.1	1 ½" – 1/8"	46.8	24	0.4 (0.88)	T3J
AISI 316L	1 1/2	PN 40	72	2" - 1/8"	62	34	0.6 (1.32)	T4J
	2	PN 40	89	2 1⁄2" – 1/8"	77	45	1.1 (2.43)	T5J

1) Surface roughness of the wetted surfaces  $R_a$  < 0.8  $\mu m$  (31.5  $\mu in$ ) as standard.

2) Product Configurator, order code for "Process connection"

### Aseptic screwed union, nozzle, DIN 11864-1 Form A; pipe DIN 11866-A



Material <sup>1)</sup>	Taper adapter				Slotted nut		Diaphr	agm seal	Approval	Option <sup>2)</sup>
	Nominal diameter Nominal pressure D f		G	m	d <sub>M</sub>	Weight				
	[in]	[bar]	[mm]	[mm]			[mm]	[kg (lb)]		
AISI 316L	DN 40	PN 40	55	10	Rd 65 x 1/6"	21	36	0.63 (1.39)	EHEDG, 3A, ASME-BPE	NCJ
AISI 510L	DN 50	PN 25	67	11	Rd 78 x 1/6"	22	48	0.92 (2.03)	EHEDG, 3A, ASME-BPE	NDJ

1) Surface roughness of the wetted surfaces  $R_a < 0.8 \mu m$  (31.5  $\mu in$ ) as standard.

2) Product Configurator, "Process connection" section

#### Aseptic flange connection, DIN 11864-2 Form A; pipe DIN 11866-1



Material <sup>1)</sup>	Collar flange					Diaphra	agm seal	Approval	Option <sup>2)</sup>
	Nominal diameter	Nominal pressure	К	d	D	d <sub>M</sub>	Weight		
	[in]	[bar]	[mm]	[mm]	[mm]	[mm]	[kg (lb)]		
	DN 32	PN 16	59	47.7	76	25	1.5 (3.31)	EHEDG, 3A, ASME-BPE	NFJ
AISI 316L	DN 40		65	53.7	82	35	1.7 (3.75)	EHEDG, 3A, ASME-BPE	NXJ
	DN 50		77	65.7	94	45	2.2 (4.85)	EHEDG, 3A, ASME-BPE	NZJ

Surface roughness of the wetted surfaces  $R_a$  < 0.8  $\mu m$  (31.5  $\mu in)$  as standard. 1)

2) Product Configurator, "Process connection" section

### Taper adapter with coupling nut, DIN 11851



Material 1)	Taper adapter	:			Slotted nut		Diaphrag	n seal		Approval	Option <sup>2)</sup>
	Nominal diameter	Nominal pressure	D	f	G	m	d <sub>M</sub>	d <sub>M</sub>			
		PN					Standard	With TempC diaphragm			
	[in]	[bar]	[mm]	[mm]		[mm]	[mm]	[mm]	[kg (lb)]		
	DN 32	PN 40	50	10	Rd 58 x 1/6"	21	32	28	0.45 (0.99)	EHEDG, 3A, ASME-BPE	MIJ <sup>3)</sup>
	DN 40	PN 40	56	10	Rd 65 x 1/6"	21	38	36	0.45 (0.99)	EHEDG, 3A, ASME-BPE	MZJ <sup>3)</sup>
AISI 316L	DN 50	PN 25	68.5	11	Rd 78 x 1/6"	19	52	48	1.1 (2.43)	EHEDG, 3A, ASME-BPE	MRJ <sup>3)</sup>
	DN 65	PN 25	86	12	Rd 95 x 1/6"	21	66	61	2.0 (4.41)	EHEDG, 3A, ASME-BPE	MSJ <sup>3)</sup>
	DN 80	PN 25	100	12	Rd 110 x 1/4"	26	81	61	2.55 (5.62)	EHEDG, 3A, ASME-BPE	MTJ <sup>3)</sup>

1) Surface roughness of the wetted surfaces  $R_a$  < 0.76  $\mu m$  (29.9  $\mu in)$  as standard.

2) 3) Product Configurator, "Process connection" section

Alternatively available with TempC diaphragm.

#### **NEUMO BioControl**



Material <sup>1)</sup>			10.4	- 1200	C (11/1++	1 2 0 2 °F	、		Diaphrag	n seal	-	Approval	Option <sup>2)</sup>
	Process temp	perature range	e: -10 to	0 +200	C (+14 to	+392 F	)		d <sub>M</sub>		Weight		
	Nominal diameter	Nominal pressure	D	d	d <sub>2</sub>	d <sub>3</sub>	<b>d</b> <sub>1</sub>	h	Standard	With TempC diaphragm			
		[bar]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[kg (lb)]		
	DN 50	PN 16	90	17	4 x Ø 9	50	70	27	40	36	1.1 (2.43)	3A, ASME- BPE	S4J <sup>3)</sup>
AISI 316L	DN 80	PN 16	140	25	4 x Ø 11	87.4	115	37	61	61	2.6 (5.73)	EHEDG, 3A, ASME- BPE	S6J <sup>4)</sup>

1) Surface roughness of the wetted surfaces  $R_a < 0.76 \ \mu m$  (29.9  $\mu in$ ) as standard.

2) Product Configurator, order code for "Process connection"

3) Alternatively available with TempC diaphragm.

4) With TempC diaphragm

## Universal adapter



Designation	Nominal pressure	Material <sup>1)</sup>	Weight	Approval <sup>2)</sup>	Option <sup>3)</sup>
			[kg (lb)]		
Universal adapter with silicone molded seal (spare part no.: 52023572) FDA 21CFR177.2600/USP Class VI	PN 10	AISI 316L (1.4435)	0.8 (1.76)	EHEDG, 3A, ASME-BPE	UPJ <sup>4) 5)</sup>

1) The roughness of the surface in contact with the medium is  $R_a < 0.76 \ \mu m$  (29.9  $\mu in$ ). Optionally available as an ASME-BPE-compliant version for use in biochemical processes, surfaces in contact with medium  $R_a < 0.38 \ \mu m$  (15  $\mu in$ ) electropolished, ordering information: Product Configurator, order code for "Service", option "HK"

2) EHEDG or 3A approval only with approved process connection.

3) Product Configurator, "Process connection" section

- 4) Endress+Hauser supplies these slotted nuts in stainless steel AISI 304 (1.4301) or in AISI 304L (1.4307).
- 5) Alternatively available with TempC diaphragm.

# EN/DIN flanges, connection dimensions as per EN 1092-1/DIN 2527 and DIN 2501-1 A0021680 $\,$



Flange <sup>1) 2) 3)</sup>							Boltholes			Diaphr	Option <sup>4)</sup>	
Nominal diameter	Nominal pressure	Shape <sup>5)</sup>	D	b	g	f	Quantity	<b>g</b> <sub>2</sub>	k	d <sub>M</sub>	Weight	
			[mm]	[mm]	[mm]	[mm]	1	[mm]	[mm]	[mm]	[kg (lb)]	1
DN 25	10-40	B1 (D)	115	18	68	3	4	14	85	32	2.1 (4.63)	CNJ <sup>6)</sup>
DN 25	63-160	B2 (E)	140	24	68	2	4	18	100	28	2.5 (5.51)	QIJ
DN 25	250	B2 (E)	150	28	68	2	4	22	105	28	3.7 (8.16)	QJJ
DN 25	400	B2 (E)	180	38	68	2	4	26	130	28	7.0 (15.44)	QSJ
DN 32	10-40	B1 (D)	140	18	77	2.6	4	18	100	34	1.9 (4.19)	СРЈ
DN 40	10-40	B1 (D)	150	18	87	2.6	4	18	110	48	2.2 (4.85)	CQJ
DN 50	10-40	B1 (D)	165	20	102	3	4	18	125	59	3.0 (6.62)	CXJ <sup>6)</sup>
DN 50	63	B2 (E)	180	26	102	3	4	22	135	59	4.6 (10.14)	PDJ
DN 50	100-160	B2 (E)	195	30	102	3	4	26	145	59	6.2 (13.67)	QOJ
DN 50	250	B2 (E)	200	38	102	3	8	26	150	59	7.7 (16.98)	QMJ
DN 50	400	B2 (E)	235	52	102	3	8	30	180	59	14.7 (32.41)	QVJ
DN 80	10-40	B1 (D)	200	24	138	3.5	8	18	160	89	5.3 (11.69)	CZJ <sup>6)</sup>
DN 80	100	B2 (E)	230	32	138	4	8	24	180	89	8.9 (19.62)	РРЈ
DN 100	100	B2 (E)	265	36	175	5	8	30	210	89	13.7 (30.21)	PQJ

1) Material: AISI 316L

2) The roughness of the surface in contact with the medium, including the raised face of the flanges (all standards) made of Alloy C276, Monel, tantalum, rhodium>gold or PTFE is R<sub>a</sub>< 0.8 µm (31.5 µin). Lower surface roughness on request.</p>

3) The flange raised face is made of the same material as the process isolating diaphragm.

4) Product Configurator, "Process connection" section

5) Description as per DIN 2527 provided in brackets

6) Alternatively available with TempC membrane. Diameter of process isolating diagram modified in TempC version: DN25: 28 mm; DN50: 61 mm.



# EN/DIN flanges with barrel (extended diaphragm seal), connection dimensions as per EN 1092- 1/DIN 2527 and DIN 2501-1

Flange <sup>1) 2)</sup>	Boltholes			Diaph	ıragm seal	Option <sup>3)</sup>					
Nominal diameter	Nominal pressure	Shape <sup>4)</sup>	D	b	g	Quantity	<b>g</b> <sub>2</sub>	k	d <sub>M</sub>	Weight	
			[mm]	[mm]	[mm]	]	[mm]	[mm]	d <sub>M</sub>	[kg (lb)]	
DN 50	PN 10-40	B1 (D)	165	20	102	4	18	125	47	5)	FDJ <sup>5)</sup>
DN 80	PN 10-40	B1 (D)	200	24	138	8	18	160	72	5)	FEJ <sup>5)</sup>

1) Material: AISI 316L

2) In the case of process isolating diaphragms made of Alloy C276, Monel or tantalum, the raised face of the flange and the barrel pipe are made of 316L

3) Product Configurator, "Process connection" section

4) Description as per DIN 2527 provided in brackets

5) Available with 50 mm (1.97 in), 100 mm (3.94 in) and 200 mm (7.87 in)barrel, (extended diaphragm seal), for barrel (extended diaphragm seal) diameter and weight see the following table

Option <sup>1)</sup>	Nominal diameter	Nominal pressure	(L)	d <sub>3</sub>	Weight
			[mm]	[mm]	[kg (lb)]
FDJ	DN 50	PN 10-40	50 / 100 / 200	48.3	3.2 (7.1)/ 3.8 (8.4)/ 4.4 (9.7)
FEJ	DN 80	PN 10-40	50 / 100 / 200	76	6.2 (13.7)/ 6.7 (14.8)/ 7.8 (17.2)

1) Product Configurator, order code for "Process connection"



Flange <sup>1) 2) 3)</sup>						Boltholes			Diaph	ragm seal	Approval <sup>4)</sup>	Option <sup>5)</sup>
Nominal diameter	Class	D	b	g	f	Quantity	<b>g</b> <sub>2</sub>	k	d <sub>M</sub>	Weight	-	
[in]	[lb./sq.in]	[in]	[in]	[in]	[in]	-	[in]	[in]	[in]	[kg (lb)]	-	
1	150	4.25	0.56	2	0.08	4	0.62	3.12	1.26	1.2 (2.65)	CRN <sup>6)</sup>	ACJ 7)
1	300	4.88	0.69	2	0.08	4	0.75	3.5	1.26	1.3 (2.87)	CRN	ANJ <sup>7)</sup>
1	400/600	4.88	0.69	2	0.25	4	0.75	3.5	1.26	1.4 (3.09)	CRN	A0J
1	900/1500	5.88	1.12	2	0.25	4	1	4	1.26	3.2 (7.06)	CRN	A2J
1	2500	6.25	1.38	2	0.25	4	1	4.25	1.26	4.6 (10.14)	CRN	A4J
1 1/2	150	5	0.69	2.88	0.06	4	0.62	3.88	1.89	1.5 (3.31)	CRN	AEJ
1 1⁄2	300	6.12	0.81	2.88	0.06	4	0.88	4.5	1.89	2.6 (5.73)	CRN	AQJ
2	150	6	0.75	3.62	0.06	4	0.75	4.75	2.32	2.2 (4.85)	CRN	AFJ <sup>7)</sup>
2	300	6.5	0.88	3.62	0.06	8	0.75	5	2.32	3.4 (7.5)	CRN	ARJ <sup>7)</sup>
2	400/600	6.5	1	3.62	0.25	8	0.75	5	2.32	4.3 (9.48)	CRN	A1J
2	900/1500	8.5	1.5	3.62	0.25	8	1	6.5	2.32	10.3 (22.71)	CRN	A3J
2	2500	9.25	2	3.62	0.25	8	1.12	6.75	2.32	15.8 (34.84)	CRN	A5J
3	150	7.5	0.94	5	0.06	4	0.75	6	3.5	5.1 (11.25)	CRN	AGJ <sup>7)</sup>
3	300	8.25	1.12	5	0.06	8	0.75	6	3.5	7.0 (15.44)	CRN	ASJ <sup>7)</sup>
4	150	9	0.94	6.19	0.06	8	0.75	7.5	3.5	7.2 (15.88)	CRN	AHJ
4	300	10	1.25	6.19	0.06	8	0.88	7.88	3.5	11.7 (25.8)	CRN	ATJ

1) Material AISI 316/316L: Combination of AISI 316 for required pressure resistance and AISI 316L for required chemical resistance (dual rated)

2) The roughness of the surface in contact with the medium including the raised face of the flanges (all standards) made of Alloy C276, Monel, tantalum, rhodium>gold or PTFE is R<sub>a</sub>< 0.8 µm (31.5 µin). Lower surface roughness on request.

3) The flange raised face is made of the same material as the process isolating diaphragm.

4) CSA approval: Product Configurator, order code for "Approval"

5) Product Configurator, order code for "Process connection"

6) CRN approval not for TempC membrane.

7) Alternatively available with TempC membrane. Diameter of process isolating diaphragm is modified in TempC version: nominal diameter 1": 1.1 in; 2": 2.40 in.



# ASME flanges with barrel (extended diaphragm seal), connection dimensions as per ASME B 16.5, raised face RF

Flange <sup>1) 2)</sup>						Boltholes			Diaphr	agm seal	Approval <sup>3)</sup>	Option <sup>4)</sup>
Nominal diameter	Class	D	b	g	f	Quantity	<b>g</b> <sub>2</sub>	k	d <sub>M</sub>	Weight		
[in]	[lb./sq.in]	[in]	[in]	[in]	[in]	]	[in]	[in]	[in]	[kg (lb)]		
2	150	6	0.75	3.62	0.06	4	0.75	4.75	1.85	5)	CRN	FMJ <sup>5)</sup>
3	150	7.5	0.94	5	0.06	4	0.75	6	2.83	5)	CRN	FNJ <sup>5)</sup>
3	300	8.25	1.12	5	0.06	8	0.88	6.62	2.83	5)	CRN	FWJ <sup>5)</sup>
4	150	9	0.94	6.19	0.06	8	0.75	7.5	3.5	5)	CRN	FOJ <sup>5)</sup>
4	300	10	1.25	6.19	0.06	8	0.88	7.88	3.5	5)	CRN	FXJ <sup>5)</sup>

Material: AISI 316/316L. Combination of AISI 316 for required pressure resistance and AISI 316L for required chemical resistance (dual rated)
 In the case of process isolating diaphragms made of Alloy C276, Monel or tantalum, the raised face of the flange and the barrel pipe are made of 316L.

3) CSA approval: Product Configurator, "Approval" ordering feature

4) Product Configurator, "Process connection" section

5) Available with 2", 4", 6" and 8" barrel (extended diaphragm seal), for barrel (extended diaphragm seal) diameter and weight see the following table

Option <sup>1)</sup>	Nominal diameter	Class	(L)	d <sub>3</sub>	Weight
	[in]	[lb./sq.in]	in (mm)	in (mm)	[kg (lb)]
FMJ	2	150	2 (50.8) / 4 (101.6) / 6 (152.4) / 8 (203.2)	1.9 (48.3)	3.0 (6.6)/ 3.4 (7.5)/ 3.9 (8.6)/ 4.4 (9.7)
FNJ	3	150	2 (50.8) / 4 (101.6) / 6 (152.4) / 8 (203.2)	2.99 (76)	6.0 (13.2) / 6.6 (14.5) / 7.1 (15.7) / 7.8 (17.2)
FWJ	3	300	2 (50.8) / 4 (101.6) / 6 (152.4) / 8 (203.2)	2.99 (76)	7.9 (17.4) / 8.5 (18.7) / 9.0 (19.9) / 9.6 (21.2)
FOJ	4	150	2 (50.8) / 4 (101.6) / 6 (152.4) / 8 (203.2)	3.7 (94)	8.6 (19) / 9.9 (21.8) / 11.2 (24.7) / 12.4 (27.3)
FXJ	4	300	2 (50.8) / 4 (101.6) / 6 (152.4) / 8 (203.2)	3.7 (94)	13.1 (28.9)/ 14.4 (31.6)/ 15.7 (34.6)/ 16.9 (37.3)

1) Product Configurator, order code for "Process connection"

### JIS flanges, connection dimensions as per JIS B 2220 BL, raised face RF



Flange <sup>1) 2) 3)</sup>			Boltholes			Diaphra	Option <sup>4)</sup>				
Nominal diameter	Nominal pressure	D	b	g	f	Quantity	<b>g</b> <sub>2</sub>	k	d <sub>M</sub>	Weight	-
		[mm]	[mm]	[mm]	[mm]		[mm]	[mm]	[mm]	[kg (lb)]	
25 A	10 K	125	14	67	1	4	19	90	32	1.5 (3.31)	КСЈ
40 A	10 K	140	16	81	2	4	19	105	48	2.0 (4.41)	KEJ
50 A	10 K	155	16	96	2	4	19	120	59	2.3 (5.07)	KFJ
80 A	10 K	185	18	127	2	8	19	150	89	3.3 (7.28)	KGJ
100 A	10 K	210	18	151	2	8	19	175	89	4.4 (9.7)	КНЈ

1) material: AISI 316L

2) The roughness of the surface in contact with the medium including the raised face of the flanges (all standards) made of Alloy C276, Monel, tantalum, rhodium>gold or PTFE is R<sub>a</sub>< 0.8 μm (31.5 μin). Lower surface roughness on request.

3) The flange raised face is made of the same material as the process isolating diaphragm.

4) Product Configurator, "Process connection" section

## PMP55 process connections Welded separators



Position	Description	Material	Measuring range	Nominal pressure	Approval	Weight	Option <sup>1)</sup>
			[bar (psi)]			[kg (lb)]	
А	Welded, ISO 228 G ½ A EN837				-		UBJ
В	Welded, ANSI ½ MNPT	AISI 316L	≤ 160 (2320)	PN 160	CRN <sup>2)</sup>	1.43 (3.15)	UCJ
С	Welded, Gewinde DIN13 M20x1.5	1			-		UFJ

1) Product Configurator, order code for "Process connection"

2) CSA approval: Product Configurator, order code for "Approval"



#### Threaded separators

Position	Description	Material	Measuring range	Nominal pressure	Weight	Option <sup>1)</sup>
			[bar (psi)]		[kg (lb)]	
А	Threaded, ½" NPT with FKM Viton seal -20 to +200 °C (-4 to +392 °F)	AISI 316L	≤ 250 (3625)	) PN 250	4.75 (10.47)	UGJ
В	Threaded, 1" NPT with FKM Viton seal -20 to +200 °C (-4 to +392 °F)	screws made of A4	2 2 0 (2 2 2 )	FN 230	5.0 (11.03)	UHJ

1) Product Configurator, order code for "Process connection"



Position	Description	Material	Measuring range [bar (psi)]	Nominal pressure	Weight [kg (lb)]	Option <sup>1)</sup>
A	Threaded, ISO 228 G ½ A EN837 with PTFE seal -40 to +260 °C (-40 to +500 °F)	AISI 316L,	≤ 40 (580)	PN 40	1.43 (3.15)	UDJ <sup>2)</sup>
В	Threaded, ANSI ½ MNPT with PTFE seal -40 to +260 °C (-40 to +500 °F)	screws made of A4	≥ 40 (000)	FIN 40	1.45 (5.15)	UEJ <sup>2)</sup>

- 1) Product Configurator, order code for "Process connection"
- 2) In combination with silicone oil, inert oil and plant oil.



Position	Description	Material	Measuring range		Weight	Option <sup>1)</sup>
			[bar (psi)]	pressure	[kg (lb)]	
А	Threaded, ISO 228 G $\frac{1}{2}$ A EN837 with metal seal (silver-plated) –60 to +400 °C (–76 to +752 °F)	AISI 316L,	≤ 40 (580) PN 40	DN 40	1.38 (3.04)	UDJ <sup>2)</sup>
В	Threaded, ANSI ½ MNPT with metal seal (silverplated) –60 to +400 °C (–76 to +752 °F)	screws made of A4	≤ 40 (000)	FIN 40	1.50 (5.04)	UEJ <sup>2)</sup>

1) Product Configurator, order code for "Process connection"

2) In combination with high-temperature oil.



Position	Description	Material	Measuring range	- 1	Weight	Option <sup>2)</sup>
			[bar (psi)]	pressure 1)	[kg (lb)]	
A	Threaded, ISO 228 G ½ A EN837, with integrated seal lip −60 to +400 °C (−76 to +752 °F)	AISI 316L,	> 40 (580)	PN 400	4.75 (10.47)	UDJ
В	Threaded, ANSI $\frac{1}{2}$ MNPT, with integrated seal lip -60 to +400 °C (-76 to +752 °F)	screws made of A4	~ 40 (380)	FN 400	4.75 (10.47)	UEJ

1) 2) This separator is assembled prior to delivery and must not be disassembled! Product Configurator, order code for "Process connection"

### Wall and pipe mounting with "Separate housing" version



Item	Designation	Weight (kg (lb)		Option <sup>1)</sup>
		Housing (F31 or F15) Mounting bracket		
А	Dimensions with F31 housing	→ 🗎 45	0.5 (1.10)	П
В	Dimensions with F15 housing		0,5 (1.10)	0

1) Product Configurator, "Separate housing" ordering feature

Also available for order as a separate accessory: part number 71102216

# Reduction in installation height

If the separate housing is used, the mounting height of the process connection is reduced compared to the dimensions of the standard version.



## Weight

Component part	Weight
Housing	See "Housing" section
Process connection	See "Process connections" section
Capillary with armoring made of AISI 316L (1.4404)	0.16 kg/m (0.35 lb/m) + 0.2 kg (0.44 lb) (weight per capillary line)
Capillary with armoring made of AISI 316L (PVC)	0.21 kg/m (0.46 lb/m) + 0.2 kg (0.44 lb) (weight per capillary line)
Capillary with armoring made of AISI 316L (PTFE)	0.29 kg/m (0.64 lb/m) + 0.2 kg (0.44 lb) (weight per capillary line)

# Materials not in contact with F31 housing process



Item number	Component part	Material
1	F31 housing, RAL 5012 (blue)	Die-cast aluminum with protective powder-coating on polyester base
2	Cover, RAL 7035 (gray)	Die-cast aluminum with protective powder-coating on polyester base
3	Cover seal	EPDM
4	Sight glass	Mineral glass
5	Sight glass seal	Silicone (VMQ)
6	External ground terminal	AISI 304 (1.4301)
7	Nameplates	Plastic film
8	Attachement for tie-on label	AISI 304 (1.4301)/ AISI 316 (1.4401)
9	Pressure compensation filter	AISI 316L (1.4404) and PBT-FR
10	Pressure compensation filter, O-ring	VMQ or EPDM
11	Sealing ring	EPDM
12	Snap ring	PC Plastic
13	Seal of cable gland and blind plug	EPDM/NBR
14	Cable gland	Polyamide (PA), for dust ignition-proof: CuZn nickel- plated
15	Blind plug	PBT-GF30 FR
		for dust ignition-proof, Ex d, FM XP and CSA XP: AISI 316L (1.4435)
16	Cover clamp	Clamp AISI 316L (1.4435), screw A4

## F15 housing



Item number	Component part	Material
1	F15 housing	AISI 316L (1.4404)
2	Cover	-
3	Cover seal	Silicone with PTFE coating
4	Sight glass for non-hazardous area, ATEX Ex ia, NEPSI Zone 0/1 Ex ia, IECEx Zone 0/1 Ex ia, FM NI, FM IS, CSA IS	Polycarbonate (PC)
4	Sight glass for ATEX 1/2 D, ATEX 1/3 D, ATEX 1 GD, ATEX 1/2 GD, ATEX 3 G, FM DIP, CSA dust ignition-proof	Mineral glass
5	Sight glass seal	Silicone (VMQ)
6	External ground terminal	AISI 304 (1.4301)
7	Attachement for tie-on label	AISI 304 (1.4301)/ AISI 316 (1.4401)
8	Pressure compensation filter	AISI 316L (1.4404) and PBT-FR
9	Pressure compensation filter, O-ring	VMQ or EPDM
10	Nameplates	lasered
11	Cable gland	Polyamide (PA), for dust ignition- proof: CuZn nickel-plated
12	Seal of cable gland and blind plug	NBR/Silicone/EPDM
13	Sealing ring	EPDM
14	Screw	A4-50

## **Connecting parts**



Item number	Component part	Material
1	Connection between the housing and process connection	AISI 316L (1.4404)
2	Mounting bracket	Bracket AISI 316L (1.4404)
3		Screw and nuts A4-70
4		Half-shells: AISI 316L (1.4404)
5	Seal for cable from Separate housing	FKM, EPDM
6	<ul><li>Gland for cable from separate housing:</li><li>Screws:</li></ul>	<ul><li>AISI 316L (1.4404)</li><li>A2</li></ul>
7	PE cable for separate housing	Abrasion-proof cable with strain-relief Dynema members; shielded using aluminum-coated film; insulated with polyethylene (PE-LD), black; copper wires, twisted, UV-resistant
8	FEP cable for separate housing	Abrasion-proof cable; shielded using galvanized steel wire netting; insulated with fluorinated ethylene propylene (FEP), black; copper wires, twisted, UV-resistant
9	Process connection adapter for separate housing	AISI 316L (1.4404)
10	Cell body	AISI 316L (1.4404)
11	Connection between body of measuring cell and capillary	AISI 316L (1.4404)
12	Shrink tubing (available only if capillary armoring comprises PVC coating or PTFE sheath)	Polyolefin



Position	Component part	A Standard <sup>1)</sup> Armor for capillary	B PVC-coated Armor for capillary	C PTFE hose Armor for capillary
1	Capillary	AISI 316 Ti (1.4571)	AISI 316 Ti (1.4571)	AISI 316 Ti (1.4571)
2	Flexible armor for capillary	AISI 316L (1.4404) <sup>2)</sup>	AISI 316L (1.4404)	AISI 316L (1.4404)
3	Coating/armor	-	PVC <sup>3)</sup>	PTFE <sup>4)</sup>
4	Single-ear clamp	-	-	1.4301
5	Shrink tubing at capillary junction	-	Polyolefin	-

1) If no option is specified when ordering, order option "SA" is supplied.

2) Product Configurator, order code for "Armor for capillary:" option "SA"

3) Product Configurator, order code for "Capillary armoring:" option "SB"

4) Product Configurator, order code for "Capillary armoring:" option "SC"

Materials in contact with the	NOTICE
process	<ul> <li>The wetted device of</li> </ul>

The wetted device components are listed in the "Mechanical construction" → 
 <sup>(1)</sup> 45 and "Ordering information" → 
 <sup>(1)</sup> 118 sections.

#### Delta-ferrite content

The delta- ferrite content of the wetted parts material can be guaranteed and certified to  $\leq 3\%$  if the option "KF" is chosen in the Product Configurator "Material of the process isolating diaphragm" ordering feature. When PMC51 with hygienic process connections is chosen, the deltaferrite content can be guaranteed and certified to  $\leq 1\%$  if the option "KF" is chosen in the Product Configurator "Material of the process isolating diaphragm" ordering feature.

### TSE Certificate of Suitability (Transmissible Spongiform Encephalopathy)

The following applies to all process wetted device components:

- They do not contain any materials derived from animals.
- No auxiliaries or operating materials derived from animals are used in production or processing.

#### Process connections

- "Clamp connections" and "Hygienic process connections" (see also "Ordering information" ordering feature): AISI 316L (DIN/EN material number 1.4435)
- Endress+Hauser supplies process connections with threaded connections and DIN/ EN flanges made of stainless steel as per AISI 316L (DIN/EN material number 1.4404 (AISI 316) or 14435). With regard to their stability-temperature property, the materials 1.4404 and 1.4435 are grouped together under 13E0 in EN 1092-1 Tab.18. The chemical composition of the two materials can be identical.
- Some process connections are also available in the material Alloy C276 (DIN/EN material number 2.4819). See the information in the "Mechanical construction" ordering feature.

#### Process isolating diaphragm

Туре	Designation	Option <sup>1)</sup>
PMC51	$Al_2O_3$ aluminum oxide ceramic (FDA $^{2)}$ , USP Class VI+121°C), ultrapure 99.9 % (see also www.endress.com/ceraphire)	Standard
PMP51	51 AISI 316L (DIN/EN material number 1.4435)	
	AISI 316L with gold-rhodium coating	М
	Alloy C276 (DIN/EN material number 2.4819)	В
PMP55	AISI 316L (DIN/EN material number 1.4435)	А
	AISI 316L, TempC	Е
	AISI 316L with gold-rhodium coating	М
	AISI 316L with 0.25 mm (0.01 in) PTFE coating	S
	Alloy C276 (DIN/EN material number 2.4819)	B <sup>3)</sup>
	Monel (2.4360)	C <sup>3)</sup>
	Tantal (UNS R05200)	D <sup>3)</sup>

1) Product Configurator, "Material of the process isolating diaphragm" ordering feature

2) The US Food & Drug Administration (FDA) has no objections to the use of ceramics made from aluminum oxide as a surface material in contact with foodstuffs. This declaration is based on the FDA certificates of our ceramic suppliers.

3) The flange raised face is made from the same material as the process isolating diaphragm.

## Seals

Туре	Designation	Option 1)
PMC51	FKM Viton	А
	FKM Viton, FDA, 3A Class I, USP Class VI	В
	FFKM Perlast G75LT	С
	NBR	F
	HNBR, FDA, 3A Class II, KTW, AFNOR, BAM	G
	NBR, Low temperature	Н
	EPDM, FDA	J
	EPDM, FDA, 3A Class II, USP Class VI+121°C, DVGW, KTW, W270, WRAS, ACS, NSF61	К
	FFKM Kalrez 6375	L
	FFKM Kalrez 7075	М
	FFKM Kalrez 6221, FDA, USP Class VI	N
	Fluoroprene XP40, FDA, USP Class VI+121°C, 3A Class I	Р
	VMQ Silicone, FDA	S

### 1) Product Configurator, "Seal" ordering feature

## Fill fluid

Designation	Option PMP51 <sup>1)</sup>
Silicone oil	1
Inert oil	2
NSF-H1 synthetik oil according to FDA 21 CFR 178.3570	3

1) Product Configurator, "Fill fluid" ordering feature

Designation	Option PMP55 <sup>1)</sup>
Silicone oil, suitable for foods FDA 21 CFR 175.105	1
Inert oil	2
Vegetable oil, Suitable for foods FDA 21 CFR 172.856	4
High-temperature oil	5
Low-temperature oil	6

1) Only select FDA-approved filling oils for diaphragm seal devices with 3-A and EHEDG certification!

## Operability

Operating concept	Operator-oriented menu structure for user-specific tasks
	<ul> <li>Commissioning</li> <li>Operation</li> <li>Diagnosis</li> <li>Expert level</li> </ul>
	Quick and safe commissioning
	Guided menus for applications
	Reliable operation
	<ul> <li>Local operation possible in several languages</li> <li>Standardized operation at the device and in the operating tools</li> <li>Parameters relating to measured values can be locked/unlocked using the device's write protection switch, using the device software or via remote control</li> </ul>
	Efficient diagnostic behavior increases measurement availability
	<ul><li>Remedial measures are integrated in plain text</li><li>Diverse simulation options</li></ul>
Local operation	Local display (optional) for devices with HART-, PROFIBUS PA- or FOUNDATION Fieldbus- Elektronik
	A 4-line liquid crystal display (LCD) is used for display and operation. The local display shows measured values, dialog texts as well as fault and notice messages in plain text, thereby supporting the user at every stage of operation. The liquid crystal display of the device can be turned in 90° stages. Depending on the orientation of the device, this makes it easy to operate the device and reac the measured values.
	<ul> <li>Functions</li> <li>8-digit measured value display including sign and decimal point, bar graph for 4 to 20 mA HART as current display; or for PROFIBUS PA as graphic display of the standardized value of the AI Block; for FOUNDATION Fieldbus as graphic display of the transducer output in relation to the ser pressure range.</li> <li>Simple and complete menu guidance as parameters are split into several levels and groups</li> <li>Each parameter is given a 3-digit ID number for easy navigation</li> <li>Possibility of configuring the display to suit individual requirements and preferences, such as language, alternating display, contrast setting, display of other measured values such as sensor temperature etc.</li> <li>Comprehensive diagnostic functions (fault and warning message, peak-hold indicators etc.)</li> </ul>
	Overview
	$ \begin{array}{c c} \hline & & & & & & & & & & & & & & & & & & &$

- Operating keys Bar graph Symbol Header line
- 1 2 3 4 5

- Parameter identification number

Function	Operation via disp	lay		
	Analog electronic	HART	PROFIBUS PA	FOUNDATION Fieldbus
Position adjustment (zero point correction)	_	r	V	V
Setting lower range value and upper range value - reference pressure present at the device	_	V	V	V
Device reset	-	r	V	<i>v</i>
Locking and unlocking parameters relevant to the measured value	_	r	V	V
Value acceptance indicated by the green LED	_	_	_	_
Switching damping on and off	-	r	~	V

### Ordering information: Product Configurator, "Output, Operation" ordering feature

## Local display (optional) for devices with analog electronics

A 4-line liquid crystal display (LCD) is used. The local display shows measured values, fault messages and notice messages. The liquid crystal display of the device can be turned in 90° stages. Depending on the orientation of the device, this makes it easy to operate the device and read the measured values.

## Functions:

- 8-digit measured value display including sign and decimal point, bar graph for 4 to 20 mA as current display.
- Diagnostic functions (fault and warning message etc.)

#### Overview



- 1 Bar graph
- 2 Symbol
- 3 Parameter name

Ordering information: Product Configurator, "Display, operation" ordering feature

#### Operating keys and elements located inside on the electronic insert

Function	Operation with oper	rating ke	eys and element	s on the electronic insert
	Analog electronics	HART	PROFIBUS PA	FOUNDATION Fieldbus
Position adjustment (zero point correction)	V	V	V	٧
Setting lower range value and upper range value - reference pressure present at the device	V	r	_	_
Device reset	r	r	V	٧
Locking and unlocking parameters relevant to the measured value	-	r	V	٧
Value acceptance indicated by the green LED	r	r	V	٧
Switching damping on and off	V	v	~	V

#### Ordering information:

Product Configurator, "Output, Operation" ordering feature

#### Analog



- 1 Operating keys for lower range value (zero), upper range value (span), position zero adjustment or reset
- 2 Green LED to indicate successful operation
- 3 Slot for optional local display
- 4 DIP switch for switching damping on/off

#### HART



- 1 Operating keys for lower range value (zero) and upper range value (span)
- 2 Green LED to indicate successful operation
- 3 Slot for optional local display
- 4 DIP switch only for Deltabar M
- 5 DIP switch only for Deltabar M
- 6 DIP switch for alarm current SW / Alarm Min (3.6 mA)
- 7 DIP switch for switching damping on/off
- 8 DIP switch for locking/unlocking parameters relevant to the measured value

## PROFIBUS PA



- 1 Green LED to indicate successful operation
- 2 Operating key for position zero adjustment (Zero) or reset
- 3 Slot for optional local display
- 4 DIP-switch for bus address SW / HW
- 5 DIP-switch for hardware address
- 6 DIP switch only for Deltabar M
- 7 DIP switch only for Deltabar M
- 8 Not used
- 9 DIP switch for switching damping on/off
- 10 DIP switch for locking/unlocking parameters relevant to the measured value

## FOUNDATION Fieldbus



- 1 Operating key for position zero adjustment (Zero) or reset
- 2 Green LED to indicate successful operation
- 3 Slot for optional local display
- 4 DIP switch only for Deltabar M
- 5 DIP switch only for Deltabar M
- 6 DIP-switch for simulation mode
- 7 DIP switch for switching damping on/off
- 8 DIP switch for locking/unlocking parameters relevant to the measured value

### **Operating languages**

You can also choose another language in addition to the standard language "English":

Designation	Option <sup>1)</sup>
English	AA
German	AB
French	AC
Spanish	AD
Italian	AE
Dutch	AF

Designation	Option <sup>1)</sup>
Chinese	AK
Japanese	AL

#### 1) Product Configurator "Additional Operation Language" ordering feature

#### **Remote operation**

All software parameters are accessible depending on the position of the write protection switch on the device.

Hardware and software for remote operation	HART	PROFIBUS PA	FOUNDATION Fieldbus
FieldCare $\rightarrow \square$ 105	✓ <sup>1)</sup>	✓ <sup>2)</sup>	V
FieldXpert SFX100 $\rightarrow \triangleq 105$	v	-	V
NI-FBUS Configurator $\rightarrow \square$ 106	_	_	V

1) Commubox FXA195 required

2) Profiboard or Proficard required

#### FieldCare

FieldCare is an Endress+Hauser asset management tool based on FDT technology. With FieldCare, you can configure all Endress+Hauser devices as well as devices from other manufacturers that support the FDT standard.

FieldCare supports the following functions:

- Configuration of transmitters in offline and online mode
- Loading and saving device data (upload/download)
- Documentation of the measuring point

Connection options:

- HART via Commubox FXA195 and USB interface of a computer
- PROFIBUS PA via segment coupler and PROFIBUS interface card
- Service interface with Commubox FXA291 and ToF adapter FXA291 (USB).

For further information, please contact your local Endress+Hauser Sales Center.

#### Field Xpert SFX100

Field Xpert is an industrial PDA with integrated 3.5" touchscreen from Endress+Hauser based on Windows Mobile. It offers wireless communication via the optional VIATOR Bluetooth modem from Endress+Hauser. Field Xpert also works as a stand-alone device for asset management applications. For details refer to BA00060S/04/EN.

#### **Commubox FXA195**

For intrinsically safe HART communication with FieldCare via the USB interface. For details refer to TI00404F/00/EN.

#### Commubox FXA291

The Commubox FXA291 connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) to the USB interface of a personal computer or laptop. For details refer to TI00405C/07/EN.

For the following Endress+Hauser devices you will need the "ToF Adapter FXA291" as an additional accessory:

- Cerabar M
- Deltabar M
- Deltapilot M

#### ToF Adapter FXA291

The ToF adapter FXA291 connects the Commubox FXA291 with devices of the ToF platform, pressure equipment and Gammapilot via the USB interface of a personal computer or a notebook. For details refer to KA00271F.

#### Profiboard

For connecting a PC to the PROFIBUS.

## Proficard

For connecting a laptop to the PROFIBUS.

#### FF configuration program

FF configuration program, such as NI-FBUS Configurator, to

- connect devices with "FOUNDATION Fieldbus signal" into an FF-network
- set FF-specific parameters

#### Operation with NI-FBUS Configurator:

The NI-FBUS Configurator is an easy-to-use graphical environment for creating linkages, loops, and a schedule based on the fieldbus concepts.

You can use the NI-FBUS Configurator to configure a fieldbus network as follows:

- Set block and device tags
- Set device addresses
- Create and edit function block control strategies (function block applications)
- Configure vendor-defined function and transducer blocks
- Create and edit schedules
- Reading and writing of data from control and regulation systems
- Invoke methods specified in the manufacturer-specific DD (e.g. basic device settings)
- Display DD menus (e.g. tab for calibration data)
- Download a configuration
- Verify a configuration and compare it to a saved configuration
- Monitor a downloaded configuration
- Replace a virtual device by a real device
- Save and print a configuration

## System integration (Except analog electronics)

#### The device can be given a tag name (max. 8 alphanumeric characters)

Designation	Option <sup>1)</sup>
Tagging (TAG), see aditional spec.	Z1
Bus address, see aditional spec.	Z2

1) Product configurator "Marking" ordering feature

## Planning instructions for diaphragm seal systems

## NOTICE

## Diaphragm seal systems sized/ordered incorrectly

The performance and the permitted range of application of a diaphragm seal system depend on the process isolating diaphragm used, the filling oil, the coupling, the unit design and on the specific process and ambient conditions present in the individual application.

To help you select the right diaphragm seal systems for your particular applications, Endress
 +Hauser provides its customers with the "Applicator Sizing Diaphragm Seal" selection tool, which is available free of charge at "www.endress.com/applicator" or as a download.

Home > Sizing - Pressure												Help Cor
Sizing Diaphr	agm Seal	1								Dimensi	oning pressure de	evices
Chart Sizing Chart	Extended 0	Order code										
General paramet	ers											
Product 1		Cerabar S PN	(P75		$\sim$							
TAG						Order code	PMP75-1H6	183			<b>\$</b>	
											db	
1 Message(s												
Transmitter data							Measurement accuracy and of	ffset ()				~
		1bar/100kPa/15psi gauge 14.504		unit					% span /SOF	~	psi/SOF	~
Sensor 1				~			Error due to change in process temperature		0.133		0.019	
Adjusted span 👔					psi	$\sim$	Error due to change in ambient temperature 🕕		0.202	0.202 0.029		
Membrane materia	d 🕕	316L		~								
Process connection	dasses	All		~			Calibration offset					
Diaphragm seal 💷		DN50 PN10-40	0 61, 316L	$\sim$			Maximum offset after	minimum	nominal	maximum	unit	
Transmitter mount	ing 🕕	direct		~			installation	-0.1	0	0.1	psi	~
Fill fluid 🕕		Silicone oli		~				-0.4	0	0.6	Nispan	$\sim$
Process and amb	ient conditio						Performance data	minimum	nominal	maximum	unit	
		minimum 14	nominal	maximum 212	unit 'F	~	Response time Tau (T63)	0.2	0.2	0.2	3	
Process temperatur		14	77	212	r Tr	~	Diaphragm deflection ()	-23	0	15	6	
Static pressure (ab		14	14.504	29.008	psi							
static pressure (ab	u 🕕	15.055	14.504	29.008	pai							

Applications

your local Endress+Hauser Sales Center.

For further details, or for information on an optimum diaphragm seal solution, please contact

Diaphragm seal systems should be used if the process and the device need to be separated.

- Diaphragm seal systems offer clear advantages in the following instances:
- In the case of extreme process temperatures
- For aggressive media
- If extreme measuring point cleaning is necessary, or in the event of very damp mounting locations
- If the measuring point is exposed to severe vibrations
- For mounting locations that are difficult to access

#### Function and design

Diaphragm seals separate the measuring system from the process.

- A diaphragm seal system consists of:
- A diaphragm seal
- A capillary tube or a temperature isolator if necessary
- Fill fluid and
- a pressure transmitter.

The process pressure acts via the process isolating diaphragm of a diaphragm seal on the liquid-filled system, which transfers the process pressure to the sensor of the pressure transmitter.

Endress+Hauser delivers all diaphragm seal systems as welded versions. The system is hermetically sealed, which ensures greater reliability.

The diaphragm seal determines the application range of the system on the basis of

- The diameter of the process isolating diaphragm
- The process isolating diaphragm: stiffness and material
- The design (oil volume)

#### Diameter of the process isolating diaphragm

The greater the diameter of the process isolating diaphragm (less stiff), the smaller the temperature effect on the measurement result.

#### Stiffness of the process isolating diaphragm

The stiffness depends on the diameter of the process isolating diaphragm, the material, any existing coating, the thickness and shape of the process isolating diaphragm. The thickness of the process isolating diaphragm and the shape are determined by the design. The stiffness of a process isolating diaphragm of a diaphragm seal influences the temperature application range and the measuring error caused by temperature effects.

## The Endress+Hauser TempC membrane: Highest accuracy and process safety when measuring pressure and differential pressure using diaphragm seals

To measure with even greater accuracy in these applications and increase process safety, Endress +Hauser has developed the TempC diaphragm which is based on a completely revolutionary technology. This diaphragm guarantees the utmost level of accuracy and process safety in diaphragm seal applications.

- The very low temperature effect minimizes the effect of process and ambient temperature fluctuations, thereby guaranteeing accurate and reliable measurements. Measurement inaccuracies caused by temperature are reduced to a minimum.
- The TempC membrane can be used at temperatures between -70 °C (-94 °F) and +400 °C (+752 °F). This guarantees maximum process safety even for very long sterilization and cleaning cycles (SIP/CIP) in tanks and pipes at high temperatures.
- With a smaller process connection, the new diaphragm measures at least as accurately as a conventional diaphragm with a larger diameter. With a smaller process connection, the new membrane measures at least as accurately as a conventional membrane with a larger diameter.
- Due to the geometry of the membrane, an overshoot occurs initially immediately following a temperature shock. This results in a transient response, the duration and deviation of which are significantly less compared to traditional membrane types. In the case of batch processes, these shorter recovery times mean a far higher level of availability of the production facilities. For TempC membranes, the effect of the overshoot on the output signal can be reduced by adjusting the damping.
- In addition, TempC Membrane convinces customers by its better hygiene cleanability as well as insensitivity to strong pressure load changes.

#### Ordering information:

See the Product Configurator for the individual process connection and the choice of process isolating diaphragm.

Selection in the Applicator:

Under "Transmitter data" in the "Membrane material" field.

#### Capillary

As standard, capillaries with an internal diameter of 1 mm (0.04 in) are used.

The capillary tube influences the thermal change, the ambient temperature operating range and the response time of a diaphragm seal system as a result of its length and internal diameter.
## Filling oil

Observe the temperatures and pressures during commissioning and cleaning. A further selection criterion is the compatibility of the filling oil with the requirements of the medium. For example, only filling oils that do not present a health hazard are used in the food industry, e.g. vegetable oil or silicone oil. (See also the following section "Diaphragm seal filling oils".)

The filling oil used influences the thermal change, the temperature application range of a diaphragm seal system and the response time. A temperature change results in a volume change in the filling oil. The volume change depends on the thermal expansion coefficient of the filling oil and on the volume of the fill fluid at calibration temperature (constant in the range: +21 to +33 °C (+70 to +91 °F)).

For example, the filling oil expands in the event of a temperature increase. The additional volume presses against the process isolating diaphragm of a diaphragm seal. The stiffer a process isolating diaphragm is, the greater its return force, which counteracts a volume change and acts together with the process pressure on the measuring cell, thus shifting the zero point.

## Pressure transmitter

The pressure transmitter influences the temperature application range, the thermal change and the response time as a result of its volume change. The volume change is the volume that has to be shifted in order to pass through the complete measuring range.

Pressure transmitters from Endress+Hauser are optimized with regard to minimum volume change.

### Diaphragm seal filling oils

Filling oil	Permissible temperature range <sup>1)</sup> at 0.05 bar (0.725 psi) $\leq p_{abs} \leq 1$ bar (14.5 psi)	Permitted temperature range $^{1)}$ at $p_{abs} \ge 1$ bar (14.5 psi)	Option <sup>2)</sup>
Silicone oil	-40 to +180 °C (-40 to +356 °F)	-40 to +250 °C (-40 to +482 °F)	1
Inert oil	-40 to +80 °C (-40 to +176 °F)	-40 to +175 °C (-40 to +347 °F)	2
Vegetable oil	-10 to +120 °C (+14 to +248 °F)	-10 to +200 °C (+14 to +392 °F)	4
Hightemperature oil	−10 to +200 °C (+14 to +392 °F)	-10 to +400 °C (+14 to +752 °F) <sup>3) 4) 5)</sup>	5
Low temperature oil	-70 to +80 °C (-94 to +176 °F)	−70 to +180 °C (−94 to +356 °F)	6

1) Observe temperature limits of the device and of the system

2) Product Configurator, "Fill fluid" ordering feature

3) 325 °C (617 °F) at  $\geq$ 1 bar (14.5 psi)absolute pressure.

4)  $350 \degree C (662 \degree F)$  at  $\geq 1$  bar (14.5 psi) absolute pressure (max. 200 hours).

5) 400 °C (752 °F) at  $\geq$ 1 bar (14.5 psi) absolute pressure (max. 10 hours).

## Additional data:

Filling oil	Density [g/cm3] / [SGU]	Viscosity [mm²/s] / [cSt] bei 25 °C (77 °F)	Expansion coefficient <sup>1)</sup> [1/K]	Notes <sup>2)</sup>	Option <sup>3)</sup>
Silicone oil	0.96	100	0.00096	suitable for foods FDA 21 CFR 175.105	1
Inert oil	1.87	27	0.000876	For ultrapure gas and oxygen applications	2
Vegetable oil	0.94	9.5	0.00101	suitable for foods FDA 21 CFR 172.856	4
Hightemperature oil	1.00	150	0.00096	High temperatures	5
Low temperature oil	0.92	4.4	0.00108	Low temperatures	6

1) The thermal change in the diaphragm seal and other important technical features can be found in the "Applicator Sizing Diaphragm Seal" selection tool.

2) Only select FDA-approved filling oils for diaphragm seal devices with 3-A and EHEDG certification!

3) Product Configurator, "Fill fluid" ordering feature

**Operating temperature range** The operating temperature range of a diaphragm seal system depends on the fill fluid, capillary length and internal diameter, process temperature and oil volume of the diaphragm seal.

	The range of application can be extended by using a fill fluid with a smaller expansion coefficient and a shorter capillary.
Cleaning instructions	Endress+Hauser offer flushing rings as accessories to clean process isolating diaphragms without taking the transmitters out of the process.
	For further information please contact your local Endress+Hauser Sales Center.
	We recommend you perform CIP (cleaning in place (hot water)) before SIP (sterilization in place (steam)) for pipe diaphragm seals. A frequent use of sterilization in place (SIP) will increase the stress on the process isolating diaphragm. Under unfavorable circumstances in the long term view we cannot exclude that a frequent temperature change could lead to a material fatigue of the process isolating diaphragm and possibly to a leakage.
Installation instructions	Diaphragm seal systems
	<ul> <li>A diaphragm seal together with the transmitter form a closed, calibrated system, which is filled through openings in the diaphragm seal and in the transmitter's measurement system. These openings are sealed and must not be opened.</li> <li>In the case of devices with diaphragm seals and capillaries, the zero point shift caused by the hydrostatic pressure of the filling liquid column in the capillaries must be taken into account when selecting the measuring cell. If a measuring cell with a small measuring range is selected, a position adjustment can cause range violation.</li> <li>For devices with a temperature isolator or capillary, a suitable fastening device (mounting bracket) is recommended.</li> <li>When mounting, sufficient strain relief must be provided for the capillary line to prevent the capillary from bending (capillary bending radius ≥ 100 mm (3.94 in)</li> </ul>
	Capillary
	<ul> <li>In order to obtain more precise measurement results and to avoid a defect in the device, mount the capillaries as follows:</li> <li>Vibration-free (in order to avoid additional pressure fluctuations)</li> <li>Not in the vicinity of heating or cooling lines</li> <li>Insulate if the ambient temperature is below or above the reference temperature</li> <li>With a bending radius of ≥ 100 mm (3.94 in)</li> </ul>
	Thermal insulation
	The PMP55 may only be insulated up to a certain height. The maximum permitted insulation height is indicated on the devices and applies to an insulation material with a heat conductivity $\leq 0.04 \text{ W}/(\text{m x K})$ and to the maximum permitted ambient and process temperature. The data were determined under the most critical application "quiescent air". Maximum permitted insulation height, here indicated on a PMP55 with a flange:

- Α
- Ambient temperature  $\leq$  70 °C (158 °F) Process temperature max. 400 °C (752 °F), depending on the diaphragm seal filling oil used Maximum permitted insulation height Insulation material В

4

1

1

В

1

- 1
- 2

A0020474

## Mounting with temperature isolator

Endress+Hauser recommends the use of temperature isolators in the event of constant extreme medium temperatures which lead to the maximum permissible electronics temperature of +85 °C (+185 °F) being exceeded. Depending on the filling oil used, diaphragm seal systems with temperature isolators can be used for maximum temperatures of up to +400 °C (+752 °F)  $\rightarrow \implies$  109, "Diaphragm seal filling oils" section. To minimize the influence of rising heat, Endress+Hauser recommends the device be mounted horizontally or with the housing pointing downwards. The additional installation height also brings about a maximum zero point shift of 21 mbar (0.315 psi) due to the hydrostatic column in the temperature isolator. You can correct this zero point shift at the device.



1 Transmitter

Position	Insulation	Ambient temperature (T <sub>a</sub> ) at transmitter	Maximum process temperature (T <sub>p</sub> )
A	No insulation	60 ℃ (140 ℉)	400 °C (752 °F) <sup>1)</sup>
		85 °C (185 °F)	200 °C (392 °F)
В	30 mm (1.18 in) Insulation	80 °C (176 °F)	400 °C (752 °F)
		85 °C (185 °F)	300 ℃ (572 °F)
С	Maximum insulation	67 ℃ (153 ℉)	400 °C (752 °F)
		85 °C (185 °F)	200 °C (392 °F)

1) Process temperature: max.400 °C (752 °F), depending on the diaphragm seal filling oil used

## Vacuum applications

## Mounting instructions

For vacuum applications, pressure transmitters with a ceramic measuring membrane (oil-free) are preferable.

For applications under vacuum, Endress+Hauser recommends mounting the pressure transmitter below the diaphragm seal. This prevents vacuum loading of the diaphragm seal caused by the presence of fill fluid in the capillary.

When the pressure transmitter is mounted above the diaphragm seal, the maximum height difference H1 in accordance with the illustrations below must not be exceeded. The following diagram depicts installation above the lower diaphragm seal:



The maximum height difference depends on the density of the filling oil and the smallest ever pressure that is permitted to occur at the diaphragm seal (empty vessel), see illustration below. The following diagram depicts the maximum installation height above the diaphragm seal for vacuum applications.



- A Height difference H1
- *B Pressure at diaphragm seal*
- 1 Low temperature oil
- 2 Vegetable oil
- 3 Silicone oil
- 4 High-temperature oil
- 5 Inert oil

# Certificates and approvals

CE mark	The device meets the legal requirements of the relevant EC directives. Endress+Hauser confirms that the device has been successfully tested by applying the CE mark.
RoHS	The measuring system complies with the substance restrictions of the Restriction on Hazardous Substances Directive 2011/65/EU (RoHS 2).
RCM-Tick marking	The supplied product or measuring system meets the ACMA (Australian Communications and Media Authority) requirements for network integrity, interoperability, performance characteristics as well as health and safety regulations. Here, especially the regulatory arrangements for electromagnetic compatibility are met. The products are labelled with the RCM- Tick marking on the name plate.
	A0029561
Ex approvals	<ul> <li>ATEX</li> <li>IECEx</li> <li>FM</li> <li>CSA</li> <li>NEPSI</li> <li>Also combinations of different approvals</li> </ul>
	All explosion protection data are given in separate documentation which is available upon request. The Ex documentation is supplied as standard with all devices approved for use in explosion hazardous areas $\rightarrow \cong 122$ .
EAC conformity	The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity together with the standards applied.
	Endress+Hauser confirms successful testing of the device by affixing to it the EAC mark.
Suitable for hygiene applications	The device is available with hygienic process connections (overview: see order code). The materials of the hygienic process connections in contact with food comply with Regulation (EC) 1935/2004.
	<ul> <li>CAUTION</li> <li>Contamination in the process!</li> <li>Risk of contamination if incorrect seals and parts are used!</li> <li>To avoid the risk of contamination, when installing the device comply with the design principles of EHEDG, Guideline 37 "Hygienic Design and Application of Sensors" and Guideline 16 "Hygienic Pipe Couplings".</li> <li>Suitable assemblies and seals must be used to ensure hygienic design in accordance with 3-A SSI and EHEDG specifications.</li> <li>The leak-proof connections can be cleaned with the cleaning methods typical of this industry (CIP and SIP). Attention must be paid to the pressure and temperature specifications of the sensor and process connections for CIP and SIP processes (clean in place/sterilize in place).</li> <li>Only select FDA-approved filling oils for diaphragm seal devices with 3-A and EHEDG certification!</li> </ul>



The gap-free connections can be cleaned of all residue using the typical cleaning methods within this industry.

Certificate of Compliance	Ordering information:			
ASME BPE 2012	Product Configurator, "Additional approval" ordering feature, option "LW"			
Functional safety SIL	The Cerabar M with 4 to 20 mA output signal has been developed to assessed and certified by TÜV NORD CERT as per IEC 61508 Edition 2.0 and IEC 61511. These devices can be used to monitor the process level and pressure up to SIL 2. For a detailed description of the safety functions with Cerabar M, settings and functional safety data, see the "Functional safety manual - Cerabar M" SD00347P.			
	Ordering information:			
	Product Configurator, "Additional approval" ordering feature, option "LA"			
CRN approvals	Some device versions have CRN approval. A CRN-approved process connection with a CSA approval must be ordered for a CRN-approved device.PMP55 devices with a capillary are not CRN-approved.These devices are fitted with a separate plate bearing the registration number0F10525.5C			
	Ordering information:			
	Product Configurator, "Process connection" section and			
	Product Configurator, "Approval" ordering feature			
Other standards and guidelines	The applicable European guidelines and standards can be found in the relevant EU Declarations of Conformity. The following were also applied:			
	DIN EN 60770 (IEC 60770):			
	Transmitters for use in industrial-process control systems Part 1: Methods for inspection and routine testing			
	DIN 16086:			
	Electrical pressure measuring instruments, pressure sensors, pressure transmitters, pressure measuring instruments, concepts, specifications in data sheets			
	EN 61326-Serie:			
	EMC product family standard for electrical equipment for measurement, control and laboratory use.			
	EN 60529:			
	Degrees of protection by housing (IP code)			
AD2000	The pressure retaining material 316L (1.4435/1.4404) corresponds to AD2000 - W2/W10.			
Pressure Equipment	Pressure equipment with allowable pressure ≤ 200 bar (2 900 psi)			
Directive 2014/68/EU (PED)	Pressure equipment (having a maximum allowable pressure PS $\leq$ 200 bar (2900 psi)) can be classified as pressurized equipment in accordance with Pressure Equipment Directive 2014/68/EU. If the maximum allowable pressure is $\leq$ 200 bar (2900 psi) and the pressurized volume of the pressure equipment is $\leq$ 0.1 l, the pressure equipment is subject to the Pressure Equipment Directive (cf. Pressure Equipment Directive 2014/68/EU, Article 4, point 3). The Pressure Equipment Directive only requires that the pressure equipment shall be designed and manufactured in accordance with the "sound engineering practice of a Member State".			

## Reasons:

- Pressure Equipment Directive (PED) 2014/68/EU Article 4, point 3
- Pressure equipment directive 2014/68/EU, Commission's Working Group "Pressure", Guideline A-05 + A-06

## Note:

A partial examination shall be performed for pressure instruments that are part of safety equipment for the protection of a pipe or vessel from exceeding allowable limits (equipment with safety function in accordance with Pressure Equipment Directive 2014/68/EU, Article 2, point 4).

## Pressure equipment with allowable pressure > 200 bar (2900 psi)

Pressure equipment designated for application in every process fluid having a pressurized volume of < 0,1 l and a max. allowable pressure PS > 200 bar (2 900 psi)shall satisfy the essential safety requirements set out in Annex I of the Pressure Equipment Directive 2014/68/EU. According to Article 13 pressure equipment shall be classified by category in accordance with Annex II. The conformity assessment of the pressure equipment shall be determined by the category I underconsideration of the above-mentioned low pressurized volume. These devices shall be provided with CE marking.

Reasons:

- Pressure Equipment Directive 2014/68/EU, Article 13, Annex II
- Pressure equipment directive 2014/68/EU, Commission's Working Group "Pressure", Guideline A-05

## Note:

	A partial examination shall be performed for pressure instruments that are part of safety equipment for the protection of a pipe or vessel from exceeding allowable limits (equipment with safety function in accordance with Pressure Equipment Directive 2014/68/EU, Article 2, point 4).
	The following also applies:
	<ul> <li>PMP51 /PMP55with threaded connection and internal process isolating diaphragm PN &gt; 200: Suitable for stable gases in group 1, category I, module A</li> <li>PMP55 with pipe diaphragm seal ≥ 1.5"/PN40: Suitable for stable gases in group 1, category II, module A2</li> <li>PMP55 with separators PN400: Suitable for stable gases in group 1, category I, module A</li> </ul>
Manufacturer declaration	<ul> <li>Depending on the desired configuration, the following documents can be ordered additionally with the device:</li> <li>FDA conformity</li> <li>TSE-free, materials free from animal origin</li> <li>Regulation EC 2023/ 2006 (GMP)</li> <li>Regulation (EC) No. 1935/2004 on materials intended to come into contact with food</li> </ul>

## Downloading the Declaration of Conformity

http://www.endress.com/en/download

Downloads
Search and download operating manuals, brochures, publications, software updates, videos, certificates and a whole host of other documents! $2$
Media Type Approvals & Certificates Manufact. Declaration V
Product Code 3
Text Search
Advanced Search Reset Search 4
A00317

- 1. Select "Approvals & Certificates"
- 2. Select "Manufact. Declaration"
- 3. Enter the required product code
- 4. Click "Search"

The available downloads are displayed.

Marine approval	Designation		Opt	ion <sup>1)</sup>			
	GL (Germanischer Lloyd)			LE			
	ABS (American Bureau of Shipping)		LF	LF			
	LR (Lloyd's Register )			LG			
	BV (Bureau Veritas)			LH			
	DNV (Det Norske Veritas)		LI	LI			
	1) Product Configurator, "Additional approval" ordering feature						
Drinking water approval	NSF 61 - approval forPMC51 and PMP51						
	UBA / W270 - approval for PMC51 and PMP51						
	Ordering information:						
	Product Configurator, "Additional approval" ordering feature, option "LR"						
Classification of process sealing between electrical systems and (flammable or combustible) process fluids in accordance with ANSI/ ISA 12.27.01	<ul> <li>Endress+Hauser instruments are designed according to ANSI/ISA 12.27.01 either as single seal or dual seal devices with annunciation, allowing the user to waive the use and save the cost of installin external secondary process seals in the conduit as required by the process sealing sections of ANSI/NFPA 70 (NEC) and CSA 22.1 (CEC). These instruments comply with the North-American installation practice and provide a very safe and cost-saving installation for pressurized applications with hazardous fluids.</li> <li>Further information can be found in the control drawings of the relevant devices.</li> </ul>				installin f ANSI/		
Inspection certificate	Designation	PMC51	PMP51	PMP55	Option 1)		
	3.1 Material certificate, wetted metallic parts, EN10204-3.1 inspection certificate	r	v	v	JA <sup>2)</sup>		
	Conformity to NACE MR0175, wetted metallic parts	V	v				
	comornity to trace whom y, wetter metallic parts			~	JB <sup>2)</sup>		
	Conformity to NACE MR0103, wetted metallic parts	~	r	v v	JB <sup>2)</sup> JE <sup>2)</sup>		
		<ul> <li>✓</li> <li>−</li> </ul>	v v		5		
	Conformity to NACE MR0103, wetted metallic parts Conformity to AD2000, wetted metallic parts, excepting process	-	-	V	JE <sup>2)</sup>		

Designation	PMC51	PMP51	PMP55	Option 1)
Pressure test, internal procedure, inspection certificate	r	r	r	KE
3.1 Material certificate+Delta-Ferrit measurement, internal procedure, wetted metallic parts, EN10204-3.1 inspection certificate	v	V	V	KF
3.1 Material certificate+PMI test (XRF), internal procedure, wetted metallic parts, EN10204-3.1 inspection certificate	-	V	V	KG
Welding documentation, wetted/pressurized seams	-	V	-	KS

1)

Product Configurator, "Test, certificate" ordering feature The selection of this feature for coated process isolating diaphragm / process connections refers to the 2) metallic base material.

Calibration; unit	Designation	Option <sup>1)</sup>
	Sensor range; %	А
	Sensor range; mbar/bar	В
	Sensor range; kPa/MPa	С
	Sensor range; mm/mH2O	D
	Sensor range; inH2O/ftH2O	E
	Sensor range; psi	F
	Customized pressure; see additional specification	J
	Customized level; see additional specification	К

Product Configurator, "Calibration; unit" ordering feature 1)

Calibration

Designation	Option <sup>1)</sup>
Factory calib. certificate 5-point	F1
DKD/DAkkS calib. certificate 10-point <sup>2)</sup>	F2

1) Product Configurator "Calibration" ordering feature

2)

Service

Designation	Option <sup>1)</sup>
Cleaned from oil+grease <sup>2)</sup>	HA
Cleaned for oxygen service <sup>2)</sup>	НВ
Cleaned from PWIS (PWIS = paint wetting impairment substances) <sup>2)</sup>	НС
Adjusted min alarm current	IA
Adjusted HART Burst Mode PV	IB

1) Product Configurator "Service" ordering feature

2) Only device, not accessory or enclosed accessory

## **Ordering information**

Detailed ordering information is available as follows:

- In the Product Configurator on the Endress+Hauser website:www.endress.com → Click "Corporate" → Select your country → Click "Products" → Select the product using the filters and search field → Open product page → The "Configure" button to the right of the product image opens the Product Configurator.
- From your Endress+Hauser Sales Center:www.addresses.endress.com
- Product Configurator the tool for individual product configuration
- Up-to-the-minute configuration data
  - Depending on the device: direct input of information specific to the measuring point, such as measuring range or operating language
  - Automatic verification of exclusion criteria
  - Automatic generation of the order code with its breakdown in PDF or Excel output format
  - Ability to order directly in the Endress+Hauser Online Shop

Scope of delivery

- Device
  - Optional accessories
  - Brief Operating Instruction
  - Calibration certificates
  - Optional certificates

#### Measuring point (TAG) Ordering feature 895: Marking Option Z1: Tagging (TAG), see additional spec. Position of the measuring To be selected in the additional specifications: point marking Tag plate Stainless Steel • Self-adhesive paper label Supplied label/plate RFID TAG RFID TAG + Tag plate Stainless Steel RFID TAG + Self-adhesive paper label RFID TAG + Supplied label/plate Definition of the measuring To be defined in the additional specifications: point designation 3 lines containing up to 18 characters each The measuring point designation appears on the selected label and/or the RFID TAG. Identification on electronic 32 characters nameplate (ENP) Identification on display 10 characters module

Configuration data sheet (HART, PROFIBUS PA, FOUNDATION Fieldbus electronics)

## Pressure

If the option "J" was selected in the "Calibration; Unit" ordering feature of the Product Configurator, the following configuration data sheet must be completed and included with the order.

Pressure Engineering Unit				
<ul><li>mbar</li><li>bar</li><li>psi</li></ul>	$\begin{array}{c c} mmH_2O\\ mH_2O\\ ftH_2O\\ nH_2O\\ nH_2O\end{array}$	<ul> <li>mmHg</li> <li>kgf/cm<sup>2</sup></li> </ul>	<ul><li>Pa</li><li>kPa</li><li>MPa</li></ul>	

## Calibration Range / Output

Low range value (LRV): Upper range value (URV):

- \_\_\_\_\_
- [Pressure engineering unit] [Pressure engineering unit]

Display Information	
1st Value Display <sup>1)</sup>	2nd Value Display <sup>1)</sup>
Main Value	none (Default) Main Value [%] Pressure Current [mA] (HART only) Temperature

1) (Depending on sensor and comunication variant)

Damping	
Damping	 sec (Default 2 sec)

Smallest span (factory calibration)  $\rightarrow \square 14$ 

#### Level

If the option "K" was selected in the "Kalibration; Einheit" ordering feature of the Product Configurator, the following configuration data sheet must be completed and included with the order.



Display Information		
1st Value Display <sup>1)</sup>	2nd Value Display	
Main Value	none (Default)	
	Main Value [%]	
	Pressure	
	Current [mA] (HART only)	
	Temperature	
	-	

1) (Depending on sensor and comunication variant)

Damping:

sec (Default 2 sec)

Configuration data sheet (Analog electronics)

## Pressure

1)

If the option "J" was selected in the "Kalibration; Einheit" ordering feature of the Product Configurator, the following configuration data sheet must be completed and included with the order.

Pressure Engin	eering Unit			
□ mbar □ bar □ psi	$\begin{array}{c c} & mmH_2O\\ \hline & mH_2O\\ \hline & ftH_2O\\ \hline & inH_2O \end{array}$	□ mmHg □ kgf/cm <sup>2</sup>	<ul> <li>Pa</li> <li>kPa</li> <li>MPa</li> </ul>	

Calibration Range / Output		
Low range value (LRV): Upper range value (URV):	 [Pressure engineering unit] [Pressure engineering unit]	

Display Information	
1st Value Display <sup>1)</sup>	2st Value Display none (Default)
Depending on sensor and comunication variant	

Damping	
Damping:	 sec (Default 2 sec)

Smallest span (factory calibration)  $\rightarrow$  🗎 14

Field of Activities	Pressure measurement, powerful instruments for process pressure, differential pressure, level and flow:				
	FA00004P/00/EN				
Technical Information	<ul> <li>Deltabar M: TI00434P/00/EN</li> <li>Deltapilot M: TI00437P/00/EN</li> <li>EMC test procedures: TI00241F/00/EN</li> <li>Weld-in adapter, adapter and flanges: TI00426F/00/EN</li> </ul>				
Special Documentation	Mechanical accessories for pressure measuring devices: SD01553P/00/EN				
Operating Instructions	<ul> <li>420 mA Analog: BA00385P/00/EN</li> <li>420 mA HART: BA00382P/00/EN</li> <li>PROFIBUS PA: BA00383P/00/EN</li> <li>FOUNDATION Fieldbus: BA00384P/00/EN</li> </ul>				
Brief operating instruction	<ul> <li>420 mA Analog: KA01036P/00/EN</li> <li>420 mA HART: KA01030P/00/EN</li> <li>PROFIBUS PA: KA01031P/00/EN</li> <li>FOUNDATION Fieldbus: KA01032P/00/EN</li> </ul>				
Functional safety manual (SIL)	Cerabar M (420 mA): SD00347P/00/EN				

## Additional documentation

## Safety Instructions

Directive	Approval	Category	Туре	Hous	sing	Electronics	Documentation	Option <sup>1)</sup>
				F31	F15	-		
ATEX	Ex ia IIC	II 1/2 G	PMC51 PMP51 PMP55	r	r	420 mA HART	XA00464P/00	BA
ATEX	Ex t IIC	II 1/2 D	PMC51 PMP51 PMP55	r	r	420 mA HART	XA00466P/00	BB
ATEX	Ex d	II 2 G	PMP51 PMP55	r	-	420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA00467P/00	BC
ATEX	Ex nA	II 3 G	PMC51 PMP51 PMP55	r	r	420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA00469P/00	BD
ATEX	Ex ia IIC	II 2 G	PMC51 PMP51 PMP55	r	r	420 mA HART	XA00464P/00	BE
ATEX	Ex ia IIC	II 1/2 D	PMC51	V	V	420 mA HART	XA00465P/00	BF
ATEX	Ex ic IIC	II 3 G	PMC51 PMP51 PMP55	r	r	420 mA HART	XA00489P/00	BG
ATEX	Ex ia Ex ia IIIC	II 1/2 G II 1/2 D	PMC51 PMP51 PMP55	r	r	420 mA HART	XA00468P/00	B1
ATEX	Ex ia IIC	II 2 G II 1/2 G	PMP51 PMP55	r	r	420 mA HART	XA00468P/00	B2
ATEX	Ex d IIC Ex ia IIC	II 2 G II 1/2 G	PMP51 PMP55	r	-	420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA00504P/00	8A

1) Product Configurator, "Approval" ordering feature

Directive	Approval	EPL	Туре	Hous	ing	Electronics	Documentation	Option <sup>1)</sup>
				F31	F15			
IECEx	Ex ia IIC	Ga/Gb	PMC51 PMP51 PMP55	v	r	420 mA HART	XA00470P/00	IA
IECEx	Ex d IIC	Gb	PMP51 PMP55	r	-	420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA00471P/00	IB
IECEx	Ex t IIIC	Da/Db	PMP51 PMP55	r	r	420 mA HART	XA00472P/00	ID
IECEx	Ex ic	Gc	PMC51 PMP51 PMP55	v	r	420 mA HART	XA00488P/00	IE
IECEx	Ex ia IIIC	Da/Db	PMC51	v	v	420 mA HART	XA00487P/00	IF
IECEx	Ex ia IIC Ex ia IIIC	Ga/Gb Da/Db	PMC51 PMP51 PMP55	V	v	420 mA HART	XA00473P/00	I1

1) Product Configurator, "Approval" ordering feature

Directive	Approval	Туре	Housing		Housing		Electronics	Documentation	Option <sup>1)</sup>
			F31	F15	-				
NEPSI	Ex ia IIC T6	PMC51 PMP51 PMP55	V	v	420 mA HART	XA00533P/00	NA		
NEPSI	Ex d IIC T6 Gb	PMP51 PMP55	V	_	420 mA HART	XA00515P/00	NB		

1) Product Configurator, "Approval" ordering feature

Directive	Approval	Electronics	Dokumentation	Option <sup>1)</sup>
TIIS	Ex ia IIC T4	420 mA HART	_	ТА

## 1) Product Configurator, "Approval" ordering feature

Directive	Approval	Electronics	Dokumentation	Option <sup>1)</sup>
INMETRO		420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA01302P/00	MA
INMETRO	Ex d IIC T6/T4 Gb	420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA01284P/00	MB

1) Product Configurator, "Approval" ordering feature

## Installation/Control Drawings

Directive	Approval	Туре	Гуре Housing		Housing		Electronics	Documentation	Option <sup>1)</sup>
			F31	F15					
FM	FM IS Cl.I,II,III Div.1 Gr.A-G, AEx ia FM NI Cl.I Div.2 Gr.A-D FM IS: Zone 0,1,2,20,21,22/FM NI: Zone 2	PMC51 PMP51 PMP55	r	r	<ul> <li>420 mA HART</li> <li>PROFIBUS PA, FOUNDATION Fieldbus</li> </ul>	<ul><li>XA00563P/00</li><li>XA00564P/00</li></ul>	FA		
FM	FM XP Cl.I, II Div.1 Gr.A-D, AEx d (Factory sealed) Zone 1,2	PMP51 PMP55	~	_	<ul><li>420 mA HART</li><li>PROFIBUS PA</li><li>FOUNDATION Fieldbus</li></ul>	XA01163P/00	FB		

Directive	Approval	Туре	Hou	sing	Electronics	Documentation	Option <sup>1)</sup>
			F31	F15			
FM	FM DIP Cl.II, III Div.1 Gr.A-D Zone 21, 22	PMP51 PMP55	r	r	420 mA HART	In preparation	FC
FM	FM NI Cl.I Div.2 Gr.A-D, Zone 2	PMC51 PMP51 PMP55	r	r	420 mA HART	FM3035394	FD
FM	FM IS/XP Cl.I, II Div.1 Gr.A-G, Zone 1,2	PMP51 PMP55	r	_	<ul> <li>420 mA HART</li> <li>PROFIBUS PA, FOUNDATION Fieldbus</li> </ul>	<ul><li>XA01160P/00</li><li>XA00567P/00</li></ul>	F1
CSA	C/US IS Cl.I,II,III Div.1 Gr.A-G, C/US IS Cl.I Div.2 Gr.A-D, Ex ia	PMC51 PMP51 PMP55	r	r	<ul><li>420 mA HART</li><li>PROFIBUS PA, FOUNDATION Fieldbus</li></ul>	<ul><li>XA00556P/00</li><li>XA00558P/00</li></ul>	CA
CSA	CSA C/US CP Cl.I, II Div.1 Gr.B-G, Ex d (factory sealed) Zone 1,2	PMP51 PMP55	r		420 mA HART	XA00577P/00	СВ
CSA	CSA C/US Cl.II, III Div.1 Gr.E-G, Zone 21,22	PMP51 PMP55	r	~	420 mA HART	In preparation	CC
CSA	CSA C/US IS/XP CL.I, II Div.1 Gr.A-G/B-G, Zone 1,2	PMP51 PMP55	r	_	<ul><li>420 mA HART</li><li>PROFIBUS PA, FOUNDATION Fieldbus</li></ul>	<ul><li>XA00577P/00</li><li>XA00561P/00</li></ul>	C1
FM CSA	FM/CSA IS + XP Cl.I, II Div.1 Gr.A-D/B-G FM IS/FM XP Cl.I, II Div.1 Gr.A-G+ CSA IS/XP Cl.I, II Div.1 Gr.A-G, Zone 1,2	PMP55	r	_	420 mA HART	In preparation	8B

1) Product Configurator, "Approval" ordering feature

## **Combination certificate**

Directive	Approval	Туре	Electronics	Documentation	Option <sup>1)</sup>
KEMA/ FM / CSA	ATEX II Ex ia + FM/CSA IS ATEX II 1/2G Ex ia IIC T6 + FM/CSA IS CL.I Div.1 Gr.AD, FM/CSA: Zone 0,1,2	PMC51	420 mA HART, PROFIBUS PA, FOUNDATION Fieldbus	XA00464P/00	8C
			420 mA HART	XA00556P/00 + XA00536P/00	
			PROFIBUS PA, FOUNDATION Fieldbus	XA00564P/00	

## 1) Product Configurator, "Approval" ordering feature

Directive	Approval	Electronics	Documentation	Option 1)
KEMA/ FM / CSA	EMA/ FM / CSA ATEX II Ex ia + FM/CSA IS ATEX II 1/2G Ex ia IIC T6 + FM/CSA IS CL.I Div.1 Gr.A-D, FM/CSA: Zone 0,1,2	420 mA HART	<ul><li>ZD00236P/00</li><li>ZD00239P/00</li></ul>	8C
		PROFIBUS PA, FOUNDATION Fieldbus	XA00474P/00	

1) Product Configurator, "Approval" ordering feature

Manifolds

mannonas									
	For details see SD01553P/00/EN "Mechanical accessories b	For details see SD01553P/00/EN "Mechanical accessories for pressure measuring devices".							
Additional mechanical accessories	Oval flange adapters, pressure gauge valves, shutoff valves, siphons, condensate pots, cable shortening kits, adapter test, flushing rings, block&bleed valves, protective roofs. For details see SD01553P/00/EN "Mechanical accessories for pressure measuring devices".								
Welding necks and Weld-in tool flanges	For dimensions and technical data see technical Informatic	on TIO0426F/	00.						
Designation		PMC51	PMP51	PMP55	Option 1)				
Weld-in adapter G1/2, 316L,		_	V	V	QA				
Weld-in adapter G1/2, 316L, 3.1 I	EN10204-3.1 material, inspection certificate	-	V	V	QB				
Weld-in tool adapter G1/2, Brass		-	V	V	QC				
Weld-in adapter G1, 316L, conical	metal joint	-	V	-	QE				
Weld-in adapter G1, 316L, 3.1 EN	10204-3.1 material, inspection certificate, conical metal joint	_	V	-	QF				
Weld-in tool adapter G1, Brass cor	nical metal joint	_	V	-	QG				
Weld-in adapter G1-1/2, 316L		V	V	V	QJ				
Weld-in adapter G1-1/2, 316L, 3.	1 EN10204-3.1 material, inspection certificate	V	v	V	QK				
Weld-in tool adapter G1-1/2, Bras	3S	V	V	V	QL				
Weld-in flange DRD DN50 65mm,	V	V	v	QP					
Weld-in fl. DRD DN50 65mm, 316	V	V	v	QR					
Weld-in tool flange DRD DN50 65	V	V	V	QS					
Weld-in adapter Uni D65, 316L		V	-	-	QT				
Weld-in adapter Uni D65, 316L, 3	.1 EN10204-3.1 material, inspection certificate	V	-	-	QU				
Weld-in tool adapter Uni D65/D85	5, Brass	~	-	-	Q1				
Weld-in adapter Uni D85, 316L		V	-	-	Q2				
Weld-in adapter Uni D85, 316L, 3	.1 EN10204-3.1 material, inspection certificate	V	-	-	Q3				
Adapter Uni > DIN11851 DN40, 3	16L, slotted-nut	V	-	-	RA				
Adapter Uni > DIN11851 DN50, 3	16L, slotted-nut	~	-	-	RB				
Adapter Uni > DRD DN50 65mm,	316L	V	-	-	RC				
Adapter Uni > Clamp 2", 316L		V	-	-	RD				
Adapter Uni > Clamp 3", 316L		V	-	V	RE				
Adapter Uni > Varivent N, 316L		~	-	-	RF				
Adapter Uni > Cherry Burell 2", 31	6L	V	-	-	RH				
Adapter Uni > DIN11851 DN40, 3	16L, 3.1, slotted-nut, EN10204-3.1 material, inspection certificate	V	-	-	R1				
Adapter Uni > DIN11851 DN50, 3	16L, 3.1, slotted-nut, EN10204-3.1 material, inspection certificate	V	-	-	R2				
Adapter Uni > DRD DN50 65mm,	V	-	-	R3					
Adapter Uni > Clamp 2", 316L, 3.1 EN10204-3.1 material, inspection certificate					R4				
Adapter Uni > Clamp 3", 316L, 3.1	EN10204-3.1 material, inspection certificate	~	-	V	R5				
Adapter Uni > Varivent, 316L, 3.1	EN10204-3.1 material, inspection certificate	~	-	-	R6				
Adapter Uni > Cherry Burell, 316L	, 3.1 EN10204-3.1 material, inspection certificate	V	-	-	R7				

## Accessories

→ 🗎 71

1) Product Configurator, "Accessories" ordering feature

Mounting bracket for wall and pipe mounting	→ 🗎 37		
M12 connector	→ 🖺 24		

For dimensions and technical data see technical Information TI00426F/00.

## **Registered trademarks**

HART®	Registered trademark of the FieldComm Group, Austin, USA
PROFIBUS®	Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany
FOUNDATION <sup>TM</sup> Fieldbus	Registered trademark of the FieldComm Group, Austin, USA



www.addresses.endress.com

